

Fifo_top

Fifo_sva

Fifo_Test

Config_obj

Main sequence

Reset sequence

Fifo_env

Fifo_scoreboard

Fifo_coverage_collector

Fifo_Agent

Config_obj

Fifo_seq_item

Fifo_sequencer

Fifo_monitor

Fifo_driver

Fifo_vif

Fifo_vif

Fifo_interface

DUT

