



22. Securing the bearings



- Align the bearing so that it is centered on the bearing clip. Approximately the same piece of bearing should be visible on each side.
- Maintain the bearing position and fully tighten both screws.
- After installing all the bearings, check their orientation again.

[Next](#) →