



20. IR-sensor parts preparation



For the following steps, please prepare:



Prusa IR-sensor (1x)



M2x8 screw (1x)



M3x40 screw (1x)



BE CAREFUL with the filament sensor, do not touch the PCB nor the chips on it. Hold the PCB from sides.



Next →

