



## 19. Y-axis: Y-carriage



### For the following steps, please prepare:

- Y-carriage (1x)
- Linear bearing (3x)
- Bearing clip (3x)
- M3x6 screw (6x)

**The printer's package contains a lubricant, which is intended for maintenance.** No need to use it now as the bearings are lubricated. There is a dedicated online manual on how to clean the printer and apply the lubricant. See [help.prusa3d.com/maintenance-tips](https://help.prusa3d.com/maintenance-tips)



Next →

