

36. Aligning the Y-axis belt



- Make sure the belt is placed in the "axis" of the printer. Both top and bottom part of the belt should be parallel (above each other).
- To adjust the belt position, release screws on the pulley and slightly move with it, until you reach the best position.
- Tighten both screws on the pulley.



Next →

