









49. Extruder preparation and mounting



-  Insert the zip ties in the X-carriage like in the picture.
-  Lower the X-axis at about 1/3 from the top.
-  Turn the printer like in the picture with X-axis motor and shorter extrusions facing towards you. Align the bearings similarly to the picture. The exact position of the lower bearing doesn't matter for now.
-  Turn all three bearings so that the markings are facing you.
-  Place the extruder onto the bearings from the other side. Make sure the bearing openings in the X-carriage are facing towards you (together with the shorter extrusions on the frame) and the top bearings fit perfectly into the groove.
-  We will adjust the lower bearing later on.
-  Tighten and cut the zip ties.



Next →

