


56. Aligning the X-axis belt



- Both top and bottom part of the belt should be parallel (above each other).
- To adjust the belt position, release the screws on the pulley and move it slightly until you reach the best position.
- Tighten both screws on the pulley.
- ⓘ If you are having a problem with the belt alignment, check the orientation of the pulley. Make sure it is oriented in the same way as seen in the picture.



Next →

