



33. Bearing assembly



 **Insert both bearings** in the pulley. Be aware that bearings can slip out during assembly.



Next →

