











9. X-axis: assembly



-  **NOW, PLEASE BE VERY CAREFUL!** Gently insert the rod straight into the bearings, do not apply too much force and do not tilt the rod!
-  In case you manage to push out balls from the bearings, please count them. One or two balls are ok, if there are more of them, please consider ordering new bearings.
-  Insert the rods with bearings fully into the printed parts. **The holes in the printed parts must be clean.** Inspect the holes inside for dirt or filament residue.
-  **Insert the rods very carefully. Do not tilt the rods too much.**
-  Ensure the correct orientation of the parts and rods.
-  There is a special opening in the top/bottom of both X-ends. Check if you pressed the smooth rod all the way in.



Next →

