

To run the software, first open the input excel spreadsheet and specify pole-line system parameters. Then save this file as tab delimited “.txt” file.

Run the main script file titled “PLA_Solver.m”.