

QUIK-REVIEW: Connecting to a Station



To connect to a station on a local or remote platform, click the **Open (folder) icon** on the Toolbar.

Complete the fields in the **Open Station** dialog box as follows:

Click the **OK button** to accept all settings.

The Station opens in the Nav Tree, and the Station Summary view displays in the View Pane.

- Enter IP address of JACE
- Set to whichever port is used for the platform daemon. (Port 3011 is default.)
- Type in a valid station user name & password
- If you want Workbench to remember the user name and password, leave this checkbox checked.

You can also right-click directly on the host IP (for remote platforms – e.g., JACE) in the Nav Tree and select **Open Station (fox)** from the pop-up menu.

If you are **switching between multiple stations** on your local host (workstation PC), you must first connect to the platform on your local host before you can start a different station, using the Application Director.

On a Windows® based platform, multiple stations can co-exist, but normally only one station should be running at a time.

On a **QNX-based JACE**, however, there should only be a single station installed.

You should ONLY have multiple stations running at the same time on your local host when those stations have been configured to use different server ports:

FOX – 1911, 1912, 1913, etc. **WEB (HTTP)** – 80, 81, 82, etc.

Otherwise, they will be in conflict with each other and you will only be able to connect to the first station that was started.

Before starting (and then connecting to) a different station on the local host, you must first **STOP** the currently running station using the Application Director.

Interim station status: **Stopping**
Final station status: **Idle**

Highlight the station you wish to start and click the **START** button to start the station.

Interim station status: **Starting**
Final station status: **Running**

Connect to the running station by right-clicking on the **dimmed station icon**.

Click the **OK button** to accept all settings.

The Station opens in the Nav Tree, and the Station Summary view displays in the View Pane.