



# QUIK-REVIEW



## LICENSE MANAGER FUNCTIONS

VIEW/TOOL	FUNCTIONS	PLATFORM CONN REQ'D	ACCESS FROM	LOCATION
<b>PLATFORM LICENSE MANAGER</b>	<ul style="list-style-type: none"><li>▪ <u>Import</u> licenses and certificates to remote platforms (JACE or PC)</li><li>▪ <u>View</u> contents of licenses and certificates</li><li>▪ <u>Delete</u> licenses and certificates</li></ul>	YES	Platform tools	Specific local or remote platform container
<b>WORKBENCH LICENSE MANAGER</b> <i>(see the View Selector)</i>	<ul style="list-style-type: none"><li>▪ <u>Manage</u> contents of local license database</li><li>▪ Installed license is <u>automatically loaded</u> into the <i>Local License Database</i> as you connect to any remote platform and activate the platform <i>License Manager</i> view</li></ul>	NO	<b>Tools menu:</b> – <i>Local License Database</i>	<b>Actual licenses reside in Local Host:</b> – My File System – Sys Home – licenses – db