



QUIK-REVIEW



APPLICATION DIRECTOR STATION FUNCTIONALITY

APPLICATION DIRECTOR ACTIVE BUTTONS							
HOST TYPE	STATION STATUS	START	STOP	RESTART	REBOOT	KILL	SAVE BOG
WINDOWS-BASED PLATFORMS (Local host) – PC	Running	NOT ACTIVE	X	X ¹	NOT ACTIVE	X ³	X ⁴
	Failed	X	NOT ACTIVE	NOT ACTIVE	NOT ACTIVE	NOT ACTIVE	NOT ACTIVE
	Idle	X	RESULTS IN IDLE STATUS	NOT ACTIVE	NOT ACTIVE	RESULTS IN IDLE STATUS	NOT ACTIVE
WINDOWS-BASED PLATFORMS (Remote) – PC or JACE	Running	NOT ACTIVE	X	X ¹	X ²	X ³	X ⁴
	Failed	X	NOT ACTIVE	NOT ACTIVE	NOT ACTIVE	RESULTS IN FAILED STATUS	NOT ACTIVE
	Idle	X	RESULTS IN IDLE STATUS	NOT ACTIVE	X ²	NOT ACTIVE	NOT ACTIVE
QNX-BASED PLATFORMS (Remote) – JACE	Running	NOT ACTIVE	X	NOT ACTIVE	X ²	X ³	X ⁴
	Failed	X	NOT ACTIVE	NOT ACTIVE	X ²	RESULTS IN FAILED STATUS	NOT ACTIVE
	Halted	NOT ACTIVE	RESULTS IN HALTED STATUS	NOT ACTIVE	X ²	NOT ACTIVE	NOT ACTIVE

- 1 – Restart button only active to Windows-based platforms
- 2 – Reboot button always active for remote platforms
- 3 – Kill button active only when station status is **RUNNING**, **STARTING** or **STOPPING**
- 4 – Station configuration saved to config.bog file