

AntMiner FAQ

Q: How to reset to the default state?

A: There is no reset button in the first batch of AntMiner. If AntMiner has to be reset, please follow these steps.

Step 1: Set your PC's IP address as 192.x.168.2.x, and then connect AntMiner with your PC via a network cable.

Step2: Power on AntMiner for a while when it is in the normal state. The WAN LED should be light.

Step3: Short the RESET PIN to 3.3V like the following picture for more than 3 seconds.



Second pin from left



Second pin from Bottom

Step4: Power off, and then disconnect RESET pin from 3.3V.

Step5: Power on. Ping 192.168.2.99.