

**Reference** [Language \(//www.arduino.cc/en/Reference/HomePage\)](#) | [Libraries \(//www.arduino.cc/en/Reference/Libraries\)](#) | [Comparison \(//www.arduino.cc/en/Reference/Comparison\)](#) | [Changes \(//www.arduino.cc/en/Reference/Changes\)](#)

# Wire.begin()

# Wire.begin(address)

## Description

Initiate the Wire library and join the I2C bus as a master or slave. This should normally be called only once.

## Parameters

address: the 7-bit slave address (optional); if not specified, join the bus as a master.

## Returns

None

[Reference Home \(//www.arduino.cc/en/Reference/HomePage\)](#)

*Corrections, suggestions, and new documentation should be posted to the Forum (<http://arduino.cc/forum/index.php/board,23.0.html>).*

The text of the Arduino reference is licensed under a Creative Commons Attribution-ShareAlike 3.0 License (<http://creativecommons.org/licenses/by-sa/3.0/>). Code samples in the reference are released into the public domain.

## Share



## NEWSLETTER

ENTER YOUR EMAIL TO SIGN UP

SUBSCRIBE

Terms Of Service (<http://www.arduino.cc/en/Main/AboutTermsOfService>)

Privacy Policy (<http://www.arduino.cc/en/Main/PrivacyPolicy>)

Contact Us (<http://www.arduino.cc/en/Main/ContactUs>)

About Us (<http://www.arduino.cc/en/Main/AboutUs>)

Careers (<http://www.arduino.cc/Careers>)

(<https://www.arduino.cc/en/Team>)