

# PENDANT INTERFACE GUIDANCE

## WELDING MENU 1

X:0.000  
Y:0.000  
Z:0.000  
RunLinear

## WELDING MENU 2

A.1:0.000A4:0.000  
A2:0.000A5:0.000  
A3:0.000A6:0.000  
RunLinear

## WELDING MENU 3

Current Pt1  
Current SpdLOW  
RunLinear

## WELDING PAUSE MENU

PAUSED  
RunLinear