

Commissioning Report of Air Dryer						
	Item	Normal Standard	No.1	No.2	No.3	No.4
1	Check the connection of power cable and cooling water line before start air dryer		OK	OK	OK	OK
2	Check display of Ref lower pressure & high pressure before starting	0.5-1MPa	1MPa	1MPa	1MPa	1MPa
3	Check the display of both pressure gauge for Ref lower pressure & high pressure	0.3-0.6MPa (Ref lower pressure) ≤2MPa (Ref high pressure)	0.45MPa/1.3Mpa	0.45MPa /1.3Mpa	0.45MPa /1.3Mpa	0.4MPa/1.3Mpa
4	Others		During commissioning, one automatic water exhasut valve is damaged, now check and replacment have already been done and the valve is alredy running normally	None	None	None
Date		1082017				
Result		Qualified				
Signature						



2017.8

2017.8 济南安地冶金机械设备有限公司
ANDE METALLURGICAL MACHINERY CO., LTD.