	VEDANTA LIMITED – VALUE ADDED BUSINESS	Document No:	VL/IMS/PID1/INST/WI/07
	INTEGRATED MANAGEMENT SYSTEM	Revision Date:	05/01/2022
	Work Instructions for Reading Manometer	Revision No:	05
		Page No.:	1 of 2

## **WORK INSTRUCTION FOR READING MANOMETER**

**Objective:** To Read the manometer for transmitter calibration/checking of pressure/Pressure measurement.

**Scope:** This procedure is applicable for manometer reading during transmitter Calibration.

**Reference:** Operating manual of Manometer.

**Standard used:** Analog/Digital Manometer Model: HD700

**Performance Criteria:** Accuracy of measurement of Pressure TX as mentioned in MMTE

**Reference:** RISK /INST/17

**Aspect for the Activity :** Waste generation

### **Identification of Hazards:**

**Physical:** Pressure, Honeybee/snake bite, Noise

**Mechanical:** Trip & Fall

**Chemical:** CO Gas poisoning, Dust, Graphite

**Ergonomics:** Insufficient work practices

**Hazard due to Human Behavior/Human error:** Not adhering to WI/ PPE, Alcoholism, Use on non-certified tools/equipment.


**Responsibility:** Sr. Engineer Instrumentation/Associate / Inst Technician

### **Procedure:**

All engineers/technicians should follow this procedure while isolating and removing instrument for calibration, re-installation and commissioning. Care must be taken while removing and refixing to avoid contact with hot areas, gas & steam leakages. While keeping the manometer care should be taken to keep it safely so as not to fall down.

### **U tube manometer:**

- 1) Ensure that water is clean and does not stick to glass tube.
- 2) Connect flexible PU tube to one end of U tube taking care that there is no leak in the connection.
- 3) Adjust tripod so that manometer is in vertical plane and water is at '0' in both arms of 'U' tube.
- 4) Connect pressure point at other end of PU tube
- 5) Record difference in the level of water in the arms in millimeters.

	<b>VEDANTA LIMITED – VALUE ADDED BUSINESS</b>	<b>Document No:</b>	<b>VL/IMS/PID1/INST/WI/07</b>
	<b>INTEGRATED MANAGEMENT SYSTEM</b>	<b>Revision Date:</b>	<b>05/01/2022</b>
	<b>Work Instructions for Reading Manometer</b>	<b>Revision No:</b>	<b>05</b>
		<b>Page No.:</b>	<b>2 of 2</b>

### **Well type manometer:**

- 1) Ensure that water is clean and does not stick to glass tube.
- 2) Connect flexible PU tube to well type manometer taking care that there is no leak in the connection.
- 3) Adjust tripod so that manometer is in vertical plane and water is at '0' .
- 4) Connect pressure point at other end of PU tube.
- 5) Note down the reading, Record difference in the level of water (i.e. reading when pressure applied - 0) in millimeters.

<b>Prepared By:</b> Associate Manager– Electrical & Instrumentation PID1	<b>Reviewed &amp; Issued By:</b> Management Representative	<b>Approved By:</b> Head – Electrical & Instrumentation PID1
<b>Signature:</b>	<b>Signature:</b>	<b>Signature:</b>
<b>Date: 05/01/2022</b>	<b>Date: 05/01/2022</b>	<b>Date: 05/01/2022</b>