

GROUP A – Direct Wired Maps

Pin	Mode 1 Player 1 MAME*		Mode 2 Player 2 MAME*		Mode 3 Players 1 & 2 MAME*		Mode 4 Players 3 & 4 MAME*		Mode 5 Player 1 Pinball**		Mode 6 Generic Alphabetic		Mode 7 Generic Hexidecimal	
A1	5	P1 Coin	6	P2 Coin	5	P1 Coin	7	P3 Coin	5	Coin	A	A	0	0
A2	1	P1 Start	2	P2 Start	1	P1 Start	3	P3 Start	1	Start	B	B	1	1
A3	Right Arrow	P1 Right	G	P2 Right	Right Arrow	P1 Right	L	P3 Right	Right Arrow	Right	C	C	2	2
A4	Left Arrow	P1 Left	D	P2 Left	Left Arrow	P1 Left	J	P3 Left	Left Arrow	Left	D	D	3	3
A5	Up Arrow	P1 Up	R	P2 Up	Up Arrow	P1 Up	I	P3 Up	Up Arrow	Up	E	E	4	4
A6	Down Arrow	P1 Down	F	P2 Down	Down Arrow	P1 Down	K	P3 Down	Down Arrow	Down	F	F	5	5
A7	L-Ctrl	P1 Button 1	A	P2 Button 1	L-Ctrl	P1 Button 1	R-Ctrl	P3 Button 1	L-Ctrl	L/Magnasave	G	G	6	6
A8	L-Alt	P1 Button 2	S	P2 Button 2	L-Alt	P1 Button 2	R-Shift	P3 Button 2	R-Ctrl	R/Magnasave	H	H	7	7
A9	Space	P1 Button 3	Q	P2 Button 3	Space	P1 Button 3	Enter	P3 Button 3	Space	Fwd/Nudge	I	I	8	8
A10	L-Shift	P1 Button 4	W	P2 Button 4	Enter	Select	P	Pause	L-Shift	L/Flipper	J	J	9	9
B1	Z	P1 Button 5	I	P2 Button 5	6	P2 Coin	8	P4 Coin	Z	L/Nudge	K	K	A	A
B2	X	P1 Button 6	K	P2 Button 6	2	P2 Start	4	P4 Start	R-Shift	R/Flipper	L	L	B	B
B3	C	P1 Button 7	J	P2 Button 7	G	P2 Right	Numpad-6	P4 Right	/	R/Nudge	M	M	C	C
B4	V	P1 Button 8	L	P2 Button 8	D	P2 Left	Numpad-4	P4 Left	Q	Quit (VP)	N	N	D	D
B5	Enter	Select	Enter	Select	R	P2 Up	Numpad-8	P4 Up	Enter	Plunger	O	O	E	E
B6	P	Pause	P	Pause	F	P2 Down	Numpad-2	P4 Down	Pause/Break	Pause	P	P	F	F
B7	F7	Load/Save	F7	Load/Save	A	P2 Button 1	Numpad-0	P4 Button 1	A	L/Up/Flipper	Q	Q	Space	Space
B8	Tilde	OSD	Tilde	OSD	S	P2 Button 2	Numpad-Decimal	P4 Button 2	Apostrophe	(R/Up/Flipper	R	R	Enter	Enter
B9	Tab	Config	Tab	Config	Q	P2 Button 3	Numpad-Enter	P4 Button 3	Tab	View Backglass	S	S	Tab	Tab
B10	Esc	Cancel	Esc	Cancel	Esc	Cancel	Tab	Config	Esc	Exit	Esc	Esc	Esc	Esc

Important Notes

Press HWB to toggle modes

Long press of HWB to toggle groups

Group A contains the most popular modes.

The complete mapping table (shown on next page) describes all of the available groups and modes.

Keymapping Presets for Degenatrons 20 Input Arcade Encoder

Version 1.5, 9th July 2012

	Pin Number	Mode 1 Player 1 MAME*		Mode 2 Player 2 MAME*		Mode 3 Players 1 & 2 MAME*		Mode 4 Players 3 & 4 MAME*		Mode 5 Player 1 Pinball**		Mode 6 Generic Alphabetic		Mode 7 Generic Hexidecimal	
Group A Direct Wired Maps	A1	5	P1 Coin	6	P2 Coin	5	P1 Coin	7	P3 Coin	5	Coin	A	A	0	0
	A2	1	P1 Start	2	P2 Start	1	P1 Start	3	P3 Start	1	Start	B	B	1	1
	A3	Right Arrow	P1 Right	G	P2 Right	Right Arrow	P1 Right	L	P3 Right	Right Arrow	Right	C	C	2	2
	A4	Left Arrow	P1 Left	D	P2 Left	Left Arrow	P1 Left	J	P3 Left	Left Arrow	Left	D	D	3	3
	A5	Up Arrow	P1 Up	R	P2 Up	Up Arrow	P1 Up	I	P3 Up	Up Arrow	Up	E	E	4	4
	A6	Down Arrow	P1 Down	F	P2 Down	Down Arrow	P1 Down	K	P3 Down	Down Arrow	Down	F	F	5	5
	A7	L-Ctrl	P1 Button 1	A	P2 Button 1	L-Ctrl	P1 Button 1	R-Ctrl	P3 Button 1	L-Ctrl	L/Magnasave	G	G	6	6
	A8	L-Alt	P1 Button 2	S	P2 Button 2	L-Alt	P1 Button 2	R-Shift	P3 Button 2	R-Ctrl	R/Magnasave	H	H	7	7
	A9	Space	P1 Button 3	Q	P2 Button 3	Space	P1 Button 3	Enter	P3 Button 3	Space	Fwd/Nudge	I	I	8	8
	A10	L-Shift	P1 Button 4	W	P2 Button 4	Enter	Select	P	Pause	L-Shift	L/Flipper	J	J	9	9
Group B Extended Maps	B1	Z	P1 Button 5	L	P2 Button 5	6	P2 Coin	8	P4 Coin	Z	L/Nudge	K	K	A	A
	B2	X	P1 Button 6	K	P2 Button 6	2	P2 Start	4	P4 Start	R-Shift	R/Flipper	L	L	B	B
	B3	C	P1 Button 7	J	P2 Button 7	G	P2 Right	Numpad-6	P4 Right	/	R/Nudge	M	M	C	C
	B4	V	P1 Button 8	L	P2 Button 8	D	P2 Left	Numpad-4	P4 Left	Q	Quit (VP)	N	N	D	D
	B5	Enter	Select	Enter	Select	R	P2 Up	Numpad-8	P4 Up	Enter	Plunger	O	O	E	E
	B6	P	Pause	P	Pause	F	P2 Down	Numpad-2	P4 Down	Pause/Break	Pause	P	P	F	F
	B7	F7	Load/Save	F7	Load/Save	A	P2 Button 1	Numpad-0	P4 Button 1	A	L/Up/Flipper	Q	Q	Space	Space
	B8	Tilde	OSD	Tilde	OSD	S	P2 Button 2	Numpad-Decimal	P4 Button 2	Apostrophe	(R/Up/Flipper	R	R	Enter	Enter
	B9	Tab	Config	Tab	Config	Q	P2 Button 3	Numpad-Enter	P4 Button 3	Tab	View Backglass	S	S	Tab	Tab
	B10	Esc	Cancel	Esc	Cancel	Esc	Cancel	Tab	Config	Esc	Exit	Esc	Esc	Esc	Esc
Group C MAME/Pinball	Pin Number	Mode 1 Player 1 MAME*		Mode 2 Player 1 Pinball**											
	A1	5	P1 Coin	5	Coin										
	A2	1	P1 Start	1	Start										
	A3	Right Arrow	P1 Right	Right Arrow	Right										
	A4	Left Arrow	P1 Left	Left Arrow	Left										
	A5	Up Arrow	P1 Up	Up Arrow	Up										
	A6	Down Arrow	P1 Down	Down Arrow	Down										
	A7	L-Ctrl	P1 Button 1	L-Ctrl	L/Magnasave										
	A8	L-Alt	P1 Button 2	R-Ctrl	R/Magnasave										
	A9	Space	P1 Button 3	Space	Fwd/Nudge										
Group D Hot-Swap MAME/Pinball 2 Players Extended	Pin Number	Mode 1 Players 1 & 2 MAME* Extended		Mode 2 Players 1 & 2 Pinball**											
	A1	Right Arrow	P1 Right	Right Arrow	Right										
	A2	Left Arrow	P1 Left	Left Arrow	Left										
	A3	Up Arrow	P1 Up	Up Arrow	Up										
	A4	Down Arrow	P1 Down	Down Arrow	Down										
	A5	L-Ctrl	P1 Button 1	L-Ctrl	L/Magnasave										
	A6	L-Alt	P1 Button 2	R-Ctrl	R/Magnasave										
	A7	Space	P1 Button 3	Space	Fwd/Nudge										
	A8	L-Shift	P1 Button 4	L-Shift	L/Flipper										
	A9	Z	P1 Button 5	Z	L/Nudge										
Group E Hot-Swap Emulators	Pin Number	Mode 1 Player 1 MAME*		Mode 2 Generic Alphabetic		Mode 3 Generic Hexidecimal									
	A1	5	P1 Coin	A	A	0	0								
	A2	1	P1 Start	B	B	1	1								
	A3	Right Arrow	P1 Right	C	C	2	2								
	A4	Left Arrow	P1 Left	D	D	3	3								
	A5	Up Arrow	P1 Up	E	E	4	4								
	A6	Down Arrow	P1 Down	F	F	5	5								
	A7	L-Ctrl	P1 Button 1	G	G	6	6								
	A8	L-Alt	P1 Button 2	H	H	7	7								
	A9	Space	P1 Button 3	I	I	8	8								
Group F External LED and Sound	Pin Number	Mode 1 Player 2 MAME*		Mode 2 Player 2 MAME*		Mode 3 Players 1 and 2 MAME*		Mode 4 Players 3 and 4 MAME*		Mode 5 Player 1 Pinball*		Mode 6 Generic Alphabetic		Mode 7 Generic Hexidecimal	
	A1	5	P1 Coin	6	P2 Coin	5	P1 Coin	7	P3 Coin	5	Coin	A	A	0	0
	A2	1	P1 Start	2	P2 Start	1	P1 Start	3	P3 Start	1	Start	B	B	1	1
	A3	Right Arrow	P1 Right	G	P2 Right	Right Arrow	P1 Right	L	P3 Right	Right Arrow	Right	C	C	2	2
	A4	Left Arrow	P1 Left	D	P2 Left	Left Arrow	P1 Left	J	P3 Left	Left Arrow	Left	D	D	3	3
	A5	Up Arrow	P1 Up	R	P2 Up	Up Arrow	P1 Up	I	P3 Up	Up Arrow	Up	E	E	4	4
	A6	Down Arrow	P1 Down	F	P2 Down	Down Arrow	P1 Down	K	P3 Down	Down Arrow	Down	F	F	5	5
	A7	L-Ctrl	P1 Button 1	A	P2 Button 1	L-Ctrl	P1 Button 1	R-Ctrl	P3 Button 1	L-Ctrl	L/Magnasave	G	G	6	6
	A8	L-Alt	P1 Button 2	S	P2 Button 2	L-Alt	P1 Button 2	R-Shift	P3 Button 2	R-Ctrl	R/Magnasave	H	H	7	7
	A9	Space	P1 Button 3	Q	P2 Button 3	Space	P1 Button 3	Enter	P3 Button 3	Space	Fwd/Nudge	I	I	8	8
Group G Custom	Pin Number	Mode 1 Custom Mappings		Mode 2 Custom Mappings		Mode 3 Custom Mappings		Mode 4 Custom Mappings		Mode 5 Custom Mappings		Mode 6 Custom Mappings		Mode 7 Custom Mappings	
	A1	5	P1 Coin	6	P2 Coin	5	P1 Coin	7	P3 Coin	5	Coin	A	A	0	0
	A2	1	P1 Start	2	P2 Start	1	P1 Start	3	P3 Start	1	Start	B	B	1	1
	A3	Right Arrow	P1 Right	G	P2 Right	Right Arrow	P1 Right	L	P3 Right	Right Arrow	Right	C	C	2	2
	A4	Left Arrow	P1 Left	D	P2 Left	Left Arrow	P1 Left	J	P3 Left	Left Arrow	Left	D	D	3	3
	A5	Up Arrow	P1 Up	R	P2 Up	Up Arrow	P1 Up	I	P3 Up	Up Arrow	Up	E	E	4	4
	A6	Down Arrow	P1 Down	F	P2 Down	Down Arrow	P1 Down	K	P3 Down	Down Arrow	Down	F	F	5	5
	A7	L-Ctrl	P1 Button 1	A	P2 Button 1	L-Ctrl	P1 Button 1	R-Ctrl	P3 Button 1	L-Ctrl	L/Magnasave	G	G	6	6
	A8	L-Alt	P1 Button 2	S	P2 Button 2	L-Alt	P1 Button 2	R-Shift	P3 Button 2	R-Ctrl	R/Magnasave	H	H	7	7
	A9	Space	P1 Button 3	Q	P2 Button 3	Space	P1 Button 3	Enter	P3 Button 3	Space	Fwd/Nudge	I	I	8	8
One or more custom modes to suit your own specific mapping requirements.															
By default this is an empty mapping.															