

Pin	Mode 1		Mode 2		Mode 3		Mode 4	
	Player 1 MAME		Player 2 MAME		Players 1 & 2 MAME		Players 3 & 4 MAME	
A1	5	P1 Coin	6	P2 Coin	5	P1 Coin	7	P3 Coin
A2	1	P1 Start	2	P2 Start	1	P1 Start	3	P3 Start
A3	Right Arrow	P1 Right	G	P2 Right	Right Arrow	P1 Right	L	P3 Right
A4	Left Arrow	P1 Left	D	P2 Left	Left Arrow	P1 Left	J	P3 Left
A5	Up Arrow	P1 Up	R	P2 Up	Up Arrow	P1 Up	I	P3 Up
A6	Down Arrow	P1 Down	F	P2 Down	Down Arrow	P1 Down	K	P3 Down
A7	L-Ctrl	P1 Button 1	A	P2 Button 1	L-Ctrl	P1 Button 1	R-Ctrl	P3 Button 1
A8	L-Alt	P1 Button 2	S	P2 Button 2	L-Alt	P1 Button 2	R-Shift	P3 Button 2
A9	Space	P1 Button 3	Q	P2 Button 3	Space	P1 Button 3	Enter	P3 Button 3
A10	L-Shift	P1 Button 4	W	P2 Button 4	Enter	Select	P	Pause
B1	Z	P1 Button 5	I	P2 Button 5	6	P2 Coin	8	P4 Coin
B2	X	P1 Button 6	K	P2 Button 6	2	P2 Start	4	P4 Start
B3	C	P1 Button 7	J	P2 Button 7	G	P2 Right	Numpad-6	P4 Right
B4	V	P1 Button 8	L	P2 Button 8	D	P2 Left	Numpad-4	P4 Left
B5	Enter	Select	Enter	Select	R	P2 Up	Numpad-8	P4 Up
B6	P	Pause	P	Pause	F	P2 Down	Numpad-2	P4 Down
B7	F7	Load/Save	F7	Load/Save	A	P2 Button 1	Numpad-0	P4 Button 1
B8	Tilde	OSD	Tilde	OSD	S	P2 Button 2	Numpad-Decimal	P4 Button 2
B9	Tab	Config	Tab	Config	Q	P2 Button 3	Numpad-Enter	P4 Button 3
B10	Esc	Cancel	Esc	Cancel	Esc	Cancel	Tab	Config

Important Notes

Press HWB to toggle modes