


## TSS 01 - USER MANUAL

### SpaceScan Series

Photoelectric light curtains

EN


Product Data			
Electrical Data			
	SST (Transmitter)	SSR (Receiver)	
Supply voltage	12 – 30 V dc		
Max. Voltage ripple	15 % (within supply range)		
Current consumption	100 mA (RMS)	50 mA	
Max. output load	-	200 mA	
Reverse polarity protected	Yes		
Short circuit protected	-	Yes	
Inductive load protection	-	Yes	
Environmental Data			
Light immunity @5° incidence	> 100.000 lux		
Temperature, operation	-30 to + 60 °C		
Sealing class	IP 67		
Marking			

Available Models			
	Model	Beam spacing	Sensing Range
Transmitter	SST 01-10-xxx-xxx-05-H-1D1-0.5-J5	5 mm	10 m
	SST 01-10-xxx-xxx-10-H-1D1-0.5-J5	10 mm	
	SST 01-10-xxx-xxx-20-H-1D1-0.5-J5	20 mm	
	SST 01-10-xxx-xxx-40-H-1D1-0.5-J5	40 mm	
Receiver	SSR 01-4-xxx-xxx-05-H-1Dx-0.5-J8	5 mm	0 m - 4 m
	SSR 01-4-xxx-xxx-10-H-1Dx-0.5-J8	10 mm	
	SSR 01-4-xxx-xxx-20-H-1Dx-0.5-J8	20 mm	
	SSR 01-4-xxx-xxx-40-H-1Dx-0.5-J8	40 mm	
	SSR 01-10-xxx-xxx-05-H-1Dx-0.5-J8	5 mm	1 m – 10 m
	SSR 01-10-xxx-xxx-10-H-1Dx-0.5-J8	10 mm	
	SSR 01-10-xxx-xxx-20-H-1Dx-0.5-J8	20 mm	
	SSR 01-10-xxx-xxx-40-H-1Dx-0.5-J8	40 mm	

	Model	Output Mode
Receivers	SSR 01-x-xxx-xxx-xx-H-1D1-0.5-J8	Light operated (Normally closed)
	SSR 01-x-xxx-xxx-xx-H-1D2-0.5-J8	Dark operated (Normally open)

## Connection


### Wiring Diagrams



SST 5 pole M12 male connector

SSR 8 pole M12 male connector



Transmitter Model	Black wire connected to ( - )	Black wire not connected	Black wire connected to ( + )
SST 01-10-xxx-xxx-xx-H-1D1-0.5-J5	not transmitting	transmitting	transmitting



Wiring diagram

## Installation & Adjustments

Adjustment	
No initial set up or adjustments are required, due the automatic signal-tracking (AST) feature that automatically adjusts the gain of each individual beam on the system.	
1	Mount the transmitter (SST) and receiver (SSR) facing each other and correctly aligned.
2	Wire the sensor according to the wiring diagram. Notice that the pin 7 on the SSR and the pin 3 on SST (blue wires) must be connected together to a common GND ( - ). Make sure the SSR output load does not exceed 200 mA.
3	Check for correct wiring before turning power on.
4	When the power on indicators (green LED) is on the system is operating.
5	The position of the receiver and transmitter must not be changed after power-up. The light curtain is only intended for static applications.

Detection	Output mode	Output status	Output indicator (yellow led)
Present	Dark operated	Closed	On
	Light operated	Open	Off
	Dark operated	Open	Off
Absent	Light operated	Closed	On
	Dark operated	Closed	On
	Light operated	Closed	On

SSR, Test Input
The transmitter SST can be externally disabled and enabled via the black control wire for test purposes. When the transmitter is disabled the receiver will break/open the output relay and the output indicator (yellow LED) will be turned off.

SSR, Parallel or crossed beam selection, Ctrl 1
Crossed beams can be selected by connecting pin 6 permanently (pink SSR Ctrl 1 wire) to ground (GND) before power on. The green LED (Power on indicator) will flash 2 times after power-up if crossed beams are selected.

SSR, Blanking function, Ctrl 2
This function will ensure that the light curtain will ignore the beams under normal operation which are obstructed during the blanking setup.

The blanking setup mode is activated by powering up the SSR with pin 8 (red SSR Ctrl2 wire) connected to ground (GND). Blanking setup time up to 2,5 seconds from power up (depending on the model). The SSR will blink with the green LED (approximately 0,5 Hz) when blanking is completed and stored in non-volatile memory. Remove the power to the SSR and remove the pin 8 wire from ground and power SSR up again to resume normal operation with blanked beams. The yellow LED (output indicator) on SSR will flash 2 times after power-up if one or more beams are blanked.

During normal operation pin 8 can be left connected to (+) V dc or disconnected. Notice that the beams will remain blanked until a new blanking procedure is done.

Indicators	
Red LED	Status indicator
Yellow LED	Output indicator
Green LED	Power on indicator

Troubleshooting	
Probable Reason	Corrective Action
1. Symptom: Status indicator (Red LED) on SSR is constant on.	
SST has no power.	Check supply and supply cable to the SST
SST & SSR white, grey and blue wires are not connected correctly.	Connect the wires.

2. Symptom: Status indicator (Red LED) on SSR is flashing quickly after power-up.	
One or more beams are obstructed during power-up	Remove obstruction between SSR and SST or perform a blanking for the SSR to ignore the obstruction.

3. Symptom: Green LED on SSR is flashing.	
Blanking setup is completed.	Turn off the SSR. Remove connection between pin 8 (red wire) and (-) pin 7 (blue wire).
	Turn the SSR on again. Be aware that beams may now be blanked.
	Repeat correct blanking process without obstruction of any beams if no beams are intended to be blanked.

4. Symptom: Output indicator (Yellow LED) on SSR is flashing.	
Severe electrical interference.	Separate SSR and SST supply cable from high voltage cables.
Severe ambient light.	Swap position of SSR and SST.
Cross talk from another light curtain or photo sensor	Swap position of SSR and SST.
Cross talk from a nearby HF strip light	Swap position of SSR and SST or remove the strip light.

5. Symptom: Status and output indicators (Red and Yellow LED's) are off and output is open.	
One or more beams are blocked or the rails are out of sensing range.	Remove obstruction or reduce the distance between the rails.
The test input on SST is activated	Remove SST pin 4 (black wire) from ground.



### Warning


This device is not to be used for Personnel Protection in Machine Guarding Safety applications. This device does not include the self-checking redundant circuitry necessary to allow its use in personnel machine guarding stand-alone safety applications.

V 1.6 Part Number: 0666220723

November 2022 edition

Telco A/S reserves the right to make changes without prior notice

Dimensions and Descriptions



(Units in mm) (\* 5 mm channel spacing showed in diagram.)



**Warning**  
This device is not to be used for Personnel Protection in Machine Guarding Safety applications. This device does not include the self-checking redundant circuitry necessary to allow its use in personnel machine guarding stand-alone safety applications.

V 1.6 Part Number: 0666220723  
November 2022 edition

Telco A/S reserves the right to make changes without prior notice