

getting started with the Yocto Project and systemd

ESE3005

Yocto Project


- backed by a number of large tech corporations and individuals, in order to expedite getting embedded Linux systems working!
- hardware companies like IBM and TI have a vested interest in getting IoT hardware systems working (so they can sell their chips!)
- getting a Linux OS working for a newly designed embedded system is not a simple matter (there is no off-the-shelf distribution like Beagleboard Debian or Raspbian!)
- although there are several embedded OS “generic” operating systems available, notably: Android, Angstrom, OpenWrt;

Yocto Project Cont'd

- Yocto is not the only embedded Linux Build System:
 - Baserock
 - Buildroot
 - OpenEmbedded
- What is hard about a custom Linux distribution?
 - Bootloader
 - Kernel
 - Device Drivers
 - Life Cycle Management
 - Application Software Management



Openembedded Architecture Workflow



Yocto: fetch, extract, patch, configure, build...

- essentially, you use various configuration files and special script files called “recipes” to direct the build system in how to construct your Linux image
- the image is then “flashed” on your embedded system
 - in this unit, we’ll be emulating the embedded system, so you won’t have to worry about flashing a physical device!
- the Yocto’s BitBake program then runs, based on the configuration files and recipes goes through a repetitive process involving the same steps:
 - fetch (from many different sources on the Internet)
 - extract (un-zipping, un-archiving)
 - patch (updating the source code)
 - configure (configuring the build)
 - build (compiling, linking)
 - install (placing the program in the right directories, etc.)
 - package (creating the archive or image)

systemd

- originally developed by Lennart Poettering and Kay Sievers, two software engineers working at RedHat
- a software suite consisting of various system components
 - some components work as a “glue” between applications and the kernel
 - the *system and service manager*
- the predecessor to the systemd startup and service manager is System V init (sometimes called “SysV”)
 - drawback of SysV is the slow boot process:
 - SysV waits for one task to complete, before starting the next
 - whereas systemd starts up services in parallel, this was one of systemd’s primary initial aims

systemd cont'd

- What are services? Examples include:
 - webservers (Apache server)
 - ssh (secure shell), interfacing kernel and /bin/bash
 - uart communication management
 - low-level hardware control (graphics, sound, etc.)
- core components:
 - *systemd*: the start-up and service manager itself
 - *systemctl*: a command used to probe *systemd*
 - *systemd-analyze*: system state information, including boot-up performance
 - other components also provide login management, journal logging, device management, and more
- systemd has been criticized for taking on too many functions, diverting from its original mission; nevertheless, this has not slowed its widespread adoption by various Linux distributions

typing the *systemctl* command at the Linux prompt yields:

takis@Bernard: ~					
UNIT	LOAD	ACTIVE	SUB	DESCRIPTION	
proc-sys-fs-binfmt_misc.automount	loaded	active	waiting	Arbitrary Executable File Formats File System Automount Pol...	
dev-fuse.device	loaded	activating	tentative	/dev/fuse	
sys-bus-pci-drivers-nvidia.device	loaded	active	plugged	/sys/bus/pci/drivers/nvidia	
sys-devices-pci0000:00-0000:00:01.3-0000:03:00.0-usb1-1\x2d3-1.0-sound-card1.device	loaded	active	plugged	Audio Adapter (Unitex Y-247A)	
sys-devices-pci0000:00-0000:00:01.3-0000:03:00.0-usb1-1\x2d4-1.2-sound-card3.device	loaded	active	plugged	HD Pro Webcam C920	
sys-devices-pci0000:00-0000:00:01.3-0000:03:00.1-ata1-host0-target0:0:0:0:0-block-sda-sda1.device	loaded	active	plugged	WDC_WD1003FZEX-00MK2A0 1	
sys-devices-pci0000:00-0000:00:01.3-0000:03:00.1-ata1-host0-target0:0:0:0:0-block-sda-sda2.device	loaded	active	plugged	WDC_WD1003FZEX-00MK2A0 2	
sys-devices-pci0000:00-0000:00:01.3-0000:03:00.1-ata1-host0-target0:0:0:0:0-block-sda-sda5.device	loaded	active	plugged	WDC_WD1003FZEX-00MK2A0 5	
sys-devices-pci0000:00-0000:00:01.3-0000:03:00.1-ata1-host0-target0:0:0:0:0-block-sda-sda6.device	loaded	active	plugged	WDC_WD1003FZEX-00MK2A0 6	
sys-devices-pci0000:00-0000:00:01.3-0000:03:00.1-ata1-host0-target0:0:0:0:0-block-sda-sda7.device	loaded	active	plugged	WDC_WD1003FZEX-00MK2A0 7	
sys-devices-pci0000:00-0000:00:01.3-0000:03:00.1-ata1-host0-target0:0:0:0:0-block-sda.device	loaded	active	plugged	WDC_WD1003FZEX-00MK2A0	
sys-devices-pci0000:00-0000:00:01.3-0000:03:00.1-ata2-host1-target1:0:0:1:0:0-block-sdb-sdb1.device	loaded	active	plugged	INTEL_SSD5C2BP240G4 1	
sys-devices-pci0000:00-0000:00:01.3-0000:03:00.1-ata2-host1-target1:0:0:1:0:0-block-sdb-sdb2.device	loaded	active	plugged	INTEL_SSD5C2BP240G4 2	
sys-devices-pci0000:00-0000:00:01.3-0000:03:00.1-ata2-host1-target1:0:0:1:0:0-block-sdb-sdb5.device	loaded	active	plugged	INTEL_SSD5C2BP240G4 5	
sys-devices-pci0000:00-0000:00:01.3-0000:03:00.1-ata2-host1-target1:0:0:1:0:0-block-sdb.device	loaded	active	plugged	INTEL_SSD5C2BP240G4	
sys-devices-pci0000:00-0000:00:01.3-0000:03:00.2-0000:1d:07.0-0000:25:00.0-net-emp37s0.device	loaded	active	plugged	RTL8111/8168/8411 PCI Express Gigabit Ethernet Controller (W...	
sys-devices-pci0000:00-0000:00:03.1-0000:26:00.1-sound-card0.device	loaded	active	plugged	GK106 HDMI Audio Controller	
sys-devices-pci0000:00-0000:00:08.1-0000:28:00.3-sound-card2.device	loaded	active	plugged	Family 17h (Models 00h-0fh) HD Audio Controller	
sys-devices-platform-serial8250-tty-ttyS1.device	loaded	active	plugged	/sys/devices/platform/serial8250/tty/ttyS1	
sys-devices-platform-serial8250-tty-ttyS10.device	loaded	active	plugged	/sys/devices/platform/serial8250/tty/ttyS10	
sys-devices-platform-serial8250-tty-ttyS11.device	loaded	active	plugged	/sys/devices/platform/serial8250/tty/ttyS11	
sys-devices-platform-serial8250-tty-ttyS12.device	loaded	active	plugged	/sys/devices/platform/serial8250/tty/ttyS12	
sys-devices-platform-serial8250-tty-ttyS13.device	loaded	active	plugged	/sys/devices/platform/serial8250/tty/ttyS13	
sys-devices-platform-serial8250-tty-ttyS14.device	loaded	active	plugged	/sys/devices/platform/serial8250/tty/ttyS14	
sys-devices-platform-serial8250-tty-ttyS15.device	loaded	active	plugged	/sys/devices/platform/serial8250/tty/ttyS15	
sys-devices-platform-serial8250-tty-ttyS16.device	loaded	active	plugged	/sys/devices/platform/serial8250/tty/ttyS16	
sys-devices-platform-serial8250-tty-ttyS17.device	loaded	active	plugged	/sys/devices/platform/serial8250/tty/ttyS17	
sys-devices-platform-serial8250-tty-ttyS18.device	loaded	active	plugged	/sys/devices/platform/serial8250/tty/ttyS18	
sys-devices-platform-serial8250-tty-ttyS19.device	loaded	active	plugged	/sys/devices/platform/serial8250/tty/ttyS19	
sys-devices-platform-serial8250-tty-ttyS2.device	loaded	active	plugged	/sys/devices/platform/serial8250/tty/ttyS2	
sys-devices-platform-serial8250-tty-ttyS20.device	loaded	active	plugged	/sys/devices/platform/serial8250/tty/ttyS20	
sys-devices-platform-serial8250-tty-ttyS21.device	loaded	active	plugged	/sys/devices/platform/serial8250/tty/ttyS21	
sys-devices-platform-serial8250-tty-ttyS22.device	loaded	active	plugged	/sys/devices/platform/serial8250/tty/ttyS22	
sys-devices-platform-serial8250-tty-ttyS23.device	loaded	active	plugged	/sys/devices/platform/serial8250/tty/ttyS23	
sys-devices-platform-serial8250-tty-ttyS24.device	loaded	active	plugged	/sys/devices/platform/serial8250/tty/ttyS24	
sys-devices-platform-serial8250-tty-ttyS25.device	loaded	active	plugged	/sys/devices/platform/serial8250/tty/ttyS25	
sys-devices-platform-serial8250-tty-ttyS26.device	loaded	active	plugged	/sys/devices/platform/serial8250/tty/ttyS26	
sys-devices-platform-serial8250-tty-ttyS27.device	loaded	active	plugged	/sys/devices/platform/serial8250/tty/ttyS27	
sys-devices-platform-serial8250-tty-ttyS28.device	loaded	active	plugged	/sys/devices/platform/serial8250/tty/ttyS28	
sys-devices-platform-serial8250-tty-ttyS29.device	loaded	active	plugged	/sys/devices/platform/serial8250/tty/ttyS29	
sys-devices-platform-serial8250-tty-ttyS3.device	loaded	active	plugged	/sys/devices/platform/serial8250/tty/ttyS3	
sys-devices-platform-serial8250-tty-ttyS30.device	loaded	active	plugged	/sys/devices/platform/serial8250/tty/ttyS30	
sys-devices-platform-serial8250-tty-ttyS31.device	loaded	active	plugged	/sys/devices/platform/serial8250/tty/ttyS31	
sys-devices-platform-serial8250-tty-ttyS4.device	loaded	active	plugged	/sys/devices/platform/serial8250/tty/ttyS4	
sys-devices-platform-serial8250-tty-ttyS5.device	loaded	active	plugged	/sys/devices/platform/serial8250/tty/ttyS5	
sys-devices-platform-serial8250-tty-ttyS6.device	loaded	active	plugged	/sys/devices/platform/serial8250/tty/ttyS6	
sys-devices-platform-serial8250-tty-ttyS7.device	loaded	active	plugged	/sys/devices/platform/serial8250/tty/ttyS7	
sys-devices-platform-serial8250-tty-ttyS8.device	loaded	active	plugged	/sys/devices/platform/serial8250/tty/ttyS8	
sys-devices-platform-serial8250-tty-ttyS9.device	loaded	active	plugged	/sys/devices/platform/serial8250/tty/ttyS9	
sys-devices-virtual-block-loop0.device	loaded	active	plugged	/sys/devices/virtual/block/loop0	
sys-devices-virtual-block-loop1.device	loaded	active	plugged	/sys/devices/virtual/block/loop1	
sys-devices-virtual-block-loop10.device	loaded	active	plugged	/sys/devices/virtual/block/loop10	
sys-devices-virtual-block-loop11.device	loaded	active	plugged	/sys/devices/virtual/block/loop11	
sys-devices-virtual-block-loop12.device	loaded	active	plugged	/sys/devices/virtual/block/loop12	
sys-devices-virtual-block-loop13.device	loaded	active	plugged	/sys/devices/virtual/block/loop13	
sys-devices-virtual-block-loop14.device	loaded	active	plugged	/sys/devices/virtual/block/loop14	
sys-devices-virtual-block-loop2.device	loaded	active	plugged	/sys/devices/virtual/block/loop2	
sys-devices-virtual-block-loop3.device	loaded	active	plugged	/sys/devices/virtual/block/loop3	
sys-devices-virtual-block-loop4.device	loaded	active	plugged	/sys/devices/virtual/block/loop4	
sys-devices-virtual-block-loop5.device	loaded	active	plugged	/sys/devices/virtual/block/loop5	
sys-devices-virtual-block-loop6.device	loaded	active	plugged	/sys/devices/virtual/block/loop6	

lines 1-63