

Global Variables Initialization

```
LCDInitializationState= LCD_NOT_INITIALIZED;  
LCDWriteState= LCD_FREE;  
LCDDData= 0;  
LCDDDataOrCMD= LCD_CMD_WRITE;  
LCDBitMode= DATA_PINS_4 or DATA_PINS_8  
according to selected configuration;  
LCDEnControlPinState= LOW_STATE;  
LCDStartEnControlPinHighStateTimeInMS= 0
```

API Name: LCD_init
API Scope: Global

