



CBUS Steady state Node 12V supply version

Note 1 For 5V output, Fit R9 and omit VR1
For adjustable output Omit R9 and fit VR1