



The upper edge of the base must be 0,3m
above the alignment level.

A = Alignment level

Alignment level of height data is the placement level of the crane.
Erection / take down is done on this level.
If necessary, establish this level by supporting the boom from below.

SL4DFBW/B

Statically checked:	Administrator	Date	Name
	Department		
Comment:			

04.11.2009 SAR

LWE_CAD

1:150

**ASSEMBLY SL4D
NARROW TRACK**

1666-720.00.03.016-000
9880 940 08