



The upper edge of the base must be on the alignment level.

A = Alignment level

Alignment level of height data is the placement level of the crane.  
Erection / take down is done on this level.  
If necessary, establish this level by supporting the boom from below.

SL4DFBW/B

|                     |               |      |      |
|---------------------|---------------|------|------|
| Statically checked: | Administrator | Date | Name |
|                     | Department    |      |      |
| Comment:            |               |      |      |

10.02.2009 SAR

LWE\_CAD

1:150

ASSEMBLY SL4D

1666-720.00.03.009-000

9874 914 08