



Alignment level of height data is the placement level of the crane.  
Erection / take down is done on this level.  
If necessary, establish this level by supporting the boom from below.

The upper edge of the support must be  
for SL2-120-132m 1.5m and for SL2-138 2.2m  
above the alignment level.

|                     |                    |      |      |
|---------------------|--------------------|------|------|
| Statically checked: | Administrator      | Date | Name |
|                     | Department manager |      |      |
|                     | Comment:           |      |      |

LWE\_CAD

04.11.2009 SAR

ASSEMBLY SL2D  
NARROW TRACK

1666-720.00.03.015-001  
9880 939 08

A = Alignment level