



Alignment level of height data is the placement level of the crane.
Erection / take down is done on this level.
If necessary, establish this level by supporting the boom from below.

A = Alignment level

Static		Date	Name
Inspected:	Administrator		Krank
	Department manager		
Comment:	Change 001, Detail X, Support he changed from 2m to 0.3m.		

LWE_CAD

30.10.2008 SAR

A0

— 1:150

SLD-ASSEMBLY

1666-720.00.03.007-001

9873 042 08