



<

[illegible]





<div>LR1600-2</div> <div>917928508 / 98014259</div>		<div>We reserve all rights in this document and in the information contained therein. Reproduction, use or disclosure to third parties without express authority is strictly forbidden.</div> <div>© LIEBHERR WERK EHINGEN</div>		<div>Für dieses Dokument und den darin dargestellten Gegenstand behalten wir uns alle Rechte vor. Vervielfältigung, Bekanntgabe an Dritte oder Verwertung seines Inhaltes sind ohne unsere ausdrückliche Zustimmung verboten.</div> <div>© LIEBHERR WERK EHINGEN</div>		<div><div>E3</div><div>series</div></div>		1		2		3		4		5		6		7		8	
								EIS		DESCRIPTION FUSE		VALUE		COLOR		EIS		DESCRIPTION FUSE		VALUE		COLOR	
								-F837		LIGHTING CAMERA		7,5A		BN		-F865		ENGINE OIL LEVEL / TEMPERATURE		5A		LBN	
		-F838		READING LAMP		5A		LBN				-F865		HUMIDITY SENSOR(MEAS)		5A		LBN					
		-F839		FUEL PREHEATING (FUELPREFILTER)		10A		RD				-F866		AdBlue-TANK CONTENTS: LEVEL / QUALITY/ TEMPERATURE		5A		LBN					
		-F840		FUEL PREHEATING (FUELPREFILTER)		15A		LBU				-F866		NOx SENSOR DOWN		5A		LBN					
		-F841		ACTUATING DRIVE WORKING PROJECTOR		5A		LB				-F866		NOx SENSOR UP		5A		LBN					
		-F842		HYDRAULIC OIL PREHEATING		5A		LBN				-F867		LSB 1		3A		VT					
		-F843		POWER PACK E/A-MODULE 6		10A		RD				-F868		LSB 2		3A		VT					
		-F843		OUTLETS E/A-MODULE 6		10A		RD				-F869		LSB 3		3A		VT					
		-F843		ENGINE STOP		10A		RD				-F870		LSB 4		3A		VT					
		-F844		FMS - INTERFACE TELEMETRY		5A		LBN				-F871		LSB 5		3A		VT					
		-F845		BATTERY O.K.		7,5A		BN				-F872		LSB 6		3A		VT					
		-F846		SENSOR CRAWLER		5A		LB				-F872		LSB 6 BALLAST TRAILER		3A		VT					
		-F847		AIR CONDITIONING SYSTEM		7,5A		BN				-F873		OUTLETS CENTRAL UNIT 0 GROUP 0		7,5A		BN					
		-F848		DEAD MAN		7,5A		BN				-F874		OUTLETS CENTRAL UNIT 1 GROUP 0		7,5A		BN					
		-F848		MASTER SWITCH 1 - 3		7,5A		BN				-F875		OUTLETS CENTRAL UNIT 2 GROUP 0		7,5A		BN					
		-F849		LSB - OUTLETS A0-A14		15A		LBU				-F876		OUTLETS CENTRAL UNIT 3 GROUP 0		7,5A		BN					
		-F850		CHARGE CONTROL BKE		7,5A		BN				-F877		OUTLETS CENTRAL UNIT 4 GROUP 0		7,5A		BN					
		-F850		CONTROL STAGE LSB-BKE IGNITION ON		7,5A		BN				-F878		OUTLETS CENTRAL UNIT 5 GROUP 0		7,5A		BN					
		-F851		BULB EMERGENCY-STOP ENGINE		10A		RD				-F879		MONITOR 0		7,5A		BN					
		-F851		ENGINE CONTROL UNIT DIAGNOSIS		10A		RD				-F879		ACKNOWLEDGEMENT CONTROL ON		7,5A		BN					
		-F852		CAMERA MONITOR CONTROL BOX		10A		RD				-F879		POWER PACK		7,5A		BN					
		-F852		CAMERA MONITOR MONITOR 1/2		10A		RD				-F879		MONITOR 1		7,5A		BN					
		-F853		INSTRUMENT LIGHTING		7,5A		BN				-F880		MONITOR 2 (BSE)		10A		RD					
		-F854		TTY-TORQUE CONVERTER		5A		LB				-F881		EMERGENCY OPERATION		7,5A		BN					
		-F854		MOUSE		5A		LB				-F881		BRIDGING LMB EMERGENCY OPERATION		7,5A		BN					
		-F855		WINDSCREEN WIPER ACKNOWLEDGEMENT FRONT/ROOF		7,5A		BN				-F882		WINCHES 1 - 6		10A		RD					
		-F856		IGNITION ON LSB - SENSOR		15A		LBU				-F883		CONTROL STAND LEFT		10A		RD					
		-F857				?A						-F883		CONTROL STAND RIGHT		10A		RD					
		-F858		SEAT SPRINGING		7,5A		BN				-F884		SLEWING GEAR		10A		RD					
		-F858		SEAT HEATING		7,5A		BN				-F884		SUPERSTRUCTURE ± 5° IN TRAVELLING DIRECTION		10A		RD					
		-F859		HEATING AdBlue CIRCUITS		10A		RD				-F885		PRESSURE SUPPLY AUXILIARY CONSUMERS		10A		RD					
		-F860		HEATING AdBlue CIRCUITS		10A		RD				-F885		SAFETY RETAINER RAMS		10A		RD					
		-F861		VALVES EXHAUST FINISHING TREATMENT SCR		7,5A		BN				-F885		CHANGE OVER CRAWLER - WINCH		10A		RD					
		-F862		SUPPLY DIESEL ENGINE SENSORS + EXHAUST FLAP		20A		YE				-F886		CRAWLER OVERDRIVE		10A		RD					
		-F863		EXHAUST FLAP I (EXF1) (SCR)		7,5A		BN				-F886		ACOUSTIC WARNING DRIVING		10A		RD					
		-F864		EGR-FLAP I (EGR1) (3A-Derivat)		7,5A		BN				-F886		CRAWLER BRAKE		10A		RD					
		</																					

[illegible]