



Alignment level of height data is the placement level of the crane.
Erection / take down is done on this level.
If necessary, establish this level by supporting the boom from below.

Static		Date	Name
	Administrator		Kranke
Inspected:	Department manager		
Comment:	Change 001, Detail X, Support height changed from 2m to 0.3m.		

LWE_CAD

30.10.2008	SAR
------------	-----

A0

1666-720.00.03.007-001

9873 042 08

A = Alignment leve