



The upper edge of the support must be  
for SL2-120-132m = 1.5m and for SL2-138 = 2.2m  
above the alignment level.

Alignment level of height data is the placement level of the crane.  
Erection / take down is done on this level.  
If necessary, establish this level by supporting the boom from below.

Statically checked:	Administrator	Date	Name
	Department		
	Manager		
Comment:			

ASSEMBLY SL2D  
NARROW TRACK

1666-720.00.03.015-001  
9880 939 08

A = Alignment level