



The upper edge of the base must be on the alignment level.

A = Alignment level

Alignment level of height data is the placement level of the crane.  
Erection / take down is done on this level.  
If necessary, establish this level by supporting the boom from below.

SL4DFBW/B

Statically checked:	Administrator	Date	Name
	Department		
	Manager		
Comment:			

1:150

ASSEMBLY SL4D

LWE\_CAD

10.02.2009 | SAR

1666-720.00.03.009-000

9874 914 08