



Alignment level of height data is the placement level of the crane.
Erection / take down is done on this level.
If necessary, establish this level by supporting the boom from below.

A = Alignment level

The upper edge of the base must be the same as the alignment level.

Statically checked:	Administrator	Date	Name
	Department manager		
Comment:			

LWE_CAD			
30.10.2008	SAR		
1:150		ASSEMBLY SL2D	
		1666-720.00.03.008-001	
		9873 043 08	