



The upper edge of the base must be on the alignment level.
A = Alignment level

Alignment level of height data is the placement level of the crane.
Erection / take down is done on this level.
If necessary, establish this level by supporting the boom from below.

SL4DFBW/B

Statically checked:	Administrator	Date	Name
	Department		
	Manager		
Comment:			

1:150

ASSEMBLY SL4D

LWE_CAD

10.02.2009 SAR

1666-720.00.03.009-000

9874 914 08