



* LED Status

	Steady	Blinking 1S
Green LED	Charge Done	Charging Board Error or not Exist
Orange LED	Normal Charging	Charging Error (Temp high, Batt SMB lost, Battery in Protective mode, Battery Cell Fail)

** Protection

When battery have below scenario will let the charge LED blinking and also not allow to charge the battery.

- Battery temperature over 50 degree C will not be charging.
- When SMBus doesn't communicate, still will use 500mA to charge battery for 5 minutes and retry to access battery again.
If after 15 minutes (3 cycles) still can't access the battery then will stop to charge battery.
- Battery already charge / discharge protect.
- Battery single cell fail then not allow to charge the battery.