



TO "WAKE UP" MAXX™: <STOP> ON MAXX'S HEAD
CONTROLLER ON/IMMEDIATE MODE:
<POWER/STOP> TWICE. CONTROLLER WILL SHUT
OFF 20-60 SEC. AFTER LAST KEYSTROKE.
CONTROLLER REACTIVATE: <POWER/STOP> ONCE
TO PUT MAXX TO "SLEEP":
<STATUS> TWICE, <6>

STATUS OPTIONS: <STATUS> TWICE
SERIAL/PARALLEL: <0>
AUTO POWER DOWN ON/OFF: <1>
EDIT MODE ON/OFF: <2>
WRIST/ARM COUPLING ON/OFF: <3>
EXEC. BACKWARDS ON/OFF: <4>
VERBAL PROMPTS ON/OFF: <5>
©1984 CBS Toys, A Division of CBS Inc.
Newark NJ 07105

VERIFIED TO CONFORM TO PART
95 OF F.C.C. REGULATIONS.
FREQ. 27.095 MHZ
MFD. IN TAIWAN R.O.C.

USE WITH AVERY 6794 OR EQUIVALENT
PRINT AT 100% SCALE