



Ultimate Lightsaber 2.0 Instruction Manual



Questions, problems, missing parts?
Contact Customer Service:
Phone: +1 (424) 235-1594
Email: theforce@sabermasters.com
<https://www.sabermasters.com/>

Safety Instructions

Please read the entire manual before using this product. Keep this manual for future reference.

1. Do not use this product near water.
2. Do not overuse this product, put it under heavy pressure, or expose it to high temperatures.
3. This product should only be operated by the type of power source indicated on the marking label.
4. Protect the power adaptor from being walked on or pinched while charging, particularly at plugs, convenience receptacles, and the point where it connects to the product.
5. Do not overload wall outlets, extension cords, or integral convenience receptacles, as this can result in a risk of fire or electric shock.
6. Never push objects of any kind into this product through openings, as they may touch dangerous voltage points that could result in a fire or electric shock. Never spill liquid of any kind on this product.
7. Do not attempt to service this product yourself, as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.
8. Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the product.
9. Do not use attachments not recommended by the product manufacturer, as they may cause hazards.

Product Description



- 1. Saber Grip Tape
- 2. Saber End Cap
- 3. Saber Blade Emitter

- 4. Hexagon Socket Screw
- 5. Function Button
- 6. Charging Jack

Items in this Package

Before throwing away any packaging materials, please make sure you find the following items that come along with this package:

- Saber Hilt
- Saber Blade
- Saber Grip Tape
- Four Hexagon Socket Screws
- Allen Wrench
- Power Adaptor

Please contact SaberMaster Customer Service if any items are missing from the package. Retain the original packing materials for exchange or return purposes.

Initial Setup

Setup Instructions

1. Fit the **Saber Blade** into the **Saber Blade Emitter**.
2. Using the **Allen Wrench**, screw in two **Hexagon Socket Screws** into the right and left sides of the **Saber Blade Emitter** to hold the **Saber Blade** in place.
3. Remove the clear backing from the **Saber Grip Tape**, and wrap the sticky side of the **Saber Grip Tape** around the **Saber Hilt** as desired for comfort and grip.

SaberStaff Setup Instructions

If you purchase two sabers, you can connect them to create a **SaberStaff**. To connect the sabers, follow these instructions:

1. Unscrew the **Saber End Cap** from the first saber.
2. Screw the end of the first saber into the **Saber End Cap** of the second saber.

Charging Instructions

- Insert the **Power Adaptor** into the **Charging Jack**.
- To indicate low battery, the saber will beep continuously when activated.
- The saber needs to be plugged in for 2-3 hours to reach full charge. While charging, the **Function Button** will glow. To indicate a full battery, the glow will stop.

Lightsaber Operation

Lightsaber Activation and Deactivation

Activation: Quickly tap the **Function Button** until the blade vibrates once.

Deactivation: Hold the **Function Button** until the blade flashes three times, and release.

Lightsaber Effects Overview

- **Blaster Deflection Effect:** Your saber can replicate a blaster deflection sound. Activate the saber, and then tap the **Function Button**. *Note: Every tap will also activate one of six light pulsation modes.*
- **Saber Lock-up-Loop:** Activate the saber. Hold the **Function Button** until the blade flashes once, and then release. Immediately tap the button again. The effect will continue until deactivated. To deactivate the effect, tap the button once.
- **Color Change:** Activate the saber. Hold down the **Function Button** until the blade flashes two times, and then release. Immediately press the button again and hold. The lightsaber will cycle through all 11 colors: red, orange, yellow, dark green, light blue, dark blue, lilac, light green, white, purple, pink. To select a color, release the button.
- **Sound Volume:** To change the volume, first activate the saber. Hold down the **Function Button** until the blade flashes three times, and then release. Immediately press the button again and hold. The volume level will start changing. When the desired level is reached, release the button.
- **Sound Fonts:** Your saber has three unique sound fonts. To select one, first deactivate your saber. While it is off, press and hold the **Function Button** until the blade flashes once, and then release. Activate the saber. The interface will let you know which font you have selected.
- **Mute Mode:** Deactivate your saber. Hold down the **Function Button** until the blade flashes two times, and then release. Activate your saber. Repeat these steps to unmute.

Troubleshooting

Saber is beeping loudly when activated - your saber is low on battery. Charge your saber for 2-3 hours, or until the Function Button stops glowing.

Saber isn't making any sound - your saber may be muted. Deactivate your saber. Hold down the Function Button until the blade flashes two times, and then release. Activate your saber.

Saber blade is falling out of the hilt - Check that both hexagon screws are inserted in the blade emitter. If not, two replacement screws are provided in your packaging materials. Tighten the hexagon screws on the side of your blade emitter using the allen wrench.