

**elektroda.pl**<https://www.elektroda.pl/rtvforum/forums.html>Forum (<https://www.elektroda.pl/rtvforum/forums.html>)**20050.pdf**

## Sterownik silnika monochromatora - uszkodzona przetwornica flyback

W trakcie kompletowania stanowiska pomiarowego napotkałem na problem ze sterownikiem silnika monochromatora. Jest to urządzenie sterowane przez RS232 lub GPIB i nazywa się Oriel 20050. W instrukcji są schematy poszczególnych modułów, w tym zasilacza (w załączniku, na końcu dokumentu). Proszę o pomoc na forum, bo z przetwornicami flyback nie mam żadnego doświadczenia. [http://obrazki.elektroda.pl/1176806700\\_1474971813\\_thumb.jpg](http://obrazki.elektroda.pl/1176806700_1474971813_thumb.jpg) Na mostku jest napięcie powyżej 300V, na wyprowadzeniach scalaka UC3840N są napięcia ponad 100V, jednak nie ma żadnych objawów w postaci palenia się elementów, rozgrzewa się z czasem jedynie transformator. Zasilacz ma napięcia wyjściowe -15V, +15V, +5V oraz +24V niestabilizowane. Na tym ostatnim wyjściu napięcie waha się mniej więcej w zakresie 5V-14V z częstotliwością około 1Hz. Na pozostałych wyjściach stabilizowanych brak napięcia (nie są zwarte). Wymieniłem w ciemno scalak UC3840N, ale niestety objawy są wciąż te same. W zasadzie chciałbym prosić o sugestie czy to raczej wina transformatora (zamiennik jest nieosiągalny), czy próbować wymiany innych elementów w układzie zasilacza (tranzystory i diody sprawdziłem i nie mają zwarc). Ostatecznie jeśli winowajcą okaże się transformator, planuję wstawienie swojego zasilacza i chciałbym też właśnie zapytać czy musi to być układ typu flyback, czy może można go śmiało zastąpić zwykłym zasilaczem transformatorowym.

M-20050

ORIEL PRODUCT LINE  
150 Long Beach Boulevard  
Stratford, CT 06615  
Phone: (203) 377-8282  
(800) 714-5393  
Fax:

(203) 378-2457  
**elektroda.pl**  
info@elektroda.pl  
(<https://www.elektroda.pl>)  
/r/monochromator  
MONOCHROMATOR DRIVER  
MODEL 20050

Forum (<https://www.elektroda.pl/rtvforum/forums.html>)

## USER MANUAL

Please read these instructions completely before operating this equipment. The specification and operating instructions apply only to the model(s) covered by this manual. If there are any questions or problems regarding the use of this equipment, please contact Newport or the representative from whom this equipment was purchased.  
Rev: 02/21/97

M-20050

## TABLE OF CONTENTS

I.	
INTRODUCTION.....	1
II.	
SPECIFICATIONS .....	2
III.	
SET UP & OPERATION.....	3
IV.	
DESCRIPTION OF COMMANDS .....	10
V.	
COMMAND SUMMARY.....	12
VI.	
SPECIAL MESSAGES.....	13
VII.	
REPORTING COMMANDS .....	14
VIII.	

OPERATIONAL EXAMPLES .....	15
<b>elektroda.pl</b>	Forum ( <a href="https://www.elektroda.pl/rtvforum/forums.html">https://www.elektroda.pl/rtvforum/forums.html</a> )
( <a href="https://www.elektroda.pl/rtvforum/forums.html">https://www.elektroda.pl/rtvforum/forums.html</a> )	
CIRCUIT DESCRIPTION .....	18
X.	
INTERFACE.....	19
XI.	
PROGRAMMING .....	30
1. RS-232 PROGRAMMING WITH THE 20050 .....	30
1.1 Interface Setup .....	30
1.2 Writing a QBasic Program to Communicate with the 20050.....	30
1.3 Tips for Success in Writing More Advanced RS-232 Programs .....	31
1.4 BASIC Language RS-232 Motion Control Example.....	31
1.5 BASIC Language RS-232 Wavelength Calibration Example.....	34
2. IEEE-488 PROGRAMMING WITH THE 20050.....	37
2.1 Interface Setup .....	37
2.2 Addressing the 20050 .....	37
2.3 Communicating with the 20050 Using IEEE-488 .....	37
2.4 Configuring Your IEEE-488 Interface Board .....	37
2.5 Writing a Quick BASIC Program to Communicate with the 20050 .....	38
2.6 Tips for IEEE-488 Success with Your 20050 .....	39
2.7 C Language IEEE-488 Travel Command Example .....	39
XII.	
SCHEMATICS.....	42
XIII.	
WARRANTY AND RETURNS .....	47

M-20050

MONOCHROMATOR DRIVER

I.

## INTRODUCTION

The Oriel Model 20050 Monochromator Driver can drive 118 meter and 114 meter monochromators. The 20050 Monochromator Driver may be controlled by a computer equipped with RS-232 or IEEE-488 interface. A more detailed description of the interface between the monochromator driver and the control interface is outlined in Section V.

The rear panel contains the connectors for the power connections, the stepper motor connection, and the

interface connectors. The main power switch is located on the front panel.

**elektroda.pl**

Forum (<https://www.elektroda.pl/rtvforum/forums.html>)

(<https://www.elektroda.pl/rtvforum/forums.html>)

M-20050

MONOCHROMATOR DRIVER

II.

## SPECIFICATIONS

a) Power:

95 - 275 Volts AC; 50/60 Hz ; 75 Watts - Universal input

b) Motor Drive:

All Oriel monochromators - 4 phase step, power controlled

c) RS-232 - Interface

Half or Full duplex 110, 150,300, 600, 1200,2400,4800,9600 baud 8 bit 1S,NP

d) IEEE-488 - Interface

Addressable talker or listener. Address range 0 - 31

2

M-20050

MONOCHROMATOR DRIVER

III.

## SET UP & OPERATION

Figure 1: 20050 Rear Panel

### Description of Switches & Connectors:

1. Power Input:

Power line in and fuse holder.

2. I/O Connector:

15 pin subminiature 'D' connector (female) for the user TTL interface.

The connector pin-out is provided in this section.

3. RS-232 Connector:

9 pin subminiature 'D' connector (female) for RS-232 110. The

connector pin-out is provided in this section.

4. Motor Connector:

10 pin IDC connector (male). The connector pin-out is provided in

this section.

**elektroda.pl**

(<https://www.elektroda.pl/rtvforum/forums.html>)

Forum (<https://www.elektroda.pl/rtvforum/forums.html>)

Standard 24 pin IEEE-488 connector.

## 6. Configuration Switches:

A combination of 10 switch positions that sets the I10 address or baud rate depending on the type of interface selected.

3

M-20050

MONOCHROMATOR DRIVER

1.

### Power connector

This is the power input connector. The internal power supply is capable of operating over a wide range of input voltage. The fuse for the 20050 controller is located at this power connector. Be aware of potentially hazardous voltages present at this connector when changing fuses and always replace with the properly rated fuse.

2.

### I/O Connector

#### 20050 I/O-Connector Pin Assignment

DB-15 Pins

Function

I/O Type

1

RESERVED

2

RESERVED

3

RESERVED

4  
**elektroda.pl**  
RESERVED  
(<https://www.elektroda.pl/rtvforum/forums.html>)

Forum (<https://www.elektroda.pl/rtvforum/forums.html>)

5  
RESERVED

6  
RESERVED

7  
Power (+5 volts) 100mA

8  
Not Connected

9  
A Motor Half/Full

Input

10  
A Motor Enable/Disable

Input

11  
A motor Fwd. Limit

Output

12  
A Motor Rev. Limit

Output

13  
A Motor Step Pulse

Input  
**elektroda.pl**

(<https://www.elektroda.pl/rtvforum/forums.html>)

Forum (<https://www.elektroda.pl/rtvforum/forums.html>)

A Motor Forward/Reverse

15

Logic Ground

Logic 0 = &lt; 1.6 Volts

Logic 1 = > 2.7 Volts

4

Power

Input  
Ground

M-20050  
MONOCHROMATOR DRIVER

3.

RS-232 Connector

The RS-232 serial I/O connector is located on the rear panel. This connector is a 9 pin subminiature "D" connector.

Cable wiring scheme of RS-232 Connector

To computer: 9 pin female connector

Pin Connections Used on 20050: 9 pin male connector

Pin Connections Used on 20050:

Pin

Function

1

Ground

2

Transmitted Data (Tx)

3

Received Data (Rx)  
**elektroda.pl**  
(<https://www.elektroda.pl/rtvforum/forums.html>)  
Request to Send (RTS)

Forum (<https://www.elektroda.pl/rtvforum/forums.html>)

5

Clear to Send (CTS)

Power Adjustment

An adjustment is provided on the rear panel for motor power control. This control is located in the center of the rear panel, above the TTL interface connector. Normally this adjustment is set at the factory and requires no further adjustment.

To make the power adjustment, the monochromator must be moving continuously. If the monochromator appears to be missing steps, the power must be increased. To reduce noise, turn this control counterclockwise. When reducing power always test for missing steps. Missing steps should be checked by moving the monochromator between two wavelengths at the highest anticipated speed.

5

M-20050  
MONOCHROMATOR DRIVER

4.

Monochromator Connection

The monochromator connection is made at the rear panel through a single rectangular 10 pin connector. Connection to the monochromator is made through a flat 10-conductor ribbon cable. This cable is supplied with the monochromator being utilized (118 meter or 114 meter monochromator). The following is a pin-out of the connector on the rear of the Model 20050 Monochromator Driver for reference and connection. If you want to make your own cable DO NOT use a cable length of more than 2m.

Pin

Function

1

+5 volts; 50 mA maximum

2

Rev. Limit - logic low = limit

3



Forwd. Limit - logic low = limit

**elektroda.pl**

(<https://www.elektroda.pl/rtvforum/forums.html>)

Motor power return

5

Phase A

6

Phase B

7

Phase C

8

Phase D

9

Power select

10

Logic Common (Digital Gnd)

6

M-20050

MONOCHROMATOR DRIVER

5.

IEEE-488 Connector

Contact

Signal Line

Contact

Signal Line

1

Forum (<https://www.elektroda.pl/rtvforum/forums.html>)

**elektroda.pl**

(<https://www.elektroda.pl/rtvforum/forums.html>)

Forum (<https://www.elektroda.pl/rtvforum/forums.html>)

DIO 5

2

DIO 2

14

DIO 6

3

DIO 3

15

DIO 7

4

DIO 4

16

DIO 8

5

EIO

17

REN

6

DAV

18

Gnd

7

**elektroda.pl**

(<https://www.elektroda.pl/rtvforum/forums.html>)

Forum (<https://www.elektroda.pl/rtvforum/forums.html>)

Gnd

8

NDAC

20

Gnd

9

IFC

21

Gnd

10

SQR

22

Gnd

11

ATN

23

Gnd

12

Shield

24

Gnd LOGIC

7

**elektroda.pl**

MONOCHROMATOR DRIVER  
(<https://www.elektroda.pl/rtvforum/forums.html>)

Forum (<https://www.elektroda.pl/rtvforum/forums.html>)

6.

Configuration Switch

INTERFACE SETUP

Configuration switch is set for 9600 baud, computer mode

S8 UP

S1

S2

S3

S4

S5

S6

S7

Function

Half Duplex

UP

UP

UP

UP

\*

\*

\*

110 Baud Computer Mode

DOWN

UP  
**elektroda.pl**  
(<https://www.elektroda.pl/rtvforum/forums.html>)  
UP

Forum (<https://www.elektroda.pl/rtvforum/forums.html>)

\*

\*

\*

150 Baud Computer Mode

UP

DOWN

UP

UP

\*

\*

\*

300 Baud Computer Mode

DOWN

DOWN

UP

UP

\*

\*

\*

600 Baud Computer Mode

UP

UP  
**elektroda.pl**  
DOWN  
(<https://www.elektroda.pl/rtvforum/forums.html>)

Forum (<https://www.elektroda.pl/rtvforum/forums.html>)

UP

\*

\*

\*

1200 Baud Computer Mode

DOWN

UP

DOWN

UP

\*

\*

\*

2400 Baud Computer Mode

UP

DOWN

DOWN

UP

\*

\*

\*

4800 Baud Computer Mode

DOWN

DOWN  
**elektroda.pl**  
DOWN  
(<https://www.elektroda.pl/rtvforum/forums.html>)  
UP

Forum (<https://www.elektroda.pl/rtvforum/forums.html>)

\*

\*

\*

9600 Baud Computer Mode  
Full Duplex

UP

UP

UP

DOWN

\*

\*

\*

110 Baud Terminal Mode

DOWN

UP

UP

DOWN

\*

\*

\*

150 Baud Terminal Mode

UP

**elektroda.pl**

(<https://www.elektroda.pl/rtvforum/forums.html>)

Forum (<https://www.elektroda.pl/rtvforum/forums.html>)

DOWN

\*

\*

\*

300 Baud Terminal Mode

DOWN

DOWN

UP

DOWN

\*

\*

\*

600 Baud Terminal Mode

UP

UP

DOWN

DOWN

\*

\*

\*

1200 Baud Terminal Mode

DOWN



**elektroda.pl**

(<https://www.elektroda.pl>  
[/rtvforum/forums.html](https://www.elektroda.pl/rtvforum/forums.html))

Forum (<https://www.elektroda.pl/rtvforum/forums.html>)

DOWN

\*

\*

\*

2400 Baud Terminal Mode

UP

DOWN

DOWN

DOWN

\*

\*

\*

4800 Baud Terminal Mode

DOWN

DOWN

DOWN

DOWN

\*

\*

\*

9600 Baud Terminal Mode

\* = Don't care

**elektroda.pl**

(<https://www.elektroda.pl>  
[/rtvforum/forums.html](https://www.elektroda.pl/rtvforum/forums.html))

Forum (<https://www.elektroda.pl/rtvforum/forums.html>)

20050  
MONOCHROMATOR DRIVER

S8 DOWN

S1

UP

DOWN

UP

DOWN

UP

DOWN

UP

DOWN

UP

DOWN

UP

DOWN

UP

DOWN

UP

DOWN

UP

DOWN

UP

DOWN

UP

DOWN

UP

DOWN

DOWN

UP

DOWN

UP

DOWN

UP

DOWN

UP

S2

UP

UP

DOWN

DOWN

UP

UP

DOWN  
**elektroda.pl**  
UP  
(<https://www.elektroda.pl/rtvforum/forums.html>)

Forum (<https://www.elektroda.pl/rtvforum/forums.html>)

DOWN  
DOWN  
UP  
UP  
DOWN  
DOWN  
UP  
UP  
DOWN  
DOWN  
UP  
UP  
DOWN  
DOWN  
DOWN  
UP  
UP  
DOWN  
UP  
UP  
DOWN  
DOWN

S3  
UP  
UP  
UP  
UP  
DOWN  
DOWN  
DOWN  
DOWN  
UP  
UP  
UP  
UP  
DOWN  
DOWN  
DOWN  
DOWN  
DOWN  
UP  
UP  
UP

UP  
**elektroda.pl**  
DOWN  
(<https://www.elektroda.pl>  
/rtvforum/forums.html)

Forum (<https://www.elektroda.pl/rtvforum/forums.html>)

DOWN  
DOWN  
UP  
UP  
UP  
DOWN  
DOWN  
DOWN  
DOWN

S4  
UP  
UP  
UP  
UP  
UP  
UP  
UP  
UP  
DOWN  
DOWN  
DOWN  
DOWN  
DOWN  
DOWN  
DOWN  
DOWN  
UP  
UP  
UP  
UP  
UP  
UP  
UP  
UP  
DOWN  
DOWN  
DOWN  
DOWN  
DOWN  
DOWN  
DOWN

S5

UP  
**elektroda.pl**  
UP  
(<https://www.elektroda.pl/rtvforum/forums.html>)

Forum (<https://www.elektroda.pl/rtvforum/forums.html>)

UP

UP

UP

UP

UP

UP

UP

UP

UP

UP

UP

UP

DOWN

DOWN

DOWN

DOWN

DOWN

DOWN

DOWN

DOWN

DOWN

DOWN

DOWN

DOWN

DOWN

DOWN

DOWN

DOWN

\* = Don't care

9

S6

\*

\*

\*

\*

\*

\*

\*

\*

\*

\*

Forum (<https://www.elektroda.pl/rtvforum/forums.html>)

S7

\*  
**elektroda.pl**  
(<https://www.elektroda.pl/rtvforum/forums.html>)  
\*

Forum (<https://www.elektroda.pl/rtvforum/forums.html>)

Function

GPIO Address 0-Reserved

GPIO Address 1

GPIO Address 2

GPIO Address 3

GPIO Address 4

GPIO Address 5

GPIO Address 6

GPIO Address 7

GPIO Address 8

GPIO Address 9

GPIO Address 10

GPIO Address 11

GPIO Address 12

GPIO Address 13

GPIO Address 14

GPIO Address 15

GPIO Address 16

GPIO Address 17

GPIO Address 18

GPIO Address 19

GPIO Address 20

GPIO Address 21

GPIO Address 22

GPIO Address 23

GPIO Address 24

GPIO Address 25

GPIO Address 26

GPIO Address 27

GPIO Address 28

GPIO Address 29

GPIO Address 30

GPIO Address 31-listen only

M-20050

MONOCHROMATOR DRIVER

IV.

## DESCRIPTION OF COMMANDS

**elektroda.pl**Forum (<https://www.elektroda.pl/rtvforum/forums.html>)

(<https://www.elektroda.pl/rtvforum/forums.html>) This section provides a description of the commands for the Model 20050 accepts. The typed command is shown. The output data, if any, is delimited by the word response in italics. The outputs for both the debug/terminal mode and the computer mode are shown. Special operations, such as line feed, space and carriage return are shown in parenthesis: (LF),(SP), and (CR) respectively. Control key operations are shown in brackets[ ], where the control button is depressed and held and then a character key is pressed.

## Clear Absolute Register - C

Purpose: To clear the absolute register to zero.

Format:

C response - C.

## Disable Motor Windings - D

Purpose:

To disable the monochromator driver so no current flows through the motor windings.

Format:

D response - D

## Enable Command - E

Purpose: Enables the monochromator driver. This command allows the motor to step normally.

Format:

E response - E

## Inquire Command - I

Purpose: The I command displays the status of the drive motor to the terminal.

Format:

I response - (CR), (LF) A or B (sp) +I- Direction (CR), (LF) A or B (sp) Full or Half Step  
(CR), (LF) A or B (sp) Disable Or Enable Axis (CR), (LF)

## Jump Command - J

Purpose:

The J command provides an index mode of operation. This command works in conjunction with the T command. The T command sets the number of index steps.

Format:

J response - J motion is initiated when the S command is issued.

## Move Command - M

Purpose:

The M command provides continuous motion until a limit is reached or another M command is issued. Note: This command is available in Terminal/Debug only.

Format:

M response - M

## Query Command - Q

Purpose: The Q instruction displays the status of the Monochromator to the terminal.

Format:

Q response (CR), (LF) A Motor On or Off (CR), (LF) A (sp) No or - Limit (CR), (LF) A (sp)  
No or - Limit (CR), (LF)

## Start Command - S

Purpose: To start the selected axis.

Format: S response - S

## Travel Command - T



**elektroda.pl**  
 Purpose: This command includes a data field consisting of up to 8 decimal digits of data terminated by a comma. If after the 8th digit, the numeric field is automatically terminated. A back space may also be used to edit the data field.  
 Format: <https://www.elektroda.pl/rtvforum/forums.html>

+ Tdddd, or + T0000dddd, or + Tdddddddd, or - Tddd, or - T0000dddd, or - Tdddddddd

Where:

d = numeric data up to 8 digits.

10

M-20050

MONOCHROMATOR DRIVER

U Command - U

Purpose: Entering a U instructs the controller to output the value of the monochromator travel register.

Format:

U response (CR), (LF) ddddddd (CR), (LF)

Where:

d = numeric data up to 8 digits

Velocity Command - V

Purpose: This command includes a data field consisting of up to 4 decimal digits of data terminated by a comma. After the 4th digit, the numeric field is automatically terminated. A back space may also be used to edit the data field. On power up velocity is set to 100 steps/sec.

Format:

Vdddd, or Vdd

X Command

Purpose:

Format:

Where:

Entering an X will instruct the controller to output the value of the Monochromator absolute register.

X response (CR), (LF) + or - dddd ... (CR), (LF)

d = numeric data up to 8 digits

Zero Command - Z

Purpose: Z clears the absolute destination register. This command is the same as G + or -0.

Format:

Z response Z

@ Command

Purpose:

Format:

@ unconditionally stops both motors. This is similar to "Panic" stop @ will also clear a "Go Lockout" caused by specifying a range of travel outside of the limits.

@ response @ (CR), (LF) motor off (CR), (LF) B Motor off (CR), (LF)

## elektroda.pl

Control Panel Command - &gt;

Forum (<https://www.elektroda.pl/rtvforum/forums.html>)

Purpose: c will take a single step clockwise. This is the same as entering + T1 ,S

Format:

&gt; response &gt; (CR), (LF) A (sp) Motor Off (CR), (LF)

Less Than Command &lt;

Purpose: c will take a single step counter- clockwise. This is the same as entering - T1 ,S

Format:

&lt; response c (CR), (LF) A (sp) Motor Off (CR), (LF)

Plus Command +

Purpose: To preset the direction to clockwise.

Format:

c+ &gt; (response) +

Minus Command Purpose: To preset the direction to counter-clockwise.

Format:

- response -

Change to Debug/Terminal Mode

Purpose: To take out of computer mode without resetting the controller, this is useful for manual operation.

Format:

[Control] - W response (CR), (LF) Terminal Mode (CR), (LF)

Change to Computer Mode

Purpose: To return to computer mode without resetting the controller.

Format:

[Control] - U response \* (CR)

11

M-20050

MONOCHROMATOR DRIVER

**COMPUTER MODE** This section contains the description of the commands the 20050 accepts under the computer mode. In

most cases the input format will be the same. The major difference is in the way the output is presented to the computer. When a command is entered that returns no value, there is no echo back sent (half duplex). If a command that requires a value is sent, then that value is outputted and terminated with a carriage return and no line feed.

V.

### COMMAND SUMMARY

Group 1 - Translator Commands - This command group affects the motor driver:

Command Name

Command Character

Command Description

Disable  
**elektroda.pl**

(<https://www.elektroda.pl/rtvforum/forums.html>)

Forum (<https://www.elektroda.pl/rtvforum/forums.html>)

Disables motor winding current

Enable

E

Enables motor winding current

Plus

+

Set for clockwise operation

Minus

-

Set for counter-clockwise operation

Group 2 - Data/Status Commands - This command group outputs data:

Command Name

Command Character

Command Description

Inquire

I

Inquire about the translator status

Query

Q

Query the status of the move

U relative register

U

Number of steps in motor A relative register

**elektroda.pl**

(<https://www.elektroda.pl/rtvforum/forums.html>)

Forum (<https://www.elektroda.pl/rtvforum/forums.html>)

Absolute number of steps for motor A

Group 3 - Control Data Commands - This command group loads the motor control registers:

Command Name

Command Character

Command Description

Clear

C

Set the value in the absolute register to Zero

Jump

J

Index by number of steps set by the relative register

Travel

T

Set relative register to travel a number of steps

Velocity

V

Set step rate of motor

Group 4 - Direct Control Commands

Command Name

Command Character

Command Description

Move continuous

M

**elektroda.pl**<https://www.elektroda.pl/rtvforum/forums.html>Forum (<https://www.elektroda.pl/rtvforum/forums.html>)

S

Start motor

Stop Both

@

Stop both motors

12

M-20050

MONOCHROMATOR DRIVER

Group 5 - Macro Instruction Group - This command group simulates a multiple instruction:

Command Name

Command Character

Command Description

Zero

Z

Same as G 0, commands

Single step reverse

&amp;lt;

Same as - T1, S commands

Single step forward

&amp;gt;

Same as + T1, S commands

Group 6 - Special/Control Characters

Command Name

Command Character

**elektroda.pl**

Command Description  
(<https://www.elektroda.pl/rtvforum/forums.html>)

Forum (<https://www.elektroda.pl/rtvforum/forums.html>)

Used as terminator for numeric data field

Back Space

[Control - H]

Used to edit numeric data

Terminal Mode

[Control - W]

Switch to terminal mode

Computer Mode

[Control - U]

Switch to computer mode

VI.

## SPECIAL MESSAGES

### Terminal Mode Message Description

"A Motor Off"

This message is sent when the Monochromator reaches a limit or its destination count.

"Terminal Mode"

This message is sent when a [Control - W] is typed. The controller is now in the Terminal/Data mode.

Overflow

This message is sent when a destination value larger than 16,777,215 steps is requested.

### Computer Mode Message Description

"" (CR)  
**elektroda.pl**

Forum (<https://www.elektroda.pl/rtvforum/forums.html>)

(This message is displayed when a [Control - X] is typed. The controller is now in the computer mode)

"a" (CR)

Same function as a "A Motor Off"

IEEE-488 Mode has no special messages

13

M-20050  
 MONOCHROMATOR DRIVER

VII.

## REPORTING COMMANDS

The reporting commands are I,Q,U & X. The Q command and the I command are used for status reporting. The X command reports absolute steps taken, and the U command reports how many steps remain in a relative move (counts to zero).

Q Command

Terminal/Debug

Computer Mode

GPIB

A MOTOR OFF

A NO + LIMIT

A NO - LIMIT

0(cr)

Same as Computer Mode

A MOTOR ON

A NO + LIMIT

A NO - LIMIT

1(cr)

Same as Computer Mode

A MOTOR OFF

A + LIMIT

## A NO - LIMIT **elektroda.pl**

(<https://www.elektroda.pl/rtvforum/forums.html>)

Same as Computer Mode

A MOTOR ON

either A + LIMIT or A - LIMIT

3(cr)

Same as Computer Mode

A MOTOR OFF

A NO + LIMIT

A - LIMIT

4(cr)

Same as Computer Mode

Terminal/Debug

Computer Mode

GPIB

A - DIRECTION

A FULL STEP

A DISABLE

0(cr)

Same as Computer Mode

A + DIRECTION

A FULL STEP

A DISABLE

1(cr)

Same as Computer Mode

A - DIRECTION

A HALF STEP

A DISABLE

2(cr)

Forum (<https://www.elektroda.pl/rtvforum/forums.html>)



## elektroda.pl

Same as Computer Mode

(<https://www.elektroda.pl>

/rtvforum/forums.html)

A FULL STEP

A ENABLE

4(cr)

Same as Computer Mode

I Command

Command

Terminal/Debug

Computer Mode

GPIB

U Command

dddddddd

dddddddd(cr)

Same as Computer Mode

X Command

?dddddddd

?dddddddd(cr)

Same as Computer Mode

14

M-20050

MONOCHROMATOR DRIVER

VIII.

OPERATIONAL EXAMPLES

Connect an RS-232 terminal to the 20050 using the appropriate cable. Set the mode switch to terminal mode and the baud rate to the baud rate of the terminal. Turn the terminal on and press the caps lock on

Forum (<https://www.elektroda.pl/rtvforum/forums.html>)

the terminal. Push the power switch to the ON position. This message should appear after 2 seconds.  
**elektroda.pl** \*\*  
 Forum (<https://www.elektroda.pl/rtvforum/forums.html>)

(<https://www.elektroda.pl>)

/rtvforum/forums.html) Monochromator Drive Controller

V1.1 1994

Insert on

Next type Q, the message below should appear on the screen.

A MOTOR OFF

A NO + LIMIT

A NO - LIMIT

Type I and a new message should appear.

A - DIRECTION

A FULL STEP

A DISABLE

The Q and the I commands are status reporting messages, these messages are important for determining if the monochromator has stopped running and under what conditions.

Typing X will display the absolute number of steps. Upon power up this value will be zero. The range for the absolute number of steps is ?16777215 steps.

Type &lt; ; , the screen should display the following:

A MOTOR OFF

Next type X and the screen should display:

+1

Type &lt; ; , again the screen should display the following:

A MOTOR OFF

If X is typed the screen should display:

+0

The &lt; ; and &lt; ; characters are used for single step forward and single step reverse.

Type M and wait a few seconds then type M again. The screen should display;

A MOTOR OFF

Next type X , the screen should display some number of steps based on the time between typing M again. For example: The M command will cause the Monochromator to move continuously until M is typed again. The M command only functions under debuglterminal mode, this function is inhibited when computer mode or GPIB is selected.

-467

15

M-20050

MONOCHROMATOR DRIVER

Type C and then type X, the screen should display:

-0

The C command clears the absolute register of the counter to zero.

Type + T500,S and after about 3 seconds the screen should display:

A MOTOR OFF

Type X and the screen should read:

+500

The T command is a relative move command and the value after the command is the number of steps

relative to the absolute register to move. The range for the T command is 1677721 5 steps.  
 elektroda.pl Forum (https://www.elektroda.pl/rtvforum/forums.html)  
 After type T and after about 3 seconds the screen should display:  
 (https://www.elektroda.pl/rtvforum/forums.html) A MOTOR OFF  
 Type X again and the screen should read:

+1000

The J command is an index type of command that is used in conjunction with the T command, where the T command sets the value for the number of steps to index.

Type -JS and after about 3 seconds the screen should display:

A MOTOR OFF

Type X again and the screen should display:

+500

In this case the Monochromator indexed in reverse by 500 steps. The direction for an index can be set by the plus or minus character, if no direction is selected before an index move, the Monochromator will move in the last direction selected.

Type ZS and wait about 15 to 20 seconds:

A MOTOR OFF

Type X again and the screen should display:

+0

The Z command zeros the absolute register, the Monochromator will move in a direction that causes this to happen. This command along with the C command can be used for a home function.

Connect the cable between the Monochromator and the 20050 controller. Type E+I, the screen should display:

A +DIRECTION

A FULL STEP

A ENABLED

The Monochromator is now set to move in the positive direction and the motor windings are enabled.

16

M-20050

MONOCHROMATOR DRIVER

Type M and the Monochromator should begin moving in the positive direction at about 150 steps per second. Type V60, the step rate will change to 60 steps per second, next type V10, and the step rate will change to 10 steps per second. The V command changes the step rate of the Monochromator. The range for the V command is 1 to 2000 steps per second in one step per second increments. Although the range is from 1 to 2000 steps per second most Monochromators will not move correctly above 180 steps per second. Type M to stop the Monochromator.

The 20050 can be changed to computer mode operation by Typing [control]U. The screen will display:

\*

Most of the commands used in the above examples will remain the same, but the command characters will not echo back (half duplex) and status reporting will be a numeric code. GPIB mode is the same in all cases as computer mode except in the case when the Monochromator has just stopped moving. When in computer mode, if motor stepping has ended or terminated (due to limits or a stop command ) the 20050 will send the lower case character a to indicate this condition. This will not happen in GPIB mode, you must employ status checking.

COMMAND SUMMARY

(<https://www.elektroda.pl/rtvforum/forums.html>)  
 Monochromator Commands

A ..... Switch commands to motor  
 C ..... Clear absolute register  
 D ..... Disable power to the motor windings  
 E ..... Enable power to the motor windings  
 I ..... Report the status of the Monochromator  
 J ..... Repeat the Index steps  
 M ..... Move or stop moving continuously  
 Q ..... Display the status of the drive motor  
 S ..... Start  
 T ..... Set the Index register  
 U ..... Report the travel distance of motor  
 V ..... Set the selected motor step rate in steps/sec.  
 X ..... Report the absolute number of steps  
 Z ..... Go to zero absolute  
 &lt; ..... Control-W &gt; ..... Change to user mode  
 &lt; ..... Control-U &gt; ..... Change to computer mode  
 + ..... Set to cw direction  
 - ..... Set to ccw direction  
 &lt; ..... Single step CW  
 &lt; ..... Single step CCW  
 @ ..... Stop

17

M-20050  
 MONOCHROMATOR DRIVER

IX.

## CIRCUIT DESCRIPTION

Refer to Schematic 20040-3-1001

The Oriel Model 20040 Monochromator Driver consists of a single printed circuit board containing a 75watt switching power supply (flyback) and the digital motor controller circuitry. The operation of the circuit is broken down into three major components: The flyback 75-watt switching power supply, the discrete digital gates, and monochromator motor driver.

The switching supply is a flyback type circuit with automatic line/voltage detection feeding the input high voltage level through a pass FET transistor. The pulse width modulation and voltage sense is performed by a 3840 PWM regulator integrated circuit.

Refer to Schematic 20040-4-1002

The power supply section of the main PCB supplies the driver circuits with +I-15v, +5v & +24v. Digital signal levels are buffered and conditioned by U108. Limit switch signals are conditioned by Q111, Q112, C107, C108 & R145 - 150. The limit switch conditions are tested against the command direction by U106, U107, & U110. Digital step pulses will appear at U106 pin 1 if no limit conditions exist. The step pulses

are terminated to a pulse width of x by U109. U105 is a step motor driver I.C. creates the drive sequence Q107, Q108 to drive the motor windings. Power through the motor windings is controlled by Q101 & amp, (http://www.elektroda.pl/rtvforum/forums.html) Q102. The element and voltage signals are multiplied by U102 or U104, this provides a power feedback signal. The power feedback signal is compared to a ramp pedestal signal generated by CR101, CR102, U101 or CR103, CR104, U103. This ramp is reset after each motor pulse by Q105 or Q106. The pedestal voltage (power) is adjusted by the rear panel control, R152. Maximum available power is selected by (2113, CR110 or CR111).

Refer to schematic 20050-4-1 301.

The IEEURS-232 control PCB reads the switch settings on the rear panel and activates the desired

interface. The onboard micro controller converts the commands to digital signals.

18

M-20050

MONOCHROMATOR DRIVER

X.

## INTERFACE

### RS-232 INTERFACE:

RS-232 standard is chosen for computer interface because:

1. Most computers offer this interface option
2. It can work at long distances ( & gt; loom)
3. It has high noise immunity, and
4. It is supported by most computer languages.

RS-232 is an electrical standard, meaning that it is not important what format the signal is in, as long as it is the proper voltage level and can supply the proper current. For RS-232 the asserted voltage or logic high level must not be higher than +25 volts and the not asserted voltage or logic low level must now be less than -25 volts.

After the electrical conditions have been met, the speed or rate has to be considered. Information rates are measured in bits per second or baud. To relate that to information exchange rates, a terminal operating at 4800 baud can transmit or receive 480 characters per second. Standard baud rates are: 150 Baud, 300 Baud, 600 Baud, 200 Baud, 2400 Baud, 4800 Baud, and 9600 Baud.

### RS-232 Data Format

The next area to be considered is the word structure or how the information is to be transmitted. Since RS-232 formats the information serially or sequentially in the form of bits, which are either logic 1 or logic 0, a beginning tag (start bit) and ending tag (stop bit) must also be encoded. Now the information must be encoded into bits.

A common form of information encoding is called ASCII (American Standard Communication information Interchange) in which the information is encoded into words of 10 bit length (1 start bit, 7 information bits and 2 stop bits). 7 information bits can produce up to 128 different information combinations (a typical key board has about 70 - 96 characters).

### Standard Word Structure:

Start 1 2 3 4 5 6 7 Stop

Bit

Bit

(<https://www.elektroda.pl/rtvforum/forums.html>)

The last important item in the RS-232 standard is to be aware of information structure. RS-232 information is transmitted in asynchronous mode, which can be as character strings, or single characters transmitted randomly. This mode often requires a buffer to gather up randomly sent characters so that they can be properly interpreted.

Interchange circuits between data terminal equipment (DTE) and data communication equipment (DCE) fall into four general categories.

- Ground or Common Return
- Data Circuits
- Control Circuits
- Timing Circuits

Driver a) The electronic circuitry or relay contact at the transmitting end (source) of an interchange circuit, which transmits binary digital signals to a terminator via an interconnecting cable.

b) The transmitter of a binary digital signal.

19

M-20050

MONOCHROMATOR DRIVER

Terminator a) The electronic circuitry at the receiving end (sink) of an interchange circuit which receives binary digital signals from a driver via an interconnecting cable.

b) The receiver of a binary digital signal.

Signal Characteristics, General Interchange circuits transferring data signals across the interface point shall hold marking (binary ONE) or spacing (binary ZERO) conditions for the total nominal duration of each signal element.

During the transmission of data, the marking condition shall be used to denote the binary state ONE and the spacing condition shall be used to denote the binary state ZERO.

Notion

Interchangeable Voltage

Negative

Positive

Binary State

1

0

Signal Condition

Marking Spacing

Function

OFF

ON

Interchangeable Circuits

Circuit AA - Protective Ground

Direction - Not applicable

This conductor shall be electrically bonded to the machine or equipment frame. It may be further connected to external grounds as required by applicable regulations.  
 (http://www.elektroda.pl/rtvforum/forums.html)  
 Circuit AB - Signal Ground or Common Return  
 Direction - Not applicable

This conductor shall be electrically connected to the power supply ground return. It may be further connected to external grounds as required by applicable regulations.

Circuit BA - Transmitted Data

Direction - TO data communication equipment

Signals on this circuit are generated by the data terminal equipment and are transferred to the local transmitting signal converter for transmission of data to remote data terminal equipment. The data terminal equipment shall hold Circuit BA (Transmitted Data) in marking condition during intervals between characters or words, and at all times when no data are being transmitted. In all systems, the data terminal equipment shall not transmit data unless an ON condition is present on all of the following four circuits, where implemented.

1. Circuit CA (Request to Send)
2. Circuit CB (Clear to Send)
3. Circuit CC (Data Set Ready)
4. Circuit CD (Data Terminal Ready)

All data signals that are transmitted across the interface on interchange circuit BA (Transmitted Data) during the time an ON condition is maintained on all of the above four circuits, where implemented, shall be transmitted to the communication channel.

Circuit BB - Received Data

Direction - FROM data communication equipment

20

M-20050

MONOCHROMATOR DRIVER

Signals on this circuit are generated by the receiving signal converter in response to data signals received from remote data terminal equipment via the remote transmitting signal converter. Circuit BB (Received Data) shall be held in the binary ONE (Marking) condition at all times when Circuit CF (Received Line Signal Detector) is in the OFF condition.

On a half duplex channel, Circuit BB shall be held in the Binary One (Marking) condition when Circuit CA (Request to Send) is in the ON condition and for a brief interval following the ON to OFF transition of Circuit CA to allow for the completion of transmission.

Circuit CA - Request to Send

Direction - TO data communication equipment

This circuit is used to condition the local data communication equipment for data transmission and, on a half duplex channel, to control the direction of data transmission of the local data communication equipment.

On one way only channels or duplex channels, the ON condition maintains the data communication equipment in the transmit mode. The OFF condition maintains the data communication equipment in a non-transmit mode.

On a half duplex channel, the ON condition maintains the data communication equipment in the transmit mode and inhibits the receive mode. The OFF condition maintains the data communication equipment in the receive mode.

Circuit CB - Clear to Send

Direction - FROM data communication equipment  
Signals on this circuit are generated by the data communication equipment to indicate whether or not the data set is ready to transmit data.  
(<https://www.elektroda.pl/rtvforum/showthread.php?p=782593>)  
Forum (<https://www.elektroda.pl/rtvforum/forums.html>)

The ON condition together with the ON condition on interchange circuits CA, CC and, where implemented, CD, is an indication to the data terminal equipment that signals presented on Circuit BA (Transmitted Data) will be transmitted to the communication channel.  
The OFF condition is an indication to the data terminal equipment that it should not transfer data across the interface on interchange Circuit BA.

Circuit CC - Data Set Ready

Direction - FROM data communication equipment

Signals on this circuit are used to indicate the status of the local data set.

Circuit CD - Data Terminal Ready

Direction - To data communication equipment

Signals on this circuit are used to control switching of the data communication equipment to the communication channel. The ON condition prepares the data communication equipment to be connected to the communication channel and maintains the connection established by external means (e.g., manual call origination, manual answering or automatic call origination).

21

M-20050

MONOCHROMATOR DRIVER

Interchangeable Circuit

Description

Gnd

AA

AB

BA

BB

Protective Ground

Signal Ground/ Common Return

Transmitted Data

Received Data

X

X

CA

CB

CC

Request to Send

Clear to Send



Data Set Ready  
**elektroda.pl**

(<https://www.elektroda.pl/rtvforum/forums.html>)

Data

Data Terminal Ready

Control

Timing

X

X

X

X

X

X

Pin Out for 20050 DE-9 Connector

Pin Number

1

2

3

4

5

6

8

Circuit

CF

BA

BB

CD

AB

CC

CB

Description

Data Carrier Detect

Transmitted Data

Received Data

Data Terminal Ready

Signal Ground (Common Return

Data Set Ready

Clear to Send

9

Forum (<https://www.elektroda.pl/rtvforum/forums.html>)

The load impedance (R and C ) of the terminator side of an interchange circuit shall have a dc resistance (R) of not less than 3000 Ohms, measured with an applied voltage not greater than 25 volts in magnitude, nor more than 7000 Ohms, measured with an applied voltage of 3 to 25 volts in magnitude. The effective shunt capacitance (C ) of the terminator side of an interchange circuit, measured at the interface point, shall not exceed 2500 picofarads. The reactive component of the load impedance shall not be inductive. The open circuit terminator voltage (E ) shall not exceed 2 volts in magnitude.

**RS-232 Connection** On the rear panel of the 20050 is the RS-232 connector. The RS-232 connector is a 9 pin subminiature D

style connector thru all data and commands are processed.

The RS-232 interface has a pin for input (Rx) and a pin for output (Tx). These two signals and the signal common are the only signals that the 20050 processes. All other signals and control connections are ignored.

The baud rate or speed at which data is transferred is selected by the baud rate switch on the back panel of the 20050. The switch is tested during turn on, therefore if the switch position is changed during normal operation the baud rate will not change until the 20050 is restarted.

Because of the different requirements in each RS-232 installation, the interface cabling between the 20050 and the computer or terminal is the responsibility of the end user. Figure shows which connections are implemented on the 20050.

22

M-20050

MONOCHROMATOR DRIVER

When attempting to establish a communications interface, it is important to read the interface manuals for the computer or terminal to determine which control signals must be asserted for proper operation. Sometimes connecting an output to an input solves the problem. (i.e., connect RTS to CTS and DSR to DTR.)

Next, if a terminal is available, a test interface can be set up using the terminal to simulate the 20050. Usually this requires a null modem connection. If a personal computer is used as a terminal, the connection can be straight through.

**IEEE-488 INTERFACE:**

History

The IEEE standard 488 describes a "Standard Digital Interface for Programmable Instrumentation". This

standard was introduced in 1975 and has become the most popular means of interconnecting instruments and controllers in laboratory, automatic test and some industrial applications.

**Defining the GPIB**

This section presents a summary of the IEEE-488 standard that defines a bus structure known as the General Purpose Interface Bus, or GPIB. A system will be defined as a minimum of two devices, one device must be a receiver, the other may be a controller or source. The source is typically a talker and the receiver is a listener. Devices are defined as instruments with GPIB interface capability.

- Every IEEE-488 device must be capable of performing one or more of the following interface functions.
1. Listener- A device capable of receiving data over the interface when addressed. There can be up to 15 active listeners simultaneously on the bus. (<http://www.elektroda.pl/rtvforum/viewtopic.php?p=144444>)
  2. Talker- A device capable of transmitting data over the interface when addressed. There can only be one active talker on the interface at a time.
  3. Controller- A device capable of specifying the talker and listeners for information transfer.

#### Summary of the IEEE Standard

The IEEE standard applies to systems used to connect programmable and non-programmable electronic instrumentation with other instruments necessary to configure a complete system.

The GPIB transfers digital data among a number of instruments. Communications among these instruments is via signals and protocols specified by the IEEE standard. The IEEE standard allows programmable instruments produced by different manufactures to be connected to a computer using one interface, the GPIB. This simplifies system configuration and reduces hardware complexity. Any instrument that meets the IEEE standard may be connected to the GPIB without interface circuitry.

#### General GPIB Information

The GPIB connector is a 24 pin connector with hardware for fastening the mating cable connector. The cable has sixteen signal lines and eight ground lines. The total length of the cable in a system must not be longer than 20 meters and no interconnecting cable should be any longer than 2 meters.

Each data byte transferred by the interface system uses the handshake lines to exchange data between a talker and a listener. Local messages flow between device functions and interface functions.

Message coding is the process of converting remote messages to or from interface signal line values.

There are two types of messages, uniline and multiline. A uniline message is sent over a single line. A

23

M-20050

MONOCHROMATOR DRIVER

multiline message is sent over a group of lines. only one multiline message may be sent at a time.

Several uniline messages may be sent simultaneously on different lines

IEEE-488 CONNECTOR

Contact

Signal Line

Contact

Signal Line

1

DIO 1

13

DIO 5

2  
**elektroda.pl**  
(<https://www.elektroda.pl/rtvforum/forums.html>)  
14

Forum (<https://www.elektroda.pl/rtvforum/forums.html>)

DIO 6

3

DIO 3

15

DIO 7

4

DIO 4

16

DIO 8

5

EIO

17

REN

6

DAV

18

Gnd

7

NRFD

19

Gnd

8  
**elektroda.pl**  
 (http://www.elektroda.pl  
 /rtvforum/forums.html)

Forum (<https://www.elektroda.pl/rtvforum/forums.html>)

20

Gnd

9

IFC

21

Gnd

10

SQR

22

Gnd

11

ATN

23

Gnd

12

Shield

24

Gnd LOGIC

The GPIB signal lines

The GPIB has eight data lines, three handshake lines, and five bus management lines.

Data lines (DI01 - DI08)

The data lines transfer data and messages in synchronous, bidirectional, eight bit format.

Handshake lines (DAV, NRFD, NDAC)

These interface signal lines transfer the valid data on the data lines between the instruments or the controller. The hand shake lines operate in an interlocked sequence.

DAV

(<https://www.elektroda.pl>)

/rtvforum/availability) of valid data on the data bus lines

- Indicates the instrument is ready to accept data on the bus
- Indicates the instrument has accepted the data on the bus

Management lines ( ATN, IFC, SQR, REN, EOI )

The bus management group is made up of five signal lines that send certain single line bus commands and maintain an orderly flow of data across the interface.

ATN

IFC

SRQ

REN

- Specifies how data on the bus is to be interpreted. The state of the ATN line determines whether the information on the data bus is to be considered data or a command.
- Resets the bus to a quiescent state
- Indicates need for attention and requests an interrupt of the current sequence of events
- Sets up instruments on the bus for remote operation.

24

M-20050

MONOCHROMATOR DRIVER

EOI

- Indicates the end of a multiple byte data transfer, or, ATN, executes a polling sequence

## HANDSHAKE TIMING SEQUENCE

Handshake timing:

- t1 - All become ready for data. NRFD goes high with slowest device
- t2 - Source validates data. DAV goes high.
- t3 - First acceptor sets NRFD low to indicate it is not ready for a new data byte.
- t4 - NDAC goes high with slowest acceptor to indicate all have accepted the data byte.
- t5 - DAV goes high to indicate this data byte is no longer valid.
- t6 - First acceptor sets NDAC low in preparation for the next byte.
- t7 - beginning of next handshake cycle.

Data Transfer Sequence

The complete handshake sequence for one data byte is shown above. The data bus lines should be high and the NDAC line low from the previous byte transfer. If these conditions are not true, the source must wait NRFD and NDAC returns low.

GPIO Signal Levels

All of the electrical specifications for the driver and receiver are TTL compatible. The IEEE standard uses the negative logic convention. The logic is related to the signal level as follows:

(<http://www.elektroda.pl>

/rtvforum/forums.html)

1 =True & gt; =

Signal Level

2.0v High state

0.8v Low state

## COMMAND MODE

The commands serve different purposes:

1. Set the device address- This multiline command selects the devices that will talk or listen.

25

M-20050

MONOCHROMATOR DRIVER

2. Universal Command- There are seven multiline and three uniline commands. These commands cause the device to perform a specific task.

3. Addressed Commands- These commands are similar to universal commands and are all multiline. Addressed commands only affect the devices that have been previously addressed.

4. Secondary commands- Secondary commands are multiline messages that are always used with an address, universal command, or an addressed command to provide additional command codes.

Universal Commands

Multiline Command

Mnemonic

Decimal Code

Hex Code

ASCII Character

Untalk

UNT

95

5F

-

Unlisten

**elektroda.pl**

(<https://www.elektroda.pl/rtvforum/forums.html>)

Forum (<https://www.elektroda.pl/rtvforum/forums.html>)

3F

?

Device Clear

DCL

20

14

DC4

Local Lockout

LLO

17

11

XON

Serial Poll Enable

SPE

24

18

CAN

Serial Poll Disable

SPD

25

19

EM



**elektroda.pl**  
forum and image figure  
(<https://www.elektroda.pl/rtvforum/forums.html>)

Forum (<https://www.elektroda.pl/rtvforum/forums.html>)

21

15

NAK

UNT

The untalk command unaddresses the current talker. Sending an unused talk address would accomplish the same thing.

UNL

The unlisten command unaddresses all current listeners on the bus. Specific listeners cannot be unaddressed without unaddressing all listeners. This command is used to guarantee that only desired listeners are addressed.

DCL

The device clear command causes all recognizing devices to return to a pre-defined state. All recognizing devices will respond whether they are addressed or not.

LLO

The local lockout command disables a particular front panel local reset or return to local button on devices that recognize the command. All recognizing devices will respond whether they are addressed or not. REN must be set to false to re-enable the front panel button, this will also place all devices under local control.

SPE

The serial poll enable command establishes serial poll mode for all responding talker devices on the bus. When they are addressed to talk each responding device will return a single byte of status from each device. Devices which recognize this command must have talker capabilities to output the status byte.

SPD

The serial poll disable terminates serial poll mode for all responding devices, returning the devices to their normal talker state where they output device dependent data rather than status information.

26

M-20050

MONOCHROMATOR DRIVER

PPU

The parallel poll unconfigure resets all parallel devices to idle or unable to respond to a parallel poll.  
Upline Command

Interface Line Mnemonic

IEEE-488 Connector

## Interface Clear **elektroda.pl**

(<https://www.elektroda.pl/rtvforum/forums.html>)

Forum (<https://www.elektroda.pl/rtvforum/forums.html>)

Pin 9

Remote Enable

REN

Pin 17

Attention

ATN

Pin 12

IFC

The interface clear line is used only by the system controller to halt current operations on the bus. All talkers and listeners are un-addressed and the serial poll is disabled. All devices must monitor IFC at all times, in addition all devices must respond to an IFC in 100pS.

REN

The remote enable line is used only by the system controller to put listeners into the remote programming mode. When REN is asserted, all listeners capable of remote operation are placed in remote when addressed to listen. All devices capable of remote and local operation must monitor REN at all times, in addition all devices must respond to REN in 100pS.

ATN

The attention line is used to indicate whether the bus will be used for data or commands. All devices must monitor ATN at all times, in addition all devices must respond to ATN in 200nS. When ATN is "true" the interface is in command mode. In command mode all data on the bus are commands. When ATN is "false" there will be device dependent data on the bus.

Addressed Commands

Addressed Command

Mnemonic

Decimal Code

Hex Code

ASCII Character

Group Execute Trigger

GET

08  
**elektroda.pl**  
(<https://www.elektroda.pl/rtvforum/forums.html>)  
BS

Forum (<https://www.elektroda.pl/rtvforum/forums.html>)

Selected Device Clear

SDC

04

04

EOT

Go to Local

GTL

01

01

SOH

Parallel Poll Configure

PPC

05

05

ENQ

GET

The group execute trigger causes all addressed devices to initiate a preprogrammed action. This command provides a method of triggering devices simultaneously.

SDC

The selected device clear resets the device currently addressed to listen. This command results in an action similar to DCL but only for the selected device.

GTL

The Go to local command causes the device currently addressed to exit the remote state and return to local control.

PPC

The parallel poll command causes the addressed listening device to be configured to the parallel poll enable.

**elektroda.pl**

(<https://www.elektroda.pl>  
/rtvforum/forums.html)

Forum (<https://www.elektroda.pl/rtvforum/forums.html>)M-20050  
MONOCHROMATOR DRIVER

Secondary Command

Mnemonic

Decimal Code

Hex Code

ASCII Character

Parallel Poll Enable

PPE

96-111

60-6F

\-o

Parallel Poll Disable

PPD

112

70

p

PPE

The parallel poll enable secondary command configures the devices to respond to to a parallel poll.

PPD

The parallel poll disable command disables the devices, which have received the PPC, command from responding to a parallel poll.

28

M-20050

MONOCHROMATOR DRIVER

INTERFACE FUNCTIONS:

Interface functions are predefined capabilities of a device.

**elektroda.pl**

Functions that may be designed  
(<https://www.elektroda.pl/rtvforum/viewtopic.php?p=488146>)

Forum (<https://www.elektroda.pl/rtvforum/forums.html>)

Mnemonic

Description

Talker or Extended Talker

T,TE

Device is a talker

Listener or Extended Listener

L,LE

Device is a listener

Source Handshake

SH

Device can transfer a multilane message

Acceptor Handshake

AH

Device can  
messages

Remote/Local

RL

Device can be operated from the front  
panel controls or from the IEEE-488 bus1

Service Request

SR

Device can asynchronously request service  
from the controller2

Parallel Poll  
**elektroda.pl**

(<https://www.elektroda.pl/rtvforum/forums.html>)

Forum (<https://www.elektroda.pl/rtvforum/forums.html>)

Device can identify itself if it requires  
service from the controller3

Device Clear

DC

Device is initialized to a pre-defined state4

Device Trigger

DT

Controller

C

Drivers

D

receive

remote

multilane

This function permits a device to have its  
basic function initiated by the talker on the  
bus

This function permits a device to be a  
controller5

Type of electrical drivers used.

-----  
1

Some instruments will lock out the front panel to prevent manual operation.

2

The controller must periodically conduct a parallel poll to determine if a device needs service.

3

The effect of this command is device dependent and is usually described in the manual.

4

There can only be one controller in per system.

5

There can only be one controller in per system.

**elektroda.pl**

(<https://www.elektroda.pl/rtvforum/forums.html>)

M-20050

MONOCHROMATOR DRIVER

Forum (<https://www.elektroda.pl/rtvforum/forums.html>)

XI.

## PROGRAMMING

### 1. RS-232 PROGRAMMING WITH THE 20050

#### 1.1 Interface Setup

Set the configuration switches on a rear panel for 9600 baud, computer mode:

1

2

3

4

5

6

7

8

ON

ON

ON

OFF

\*

\*

\*

OFF

#### 1.2 Writing a QBasic Program to Communicate with the 20050

Every version of Microsoft's MS-DOS since v5.0 comes with QBasic. This version of the BASIC language supports high speed serial communications through your computer's COM1 or COM2 ports. elektroda.pl Forum (<https://www.elektroda.pl/rtvforum/forums.html>)  
 Here's a simple program that will plan an easy way to get up and running quickly with your 20050. (<https://www.elektroda.pl/rtvforum/forums.html>)  
 Bring up QBasic by typing:

QBASIC

at the DOS prompt

In the main editing window, enter the following short program. (The source code is supplied with the 20050 as the file \RS232\EXAMPLE1 .BAS).

Make sure to substitute the COM port actually connected to the 20050 for COM2 on the second line.

CLEAR

OPEN &quot; COM2:9600,N,8,1 &quot; FOR OUTPUT AS #1

PRINT #1, &quot; C &quot;;

PRINT #1, &quot; E &quot;;

PRINT #1, &quot; V60, &quot;;

PRINT #1, &quot; + T100,SW

SLEEP 2

PRINT #1, &quot; - T50,S &quot;;

SLEEP 2

PRINT #1, &quot; ZS &quot;;

CLOSE #1

\RS232\Example1.bas

Run the program and your 20050 should:

- o clear the absolute register to zero (make the current position zero position)
- o enable the motor driver
- o set the motor step rate to 60 steps/sec
- o travel 100 steps in positive direction
- o move 50 steps in negative direction
- o go to the zero position.

NOTE: That this program is very simple, and it does not read the 20050 response. Also, note that the current position becomes a zero position as the program starts, which might not correspond to the zero position of your monochromator.

30

M-20050

MONOCHROMATOR DRIVER

### 1.3 Tips for Success in Writing More Advanced RS-232 Programs

- o Use buffered, interrupt-driven serial communication routines to read and write from the COM port to which you have connected your 20050. This will ensure that you do not drop characters at the 9600 baud communication rate. Many development environments have such serial communication routines built-in (e.g. QBasic, Visual Basic, Labwindows, Labview). Other languages, such as Borland or Microsoft C, rely on your PC's relatively slow BIGS communications functions. In these cases, a third pa\* serial communications library will help guarantee success.
- o Use the computer mode of operation (set the switch #4 to 'OFF').
- o Remember that the 20050 accepts only upper case character strings as commands.



- o When reading responses from your 20050, remember that the length of the response may vary.  
 Use 100 character buffers.  
 Forum (<https://www.elektroda.pl/rtvforum/forums.html>)
- Tip: Remember that the step rate of the monochromators, including ORIEL'S 77250 1/8 m and 77200 1/4 m  
 /rtvforum/forums.html will not move correctly above 180 steps per second. Set the step rate to a  
 value of 180, or less.
- o Remember that a lower case 'a' comes from the 20050 if motor stepping has ended or  
 terminated. Wait for this response before issuing the next move command.

#### 1.4 BASIC Language RS-232 Motion Control Example

This QuickBASIC program was designed to demonstrate several basic features of the instrument.

The source code is supplied with the 20050 as the file \RS232\EXAMPLE2.BAS.

Since Microsoft QuickBASIC supports only two communication ports, make sure you connect the 20050 to either COM1 or COM2.

The program is fully compatible with QBASIC version 1.0 and Microsoft BASIC 7.0 Professional Development System.

```
COMMON SHARED response$
DECLARE SUB XCommand ( )
DECLARE SUB Travel ( )
DECLARE SUB SetRate ( )
DECLARE SUB Zero ( )
DECLARE SUB CCommand 0
DECLARE SUB Enable ( )
DECLARE SUB ReadResponse ( )
DECLARE SUB Initialize ( )
DECLARE SUB GetPortNumber (port$)
CONST TRUE = 1, FALSE = NOT TRUE
CLS
COLOR 1, 11
PRINT &quot;; ===== &quot;;
PRINT &quot;;
ORIEL 20050, Monochromator Driver ,,
&quot;;
PRINT &quot;;
QuickBASIC Demonstration Program I#
&quot;;
&quot;;
PRINT &quot;;
&quot;;
PRINT &quot;;
(R) Copyright 1997 Oriel Instruments I#
&quot;;
PRINT &quot;;
250 Long Beach Blvd., Stratford, CT 06497 I
&quot;;
PRINT &quot;;
Voice: (203) 377-8282 Fax: (203) 378-2457
PRINT &quot;; ===== &quot;;
COLOR 9, 8
```

**elektroda.pl**

(<https://www.elektroda.pl>  
/rtvforum/forums.html)

Forum (<https://www.elektroda.pl/rtvforum/forums.html>)

## MONOCHROMATOR DRIVER

```
PRINT "INITIALIZE THE INSTRUMENT";
CALL Initialize
CALL Enable
CALL Xcommand
DO
PRINT
PRINT "QUIT"; , , 0
PRINT "GET CURRENT STEP"; , 1
PRINT "MOVE RELATIVE"; , , 2
PRINT "SET RATE"; , , 3
PRINT "GO TO ZERO POSITION"; , 4
PRINT "CLEAR COMMAND"; , , 5
INPUT " "; ; I%
SELECT CASE I%
CASE 0
SYSTEM
CASE 1
CALL XCommand
CASE 2
CALL Travel
CASE 3
CALL SetRate
CASE 4
CALL Zero
CASE 5
CALL CCommand
CASE ELSE
PRINT "Select 0, 1, 2, 3, 4 or 5. ";
END SELECT
LOOP
SUB CCommand
PRINT #I, "C ";
END SUB
SUB Enable
PRINT #1, "EN ";
END SUB
SUB GetPortNumber (port$)
DO
answer% = TRUE
PRINT "Enter comm port: 1 = COM1, 2 = COM2, or 0 to quit";
INPUT " "; ; 1%
SELECT CASE 1%
```

# CASE 0 elektroda.pl

Forum (<https://www.elektroda.pl/rtvforum/forums.html>)

(<https://www.elektroda.pl>)

/rtvforum/forums.html

CASE 2

port\$ = &quot; COM2: &quot;;

CASE ELSE

PRINT &quot; Select 0, 1, or 2. &quot;;

PRINT

answer% = FALSE

END SELECT

LOOP UNTIL answer% = TRUE

END SUB

SUB Initialize

32

M-20050

MONOCHROMATOR DRIVER

CALL GetPortNumber(port\$)

port.config\$ = port\$ + &quot;; 9600,N,8,1 &quot;;

OPEN port.config\$ FOR RANDOM AS #1

END SUB

SUB ReadResponse

responses = &quot;; &quot;;

DO

valid% = 0

IF NOT EOF (1) THEN

s\$ = INPUT\$((1), #1)

IF s\$ = CHR\$ ( &amp; HD) THEN

valid% = valid% + 1

ELSE

responses = responses + s\$

END IF

END IF

LOOP UNTIL valid% = 1

END SUB

SUB SetRate

PRINT &quot; Enter the rate: &quot;;

INPUT &quot;; &quot;; rate%

PRINT #1, &quot; V &quot;; + STR\$ (rate%) + &quot;; , &quot;;

END SUB

SUB Travel

PRINT "Enter step position:"

INPUT ""; st%

IF SGN(st%) = -1 THEN

PRINT #1, "-T" = STR\$(ABS(st%))+ ",S"

Forum (<https://www.elektroda.pl/rtvforum/forums.html>)

M-20050  
MONOCHROMATOR DRIVER

CONST LINES = 1200

CONST DRIVERATIO = 1  
**elektroda.pl**

Forum (<https://www.elektroda.pl/rtvforum/forums.html>)

(<https://www.elektroda.pl/rtvforum/forums.html>)  
 PRINT

PRINT &quot; ----- &quot;

PRINT &quot;

ORIEL 20050, Monochromator Driver

&quot;

PRINT &quot;

QuickBASIC Demonstration Program

&quot;

PRINT &quot;

PRINT &quot;

(R) Copyright 1997 Oriel Instruments

&quot;

PRINT &quot;

250 Long Beach Blvd., Stratford, CT 06497

&quot;

PRINT &quot;

Voice: (203) 377-8282 Fax: (203) 378-2457

PRINT &quot; ----- &quot;

PRINT

COLOR 9, 8

PRINT &quot; INITIALIZE THE INSTRUMENT &quot;

CALL Initialize

CALL XCommand

PRINT &quot; The current step position is &quot; ; currentstep%

DO

PRINT

PRINT &quot; QUIT &quot; , , 0

PRINT &quot; TRAVEL TO STEP &quot; , 1

PRINT &quot; GET CURRENT STEP &quot; , 2

34

&quot;

&quot;

M-20050

MONOCHROMATOR DRIVER

PRINT &quot; TRAVEL TO WAVELENGTH &quot; , 3

PRINT &quot; GET CURRENT WAVELENGTH &quot; , 4

PRINT &quot; CALIBRATE &quot; , , 5

INPUT &quot; &quot; ; 1%

SELECT CASE 1%

CASE 0

SYSTEM

CASE 1  
**elektroda.pl**  
 PRINT &quot; Enter step position: &quot;;  
 INPUT ' &quot;; ; wl#  
 CALL TravelToWL  
 CALL GetWL  
 PRINT &quot; The current wavelength is &quot;; ; wl#; &quot; nm &quot;;  
 CASE 2  
 CALL XCommand  
 PRINT &quot; The current step position is &quot;; ; currentstep%  
 CASE 3  
 PRINT &quot; Enter wavelength: &quot;;  
 INPUT &quot;; &quot;; ; wl#  
 CALL TravelToWL  
 CASE 4  
 CALL GetWL  
 PRINT &quot; The current wavelength is &quot;; ; wl#; &quot; nm &quot;;  
 CASE 5  
 PRINT &quot; Enter calib wavelength: &quot;;  
 INPUT ' &quot;; ; wl#  
 CALL Calibrate  
 CASE ELSE  
 PRINT &quot; Select 0, 1, 2, 3, 4, or 5. &quot;;  
 END SELECT  
 LOOP  
 SUB Calibrate  
 calstep% = wl# / ((-1 / DRIVERATIO) \* (1200 / LINES))  
 CALL XCommand  
 offset% = calstep% - currentstep%  
 END SUB  
 SUB GetPortNumber (port\$)  
 DO  
 answer% = TRUE  
 PRINT &quot; Enter corn port: 1 = COM1, 2 = COM2, or 0 to quit  
 INPUT &quot;; &quot;; ; l%  
 SELECT CASE l%  
 CASE 0  
 END  
 CASE 1  
 port \$ = &quot;; COM1: l'  
 CASE 2  
 port\$ = &quot;; COM2 : &quot;;  
 CASE ELSE  
 PRINT &quot; Select 0, 1, or 2. &quot;;  
 PRINT  
 answer% = FALSE  
 END SELECT  
 LOOP UNTIL answer% = TRUE  
 END SUB  
 SUB GetWL  
 CALL XComrnand

Forum (<https://www.elektroda.pl/rtvforum/forums.html>)

$wl\# = (.l / DRIVERATIO) * (1200 / LINES) * currentstep\%$

**elektroda.pl**

Forum (<https://www.elektroda.pl/rtvforum/forums.html>)

(<https://www.elektroda.pl/rtvforum/forums.html>)

M-20050

MONOCHROMATOR DRIVER

SUB Travel

currentstep% = currentstep% - offset%

IF SGN(currentstep%) = -1 THEN

PRINT #1, &quot; - T &quot; + STR\$(ABS(currentstep%)) + &quot; ,S &quot;;

ELSE

PRINT #1, &quot; + T &quot; + STR\$(currentstep%) + &quot; ,S &quot;;

END IF

CALL ReadResponse

END SUB

SUB TravelToWL

currentstep% = wl# / ((.l / DRIVERATIO) \* (1200 / LINES))

CALL Travel

END SUB

SUB Initialize

CALL GetPortNumber(port\$)

port.config\$ = port\$ + &quot; 9600,N18,1 &quot;;

OPEN port.config\$ FOR RANDOM AS #1

PRINT #1, &quot; En &quot;;

' Enable the motor driver

PRINT #1, &quot; V80, &quot;; ' Set the rate to 80 steps per second

END SUB

SUB ReadResponse

responses = &quot; &quot;;

DO

valid% = 0

IF NOT EOF (1) THEN

S\$ = INPUT\$((^), #1)

IF s\$ = CHR\$ ( &amp; HD) THEN

valid% = valid% + 1

ELSE

Response\$ = response\$ + s\$

END IF

END IF

LOOP UNTIL valid% = 1

END SUB

SUB XCommand

PRINT #1, &quot; X &quot;;

CALL ReadResponse

currentstep% = VAL(response\$)

currentstep% = currentstep% + offset%

END SUB  
**elektroda.pl**  
 (https://www.elektroda.pl  
 /rtvforum/forums.html)

Forum (<https://www.elektroda.pl/rtvforum/forums.html>)

M-20050  
 MONOCHROMATOR DRIVER

## 2. IEEE-488 programming with the 20050

### 2.1 Interface Setup

Set the configuration switches on the rear panel for GPIB mode. (Switch #8 - 'ON').

### 2.2 Addressing the 20050

Use of the IEEE-488 interface requires that it has a communication address. Set the primary address by using the configuration DIP switches 1 through 5.

### 2.3 Communicating with the 20050 Using IEEE-488

The information in this section was written with National Instruments IEEE-488 interface boards and NI-488 software drivers in mind. Refer to the manuals that came with your particular board and software for exact details on how to setup and configure your system.

### 2.4 Configuring Your IEEE-488 Interface Board

National Instruments supplies a configuration program called IBCONF that you can use to configure your interface board and the devices connected to it. Bring up the configuration program by typing:  
 IBCONF

at the DOS prompt

The GPIB Device Map is displayed on a screen. Press F3 key (Autoconfig) to start scanning for devices.

The IBCONF will detect a GPIB device for each 20050 connected to your interface board. Let us assume that the DEVA corresponds to your 20050. Configure DEVA using the following table.

Parameter

Primary GPIB Address

Secondary GPIB Address

Timeout setting

Serial Poll Timeout

Terminate Read on EOS

Set EOI with EOS on Writes

Type of Compare on EOS

EOS Byte

Send EOI at End of Write

Enable Repeat Addressing

Setting

1-30

NONE

10 sec

1 sec



Yes  
**elektroda.pl**

(<https://www.elektroda.pl/rtvforum/forums.html>)

Forum (<https://www.elektroda.pl/rtvforum/forums.html>)

No  
 No

Press F9 key to return to the GPIB Devices Map and save the settings to the disk.

A short routine helps you check the IEEE-488 communications from the DOS command line:

Bring up the IEEE-488 Interface Bus Interactive Control Program by typing

IBIC

37

M-20050

MONOCHROMATOR DRIVER

at the DOS prompt.

Type

IBFIND DEVA

at the : prompt.

Type

IBWRT &quot; E &quot;;

at the DEVA: prompt. This should enable the motor driver.

Type

IBWRT &quot; + T150,S &quot;;

at the DEVA: prompt. This should drive the monochromator by 150 steps.

Type

Q

at the DEVA: prompt to exit the program, or send any other command to your 20050 following the pattern shown above.

## 2.5 Writing a Quick BASIC Program to Communicate with the 20050

Bring up QBasic by typing:

QBASIC

at the DOS prompt

In the main editing window, enter the following short program. Make sure to substitute the name of the GPIB device corresponding to the 20050 for DEVA on the first line. The source code is supplied with the 20050 as the file \IEEE488\EXAMPLE4.BAS.

CLEAR

OPEN &quot; DEVA &quot;; FOR OUTPUT AS #1

PRINT #1, &quot; C &quot;;

PRINT #1, &quot; E &quot;;

PRINT #1, &quot; V60,'

PRINT #1, &quot; + T100,SW

SLEEP 2

PRINT #1, &quot; - T50,SW

SLEEP 2

PRINT #1, &quot; ZS &quot;  
**elektroda.pl**

Forum (<https://www.elektroda.pl/rtvforum/forums.html>)

(<http://www.elektroda.pl>)

For the program and your 20050 should:

- o - clear the absolute register to zero (make the current position zero position)
- o - enable the motor driver
- o - set the motor step rate to 60 steps/sec
- o - travel 100 steps in positive direction
- o - move 50 steps in negative direction
- o - go to the zero position.

NOTE: That this program is very simple, and it does not read the 20050 response. Also, note that the current position becomes a zero position as the program starts, which might not correspond to a zero position of your monochromator.

38

M-20050

MONOCHROMATOR DRIVER

## 2.6 Tips for IEEE-488 Success with Your 20050

- o Use the GPIB of operation (set the switch #8 to 'ON').
- o Remember that the 20050 accepts only upper case character strings as commands.
- o When reading responses from your 20050, remember that the length of the response may vary. Use 120 character buffers.
- o Remember that most monochromators, including ORIEL'S 77250 118 m and 77200 114 m monochromators, will not move correctly above 180 steps per second. Set the step rate to a value of 180, or less.

## 2.7 C Language IEEE-488 Travel Command Example

This C program was designed to demonstrate the T and X commands programming for the 20050. Upon successful device configuration, the program excutes the T command with 100 positive steps followed by 50 negative steps for five consecutive times, with each execution reading the absolute number of steps. The source code is supplied with the 20050 as the files \IEEE488\EXAMPLE5.C. The low-level communication utilities are provided by the National Instruments standard DOSinstalled GPIB device driver, which comes with the National Instruments GPIB board. In order to run this program you will need a communication library, which provides an access to the driver. If you are using a National Instruments GPIB board (or 100% compatible) to communicate with the 20050, then you may use the object module, which comes with the board. For example, MCIB.OBJ module comes with NI-488.2 AT-GPIB board. Or, the GPIB-C.LIB library, which comes with the LabWindows, can be used.

39

M-20050

MONOCHROMATOR DRIVER

000

000  
**elektroda.pl**  
(<https://www.elektroda.pl/rtvforum/forums.html>)  
0011

Forum (<https://www.elektroda.pl/rtvforum/forums.html>)

16  
DLE  
10  
17

32

SOH  
01  
2  
STX  
02  
3  
ETX  
03  
4

XON  
11  
18  
DC2  
12  
19  
XOF  
13  
20

21

04  
5

0110

NAK  
15  
22  
SYN  
16  
23  
BEL

0111  
**elektroda.pl**  
(<https://www.elektroda.pl/rtvforum/forums.html>)

Forum (<https://www.elektroda.pl/rtvforum/forums.html>)

08  
9

TCT

1001

09  
10  
LF

1010

0A  
11  
VT

1011

0B  
12  
FF

1100

0C  
13  
CR

1101

0D

53

54

26  
39  
ETB

36  
55

|  
**elektroda.pl**

(<https://www.elektroda.pl/rtvforum/forums.html>)

Forum (<https://www.elektroda.pl/rtvforum/forums.html>)

CAN

18

25

28

7

8

38

41

57

)

19

26

SUB

IA

27

ESC

1B

28

FS

1C

29

GS

1D

39

42

o

2A

43

58

3A

59

+

2B

44  
**elektroda.pl**  
(<https://www.elektroda.pl/rtvforum/forums.html>)  
,

Forum (<https://www.elektroda.pl/rtvforum/forums.html>)

&lt;

3C

61

-

=

3D

k

\

{

7B

124

|

6C

109

]

5D

z

7A

123

6B

108

5C

93

M

4D

40

[

L

4C  
**elektroda.pl**  
(<https://www.elektroda.pl/rtvforum/forums.html>)  
122  
j

Forum (<https://www.elektroda.pl/rtvforum/forums.html>)

6A  
107

5B  
92

y  
79

106  
Z

K  
4B  
76

121  
i

69

5A  
91

x  
78

105

90  
J

4A  
75

3B  
60

2C  
45  
2D

74  
**elektroda.pl**  
(<https://www.elektroda.pl/rtvforum/forums.html>)

Forum (<https://www.elektroda.pl/rtvforum/forums.html>)

Y

59

w

77

120

68

89

49

g

X

I

v

76

119

67

104

58

73

9

29

W

H

48

118

f

66

103



**elektroda.pl**

(<https://www.elektroda.pl/rtvforum/forums.html>)

Forum (<https://www.elektroda.pl/rtvforum/forums.html>)

u

75

102

V

G

47

72

117

e

65

56

87

t

74

101

86

F

46

71

37

56

(

EM

70

6

d

U

55

s

73  
**elektroda.pl**  
(<https://www.elektroda.pl/rtvforum/forums.html>)

Forum (<https://www.elektroda.pl/rtvforum/forums.html>)

85

45

c

T

E

r

72

115

63

100

54

69

5

35

S

D

44

114

b

62

99

53

84

q

71

98

52  
**elektroda.pl**  
(<https://www.elektroda.pl/rtvforum/forums.html>)

Forum (<https://www.elektroda.pl/rtvforum/forums.html>)

70  
113

a

R

C

112

61

82

43

68

4

&amp;

SPD

HT

3

34

Q

B

111

\

60

97

51

42

67

33  
**elektroda.pl**  
(<https://www.elektroda.pl/rtvforum/forums.html>)

Forum (<https://www.elektroda.pl/rtvforum/forums.html>)

SPE

BS

32

51

96

50

81

66

110

P

A

2

24

17

24

GET

1000

22

35

#

23

36

80

41

50

37  
**elektroda.pl**  
(<https://www.elektroda.pl/rtvforum/forums.html>)  
PPU

Forum (<https://www.elektroda.pl/rtvforum/forums.html>)

ENQ  
05  
6  
ACK  
06  
7

I

\*

101

@  
40  
65

31

\$  
DC4

64

30  
49

34

100

0

!

14  
21

PPC

48

20  
**elektroda.pl**  
(<https://www.elektroda.pl/rtvforum/forums.html>)

Forum (<https://www.elektroda.pl/rtvforum/forums.html>)

EOT

011

SP

LLO

SDC

0100

0101

010

0

NUL

00

1

GTL

0001

001

I

7C

125

m

6D

}

7D

M-20050

MONOCHROMATOR DRIVER

41

M-20050

MONOCHROMATOR DRIVER

**elektroda.pl**

(<https://www.elektroda.pl>  
[/rtvforum/schematics.html](https://www.elektroda.pl/rtvforum/schematics.html))

Forum (<https://www.elektroda.pl/rtvforum/forums.html>)

20040-3-1 001 Universal Power Supply  
20040-4-1 002 Monochromator Wavelength Drive  
20050-4-1 301 IEEURS232 Stepper Controller  
20050-2-1 21 1 IEEEIRS232 Connector Board

42

M-20050  
MONOCHROMATOR DRIVER

43

M-20050  
MONOCHROMATOR DRIVER

44

45

46

M-20050  
MONOCHROMATOR DRIVER

XIII.

## WARRANTY AND RETURNS

Newport warrants that all goods described in this manual (except consumables such as lamps, bulbs, filters, ellipses, etc.) shall be free from defects in material and workmanship. Such defects become apparent within the following period:

This warranty shall not be extended, altered or varied except by a written document signed by both parties. If any portion of this agreement is invalidated, the remainder of the agreement shall remain in full force and effect.

All products described here, except spare parts: one (1) year or 3000 hours of operation, whichever comes first, after delivery of the goods to the buyer.

(<https://www.elektroda.pl>) responsible for consequential damages resulting from misfunctions or malfunctions of the goods described in this manual. Newport's total responsibility is limited to repairing or replacing the malfunctioning or malfunctioning goods under the terms and conditions of the above described warranty.

Spare parts: ninety (90) days after delivery of goods to the buyer.

Newport's liability under this warranty is limited to the adjustment, repair and/or replacement of the defective part(s). During the above listed warranty period, Newport shall provide all materials to accomplish the repaired adjustment, repair or replacement. Newport shall provide the labor required during the above listed warranty period to adjust, repair and/or replace the defective goods at no cost to the buyer ONLY IF the defective goods are returned, freight prepaid, to a Newport designated facility. If goods are not returned to Newport, and the user chooses to have repairs made at their premises, Newport shall provide labor for field adjustment, repair and/or replacement at prevailing rates for field service, on a portal-to-portal basis.

## INSURANCE

Persons receiving goods for demonstrations, demo loan, temporary use or in any manner in which title is not transferred from Newport, shall assume full responsibility for any and all damage while in their care, custody and control. If damage occurs, unrelated to the proper and warranted use and performance of the goods, recipient of the goods accepts full responsibility for restoring the goods to their condition upon original delivery, and for assuming all costs and charges.

Newport shall be relieved of all obligations and liability under this warranty of:

The user operates the device with any accessory, equipment or part not specifically approved or manufactured or specified by Newport unless buyer furnishes reasonable evidence that such installations were not the cause of the defect. This provision shall not apply to any accessory, equipment or part which does not affect the safe operation of the device.

## RETURNS



Before returning equipment to Newport for repair, please  
**elektroda.pl** Service Department at (203) 377-8282. Forum (<https://www.elektroda.pl/rtvforum/forums.html>)  
 (<https://www.elektroda.pl>) or by e-mail at [info@elektroda.pl](mailto:info@elektroda.pl) or by fax at [info@elektroda.pl](mailto:info@elektroda.pl)  
 (The) Customer Service Representative  
 will give you a Return Material Authorization number  
 (RMA). Having an RMA will shorten the time required for  
 repair, because it ensures that your equipment will be  
 properly processed. Write the RMA on the returned  
 equipment's box. Equipment returned without a RMA  
 may be rejected by the Newport Receiving Department.  
 Equipment returned under warranty will be returned with  
 no charge for the repair or shipping. Newport will notify  
 you of any repairs not covered by the warranty, with the  
 cost of the repair, before starting the work.

The goods are not operated or maintained in accordance  
 with Newport's instructions and specifications.

The goods have been repaired, altered or modified by  
 other than authorized Newport personnel.

Buyer does not return the defective goods, freight  
 prepaid, to a Newport facility within the applicable  
 warranty period.

Please return equipment in the original (or equivalent)  
 packaging. You will be responsible for damage incurred  
 from inadequate packaging, if the original packaging is  
 not used.

IT IS EXPRESSLY AGREED THAT THIS WARRANTY  
 SHALL REPLACE ALL WARRANTIES OF FITNESS AND  
 MERCHANTABILITY. BUYER HEREBY WAIVES ALL  
 OTHER WARRANTIES, GUARANTEES, CONDITIONS OR  
 LIABILITIES, EXPRESSED OR IMPLIED, ARISING BY  
 LAW

OR

OTHERWISE,

WHETHER

OR

NOT

OCCASIONED BY NEWPORT'S NEGLIGENCE.

Include the cables, connector caps and antistatic  
 materials sent and/or used with the equipment, so that  
 Newport can verify correct operation of these  
 accessories.

**elektroda.pl**

Forum (<https://www.elektroda.pl/rtvforum/forums.html>)

(<https://www.elektroda.pl/rtvforum/forums.html>)

Download file - link to post (<https://www.elektroda.pl/rtvforum/viewtopic.php?p=15957704#15957704>)

Administrator

(<https://www.elektroda.pl/rtvforum/contact.php>)

Moderators

(<https://www.elektroda.pl/rtvforum/staff.php>)

Forum Rules

([https://www.elektroda.pl/rtvforum/faq.php#regulamin\\_forum](https://www.elektroda.pl/rtvforum/faq.php#regulamin_forum))

General Rules

([https://www.elektroda.pl/rtvforum/faq.php#regulamin\\_ogolny](https://www.elektroda.pl/rtvforum/faq.php#regulamin_ogolny))

Privacy Policy & Cookies

(<https://www.elektroda.pl/rtvforum/faq.php#ciasteczka>)

Sitemap (<https://www.elektroda.pl/rtvforum/map.html>)

Contact

(<https://www.elektroda.pl/rtvforum/contact.php>)