

# Errors

| Error Class                | Description   | Error Code            |
|----------------------------|---|-----------------------|
| OsErrorBase                | Base class for all custom OpenSTAAD-related errors.                   | (base class, no code) |
| OsError                    | Raised for a general, unspecified OpenSTAAD error.                    | -1                    |
| OsUnableToCreateProp       | Raised when a property cannot be created in OpenSTAAD.                | 0                     |
| OsInvalidArgument          | Raised when an invalid argument is provided to an OpenSTAAD function. | -100                  |
| OsMultidimArrayExpected    | Raised when a multidimensional array is expected but not provided.    | -106                  |
| OsArrayExpected            | Raised when an array is expected but not provided.                    | -107                  |
| OsArraySizeSmall           | Raised when an array is too small for the operation.                  | -108                  |
| OsArraySizeZero            | Raised when an array of size zero is encountered.                     | -109                  |
| OsNoBeamPlateSolidSelected | Raised when no beam, plate, or solid is selected in the model.        | -110                  |
| OsDoubleExpected           | Raised when a double (float) value is expected but not provided.      | -112                  |
| OsIntegerExpected          | Raised when an integer value is expected but not provided.            | -113                  |
| OsArraySizeLessThanReqd    | Raised when an array is smaller than the required size.               | -125                  |
| OsFileAlreadyExists        | Raised when a file already exists and the operation cannot proceed.   | -1003                 |

| Error Class                  | Description   | Error Code |
|------------------------------|---|------------|
| OsNodeNotFound               | Raised when a node is not found in the model.                       | -2001      |
| OsErrorAddNode               | Raised when an error occurs while adding a node.                    | -2004      |
| OsNoNodeSelected             | Raised when no node is selected in the model.                       | -2005      |
| OsInvalidNodeNo              | Raised when an invalid node number is provided.                     | -2006      |
| OsCannotFindMember           | Raised when a member (beam) cannot be found in the model.           | 0          |
| OsBeamNotFound               | Raised when a beam is not found in the model.                       | -3001      |
| OsBeamAlreadyExists          | Raised when a beam already exists and the operation cannot proceed. | -3002      |
| OsIdenticalBeamAlreadyExists | Raised when an identical beam already exists in the model.          | -3003      |
| OsErrorAddBeam               | Raised when an error occurs while adding a beam.                    | -3004      |
| OsNoBeamSelected             | Raised when no beam is selected in the model.                       | -3005      |
| OsPlateNotFound              | Raised when a plate is not found in the model.                      | -4001      |
| OsErrorAddPlate              | Raised when an error occurs while adding a plate.                   | -4004      |
| OsNoPlateSelected            | Raised when no plate is selected in the model.                      | -4005      |

| Error Class           | Description  | Error Code |
|-----------------------|--|------------|
| OsInvalidPlateNo      | Raised when an invalid plate number is provided.               | -4006      |
| OsInvalidPlateNoFound | Raised when an invalid plate number is found in the model.     | -4008      |
| OsNoValidPlateNoFound | Raised when no valid plate number is found in the model.       | -4009      |
| OsSolidNotFound       | Raised when a solid is not found in the model.                 | -5001      |
| OsErrorAddSolid       | Raised when an error occurs while adding a solid.              | -5004      |
| OsNoSolidSelected     | Raised when no solid is selected in the model.                 | -5005      |
| OsMeshNotFound        | Raised when a mesh is not found in the model.                  | -5603      |
| OsInvalidPropRef      | Raised when an invalid property reference is provided.         | -6001      |
| OsLibErrorCreateProp  | Raised when a library error occurs while creating a property.  | -6003      |
| OsProfileNotFound     | Raised when a profile is not found in the property library.    | -6004      |
| OsProfileDataNotFound | Raised when profile data is not found in the property library. | -6005      |
| OsInvalidSectionType  | Raised when an invalid section type is provided.               | -6006      |
| OsInvalidAssignType   | Raised when an invalid assign type is provided.                | -6008      |

| Error Class            | Description  | Error Code |
|------------------------|--|------------|
| OsLibErrorBetaAssign   | Raised when a library error occurs while assigning beta.     | -6009      |
| OsNoPropAttached       | Raised when no property is attached to an element.           | -6022      |
| OsMaterialNotFound     | Raised when a material is not found in the property library. | -6023      |
| OsNoPropDefined        | Raised when no property is defined in the model.             | -6025      |
| OsUptCreateFailed      | Raised when UPT (User Provided Table) creation fails.        | -6031      |
| OsAddUptSectionFailed  | Raised when adding a UPT section fails.                      | -6032      |
| OsUptSectionExists     | Raised when a UPT section already exists.                    | -6045      |
| OsGroupAlreadyExists   | Raised when a group already exists in the model.             | -7001      |
| OsInvalidLoadDirection | Raised when an invalid load direction is provided.           | -8001      |
| OsLoadCaseNotFound     | Raised when a load case is not found in the model.           | -8002      |
| OsCreateLoadFailed     | Raised when creating a load fails.                           | -8004      |
| OsLoadExists           | Raised when a load already exists in the model.              | -8029      |
| OsSeismicCodeNotFound  | Raised when a seismic code is not found in the model.        | -8034      |
| OsInvalidLoadDefId     | Raised when an invalid load definition ID is provided.       | -8039      |

| Error Class               | Description   | Error Code |
|---------------------------|---|------------|
| OsInvalidLoadCombName     | Raised when an invalid load combination name is provided.     | -8040      |
| OsInvalidLoadCombCategory | Raised when an invalid load combination category is provided. | -8041      |
| OsBeamForcesNotLoaded     | Raised when beam forces are not loaded in the results.        | -9004      |
| OsNoGnlResultSet          | Raised when no GNL (Geometric Nonlinear) result set is found. | -9911      |
| OsMemberUpdated           | Raised when a member is updated in the model.                 | 3007       |
| OsPmemberNotFound         | Raised when a physical member is not found in the model.      | -5701      |