

# Load Items: Temperature Load

[Load](#) » [Load: Load Case Details](#) » [Load Case Details: Load Items](#)

---

## Functions

---

afx\_msg VARIANT **OSLoadUI::AddTemperatureLoad** (const VARIANT FAR &varElementNo, const VARIANT FAR &varTempAxialElong, const VARIANT FAR &varTempDiffTopAndBtm, const VARIANT FAR &varTemDiffSide)  
Adds TEMPERATURE LOAD to beam or plate elements.

---

afx\_msg VARIANT **OSLoadUI::AddStrainLoad** (const VARIANT FAR &varElementNo, const VARIANT FAR &varAxialElong)  
Adds STRAIN LOAD to beam or plate elements.

---

## Detailed Description

---

These functions are related to temperature load(s) including load generated by temperature change and by strain change.

## Function Documentation

---

### ◆ AddStrainLoad()

```
VARIANT OSLoadUI::AddStrainLoad ( const VARIANT FAR & varElementNo,
                                   const VARIANT FAR & varAxialElong )
```

Adds STRAIN LOAD to beam or plate elements.

### Parameters

[in] **varElementNo** Element number ID(s).

[in] **varAxialElong** Initial axial elongation (+)/ shrinkage (-) in member due to misfit, etc. For additional information, please refer to Section 5.32.6 of the Technical Reference manual.

### Return values

0 OK.

-1 General error.

### C++ Syntax

```
// Apply strain shrinkage of 5 units.
VARIANT RetVal = OSLoadUI::AddStrainLoad(varElementNo, -5.0);
```

### VBA Syntax

```
' Apply strain shrinkage of 5 units.
Dim RetVal As VARIANT = OSLoadUI.AddStrainLoad(varElementNo, -5.0)
```

## ◆ AddTemperatureLoad()

```
VARIANT OSLoadUI::AddTemperatureLoad ( const VARIANT FAR & varElementNo,
                                       const VARIANT FAR & varTempAxialElong,
                                       const VARIANT FAR & varTempDiffTopAndBtm,
                                       const VARIANT FAR & varTemDiffSide )
```

Adds TEMPERATURE LOAD to beam or plate elements.

### Parameters

[in] <b>varElementNo</b>	Element number ID(s) VARIANT array.
[in] <b>varTempAxialElong</b>	Change in temperature.
[in] <b>varTempDiffTopAndBtm</b>	Temperature difference from the top to the bottom of the element (for calculating bending).
[in] <b>varTemDiffSide</b>	Temperature difference from side to side of the element (local Z axis). For additional information, please refer to Section 5.32.6 of the Technical Reference manual.

### Return values

- 0 OK.
- 1 General error.

### C++ Syntax

```
// Apply uniform temperature change of 5 units.
VARIANT RetVal = OSLoadUI::AddTemperatureLoad(varElementNo, 5.0, 0.0, 0.0);
```

### VBA Syntax

```
' Apply uniform temperature change of 5 units.
Dim RetVal As VARIANT = OSLoadUI.AddTemperatureLoad(varElementNo, 5.0, 0.0, 0.0)
```

© Copyright Bentley Systems, Inc. For more information, see <http://www.bentley.com>.