

Section: Beta Angle Operation

Property

Functions

afx_msg VARIANT **OSPropertyUI::AssignBetaAngle** (const VARIANT FAR &varnBeamNo, const VARIANT FAR &varfBetaAngle)
Assign beta angle to beam(s).

afx_msg VARIANT **OSPropertyUI::GetBetaAngle** (const VARIANT FAR &varnBeamNo)
Retrieve beta angle of the specified beam member.

Detailed Description

These functions are related to Beta angle commands.

Function Documentation

◆ AssignBetaAngle()

```
VARIANT OSPropertyUI::AssignBetaAngle ( const VARIANT FAR & varnBeamNo,
                                         const VARIANT FAR & varfBetaAngle )
```

Assign beta angle to beam(s).

Parameters

[in] **varnBeamNo** The beam number ID(s) of VARIANT array.

[in] **varfBetaAngle** The beta angle in degrees.

Return values

1 OK.

0 General Error

0 1 dimensional array of long expected.

0 Library Error: Unable to assign BETA angle.

Example

```
// Assign beta angle 90.0 to beam #1, 2, 3, 4.
VARIANT RetVal = OSPropertyUI::AssignBetaAngle(varnBeamNo, varfBetaAngle );
```

VBA Syntax

```
' Assign beta angle 90.0 to beam #1, 2, 3, 4.
Sub Main
    Dim objOpenStaad As Object
    Dim stdFile As String

    Set objOpenStaad = GetObject("StaadPro.OpenSTAAD")
    objOpenStaad.GetSTAADFile stdFile, "TRUE"
    If stdFile="" Then
        MsgBox"Bad"
        Set objOpenStaad = Nothing
        Exit Sub
    End If

    Dim memb(3) As Long
    memb(0) = 1
    memb(1) = 2
    memb(2) = 3
    memb(3) = 4
    Dim betaangle As Double
    betaangle = 90
    Dim retVal As Variant
    retVal=objOpenStaad.Property.AssignBetaAngle(memb, betaangle)
    Set objOpenStaad = Nothing
End Sub
```

◆ GetBetaAngle()

VARIANT OSPropertyUI::GetBetaAngle (const VARIANT FAR & **varnBeamNo**)

Retrieve beta angle of the specified beam member.

Parameters

[in] **varnBeamNo** The beam number ID.

Return values

<Val> Beta angle.

-3001 Cannot find member **varnBeamNo**.

C++ Syntax

```
// Get all properties of beam #11.  
VARIANT BetaAngle = OSPropertyUI::GetBetaAngle(11);
```

VBA Syntax

```
' Get all properties of beam #11.  
Dim BetaAngle As VARIANT = OSPropertyUI.GetBetaAngle(11)
```

© Copyright Bentley Systems, Inc. For more information, see <http://www.bentley.com>.