

Load Items: Repeat Load

[Load](#) » [Load: Load Case Details](#) » [Load Case Details: Load Items](#)

Functions

afx_msg VARIANT	OSLoadUI::AddRepeatLoad (const VARIANT FAR &varLoadCaseList, const VARIANT FAR &varFactorList) Creates a primary load case using combinations of previously defined primary load cases.
afx_msg long	OSLoadUI::AddNotionalLoad (const VARIANT FAR &varPrimaryLoadCaseList, const VARIANT FAR &varPLFactorList, const VARIANT FAR &varPLDirectionList, const VARIANT FAR &varReferenceLoadCaseList, const VARIANT FAR &varRLFactorList, const VARIANT FAR &varRLDirectionList) Creates a Notional load case using combinations of previously defined primary load cases and Reference load cases.
afx_msg long	OSLoadUI::GetRepeatLoadCount () This function returns the number of repeat load commands in the active load case.
afx_msg long	OSLoadUI::GetNoLoadFactorInRepeatLoad (long nIndex) This function returns the number of load and factor pairs associated with a given repeat load command in the active load case.
afx_msg long	OSLoadUI::GetRepeatLoadByIndex (const long nIndex, VARIANT *iLoad, VARIANT *dFactor) This function gets the list of load case IDs and load factors for a given repeat load command in the active load case in the provided two pre-sized, zero indexed arrays. The size of the arrays should be first determined using the function OSLoadUI::GetNoLoadFactorInRepeatLoad() .
afx_msg long	OSLoadUI::GetNotionalLoadCount () Returns the number of Notional load.
afx_msg long	OSLoadUI::GetNoLoadFactorDirectionInNotionalLoad (long nIndex) Gets the no of factor for specified Notional load.
afx_msg long	OSLoadUI::GetNotionalLoadByIndex (long nIndex, VARIANT *iLoad, VARIANT *dFactor, VARIANT *iDirection) Gets load case(s), direction(s) and factor(s) for specified Notional load.
afx_msg long	OSLoadUI::AddReferenceLoad (const VARIANT FAR &varLoadCaseList, const VARIANT FAR &varFactorList) Adds a reference load item to current active load case in Load Cases Details.
afx_msg long	OSLoadUI::GetReferenceLoadCount () Returns the number of reference load case item(s) in current active load case.
afx_msg long	OSLoadUI::GetNoOfSetsInReferenceLoad (const long nIndex) Returns the number of reference load case - factor set(s) in specified reference load item.

Loading [MathJax]/extensions/MathZoom.js

afx_msg long **OSLoadUI::GetReferenceLoadByIndex** (const long nIndex, VARIANT *iLoad, VARIANT *dFactor)
 Gets reference load item: reference load case reference number ID(s) and corresponding factor(s) for specified reference load item.

afx_msg VARIANT **OSLoadUI::GetReferenceLoadType** (const VARIANT FAR &varLoadNo)
 Gets reference load Type.

afx_msg VARIANT **OSLoadUI::GetReferenceLoadCaseTitle** (const VARIANT FAR &varLoadCombNo)
 Gets reference load Type Name.

afx_msg void **OSLoadUI::BeginLoadMerging** ()
 Begin Load Merging.

afx_msg void **OSLoadUI::EndLoadMerging** ()
 End Load Merging.

Detailed Description

These functions are related to Repeat Load including Repeat Load, Reference Load, Notional Load.

Function Documentation

◆ AddNotionalLoad()

```
long OSLoadUI::AddNotionalLoad ( const VARIANT FAR & varPrimaryLoadCaseList,
                                const VARIANT FAR & varPLFactorList,
                                const VARIANT FAR & varPLDirectionList,
                                const VARIANT FAR & varReferenceLoadCaseList,
                                const VARIANT FAR & varRLFactorList,
                                const VARIANT FAR & varRLDirectionList )
```

Creates a Notional load case using combinations of previously defined primary load cases and Reference load cases.

Parameters

[in] varPrimaryLoadCaseList	(Primary) load case reference number ID(s) VARIANT array of integer [array of integer].
[in] varPLFactorList	Multiplication factor VARIANT array of Primary load cases [array of double].
[in] varPLDirectionList	Direction of Primary load cases [array of integer]. X Direction = 1 or GlobalLoadDirection.X Y Direction = 2 or GlobalLoadDirection.Y Z Direction = 3 or GlobalLoadDirection.Z
[in] varReferenceLoadCaseList	(Reference) load case reference number ID(s) VARIANT array [array of integer].
[in] varRLFactorList	Multiplication factor VARIANT array of Reference load cases [array of double].
[in] varRLDirectionList	Direction of Reference load cases [array of integer]. X Direction = 1 or GlobalLoadDirection.X Y Direction = 2 or GlobalLoadDirection.Y Z Direction = 3 or GlobalLoadDirection.Z

Return values

- 0 OK.
- 1 General error.

C++ Syntax

```
// Add a Notional load of Primary load case(s) and Reference load case(s).
VARIANT RetVal = OSLoadUI::AddNotionalLoad(varPLoadCaseArray, varPMultiplyFactors,
varPDirectionFactors,
varRLoadCaseArray, varRMultiplyFactors, varRDirectionFactors);
```

VBA Syntax

```
' Add a Notional load of Primary load case(s) and Reference load case(s).
Dim RetVal As VARIANT = OSLoadUI.AddNotionalLoad(varPLoadCaseArray, varPMultiplyFactors,
>Loading [MathJax]/extensions/MathZoom.js ctors,
```

```
varRLoadCaseArray, varRMultiplyFactors, varRDirectionFactors)
```

See also

[OSLoadUI::GetNotionalLoadCount](#)

[OSLoadUI::GetNotionalLoadByIndex](#)

[OSLoadUI::GetNoLoadFactorDirectionInNotionalLoad](#)

◆ AddReferenceLoad()

```
long OSLoadUI::AddReferenceLoad ( const VARIANT FAR & varRefLoadCaseList,
                                const VARIANT FAR & varFactorList )
```

Adds a reference load item to current active load case in Load Cases Details.

Parameters

- [in] **varRefLoadCaseList** VARIANT array of reference load case number ID(s) from Reference Load Definitions.
- [in] **varFactorList** Factor(s) VARIANT array.

Return values

- 0 OK.
- 1 General error.

C++ Syntax

```
// Add load case to active reference load.
long RetVal = OSLoadUI::AddReferenceLoad(varRefLoadCaseList, varFactorList);
```

VBA Syntax

```
' Add load case to active reference load.
Dim RetVal As long = OSLoadUI.AddReferenceLoad(varRefLoadCaseList, varFactorList)
```

See also

[OSLoadUI::GetReferenceLoadCaseCount](#)

[OSLoadUI::GetReferenceLoadCaseNumbers](#)

[OSLoadUI::CreateNewReferenceLoad](#)

[OSLoadUI::SetReferenceLoadActive](#)

[OSLoadUI::GetReferenceLoadCount](#)

[OSLoadUI::GetNoOfSetsInReferenceLoad](#)

[OSLoadUI::GetReferenceLoadByIndex](#)

◆ AddRepeatLoad()

```
VARIANT OSLoadUI::AddRepeatLoad ( const VARIANT FAR & varLoadCaseList,
                                   const VARIANT FAR & varFactorList )
```

Creates a primary load case using combinations of previously defined primary load cases.

Parameters

[in] **varLoadCaseList** (Primary) load case reference number ID(s) array (Type: Long).

[in] **varFactorList** Multiplication factor array (Type: Double).

Return values

1 If Load Case is added successfully, 0 otherwise.

C++ Syntax

```
// Add a repeat load of primary load case(s).
VARIANT RetVal = OSLoadUI::AddRepeatLoad(varLoadCaseList, varFactorList);
```

VBA Syntax

```
' Add a repeat load of primary load case(s).
Dim RetVal As VARIANT = OSLoadUI.AddRepeatLoad(varLoadCaseList, varFactorList)
```

See also

[OSLoadUI::GetRepeatLoadCount](#)

[OSLoadUI::GetNoLoadFactorInRepeatLoad](#)

[OSLoadUI::GetRepeatLoadByIndex](#)

◆ BeginLoadMerging()

```
void OSLoadUI::BeginLoadMerging ( )
```

Begin Load Merging.

C++ Syntax

```
// Begin Load Merging  
OSLoadUI::BeginLoadMerging();
```

VBA Syntax

```
' Begin Load Merging  
OSLoadUI.BeginLoadMerging()
```

◆ EndLoadMerging()

```
void OSLoadUI::EndLoadMerging ( )
```

End Load Merging.

C++ Syntax

```
// End Load Merging  
OSLoadUI::EndLoadMerging();
```

VBA Syntax

```
' End Load Merging  
OSLoadUI.EndLoadMerging()
```

◆ GetNoLoadFactorDirectionInNotionalLoad()

`long OSLoadUI::GetNoLoadFactorDirectionInNotionalLoad (long nIndex)`

Gets the no of factor for specified Notional load.

Parameters

[in] **nIndex** The index for Notional load.

Return values

<Val> The factor for specified Notional load.

-1 General error.

C++ Syntax

```
// Get the factor for Notional load #1.  
long dFactor = OSLoadUI::GetNoLoadFactorDirectionInNotionalLoad(1);
```

VBA Syntax

```
' Get the factor for Notional load #1.  
Dim dFactor As long = OSLoadUI.GetNoLoadFactorDirectionInNotionalLoad(1)
```

See also

[OSLoadUI::AddNotionalLoad](#)

[OSLoadUI::GetNotionalLoadCount](#)

[OSLoadUI::GetNotionalLoadByIndex](#)

◆ GetNoLoadFactorInRepeatLoad()

long OSLoadUI::GetNoLoadFactorInRepeatLoad (long nIndex)

This function returns the number of load and factor pairs associated with a given repeat load command in the active load case.

Parameters

[in] **nIndex** The index(One based) for repeat load.

Return values

<Val> Number of load and factor pairs associated with a given repeat load command in the active load case. To set the active load case use: - VARIANT **OSLoadUI::SetLoadActive(const VARIANT FAR & varLoadNo)**. To get the active load case use:- VARIANT **OSLoadUI::GetActiveLoad()**

-1 in case of invalid repeat load index.

C++ Syntax

```
// Get the number of load/factor pairs for repeat load #1.
long dFactor = OSLoadUI::GetNoLoadFactorInRepeatLoad(1);
```

VBA Syntax

```
' Get the number of load/factor pairs for repeat load #1.
Option Explicit
Sub Main
    Dim objOpenStaad As Object
    Dim stdFile As String
    Set objOpenStaad = GetObject("StaadPro.OpenSTAAD")
    objOpenStaad.GetSTAADFile stdFile, "TRUE"

    Dim dFactor As Long
    Dim bRes As Boolean

    bRes = objOpenStaad.Load.SetLoadActive(1)
    If bRes = True Then
        dFactor = objOpenStaad.Load.GetNoLoadFactorInRepeatLoad(1)
        If dFactor <> -1 Then MsgBox("Number of factors in repeat load: " &dFactor)
    Else
        MsgBox("Not able to set active Load Case ")
    End If
End Sub
```

See also

OSLoadUI::AddRepeatLoad

OSLoadUI::GetRepeatLoadCount

OSLoadUI::GetRepeatLoadByIndex

OSLoadUI::GetRepeatLoadByIndex()

Loading [MathJax]/extensions/MathZoom.js


```
long OSLoadUI::GetNoOfSetsInReferenceLoad ( const long nIndex )
```

Returns the number of reference load case - factor set(s) in specified reference load item.

Parameters

[in] **nIndex** The index for reference load item.

Return values

<Val> Reference load case reference ID.

-1 General error.

C++ Syntax

```
// Get the number ID of reference load case with index 2.
long nLoadNo = OSLoadUI::GetNoOfSetsInReferenceLoad(2);
```

VBA Syntax

```
' Get the number ID of reference load case with index 2.
Dim nLoadNo As long = OSLoadUI.GetNoOfSetsInReferenceLoad(2)
```

See also

[OSLoadUI::GetReferenceLoadCaseCount](#)

[OSLoadUI::GetReferenceLoadCaseNumbers](#)

[OSLoadUI::CreateNewReferenceLoad](#)

[OSLoadUI::SetReferenceLoadActive](#)

[OSLoadUI::AddReferenceLoad](#)

[OSLoadUI::GetReferenceLoadCount](#)

[OSLoadUI::GetReferenceLoadByIndex](#)

◆ GetNotionalLoadByIndex()

```
long OSLoadUI::GetNotionalLoadByIndex ( long      nIndex,
                                         VARIANT * iLoad,
                                         VARIANT * dFactor,
                                         VARIANT * iDirection )
```

Gets load case(s), direction(s) and factor(s) for specified Notional load.

Parameters

- [in] **nIndex** The index for Notional load.
- [out] **iLoad** Load case reference ID(s) in VARIANT array. +ve values = Primary Load Cases -ve values = Reference Load Cases
- [out] **dFactor** Factor(s) in VARIANT array.
- [out] **dDirection** Direction(s) in VARIANT array. 1 = X Direction 2 = Y Direction 3 = Z Direction

Return values

- <Val> The size of **iLoad** or **dFactor** or **iDirection**.
- 1 General error.

C++ Syntax

```
// Get the whole definition for Notional load #1.
long nEleNotionalLoad = OSLoadUI::GetNotionalLoadByIndex(1, &iLoad, &dFactor,
&iDirection);
```

VBA Syntax

```
' Get the whole definition for Notional load #1.
Dim nEleNotionalLoad As long = OSLoadUI.GetNotionalLoadByIndex(1, &iLoad, &dFactor,
&iDirection)
```

See also

[OSLoadUI::AddNotionalLoad](#)
[OSLoadUI::GetNotionalLoadCount](#)
[OSLoadUI::GetNoLoadFactorDirectionInNotionalLoad](#)

◆ GetNotionalLoadCount()

long OSLoadUI::GetNotionalLoadCount ()

Returns the number of Notional load.

Return values

<Val> The number of Notional load.

-1 General error.

C++ Syntax

```
// Get the number of Notional load.  
long nNotionalLoad = OSLoadUI::GetNotionalLoadCount();
```

VBA Syntax

```
' Get the number of Notional load.  
Dim nNotionalLoad As long = OSLoadUI.GetNotionalLoadCount()
```

See also

[OSLoadUI::AddNotionalLoad](#)

[OSLoadUI::GetNotionalLoadByIndex](#)

[OSLoadUI::GetNoLoadFactorDirectionInNotionalLoad](#)

◆ [GetReferenceLoadByIndex\(\)](#)

```
long OSLoadUI::GetReferenceLoadByIndex ( const long nIndex,
                                         VARIANT * iLoad,
                                         VARIANT * dFactor )
```

Gets reference load item: reference load case reference number ID(s) and corresponding factor(s) for specified reference load item.

Parameters

- [in] **nIndex** The reference load and factor set number.
- [out] **iLoad** Load case(s) reference Id(s) in VARIANT array.
- [out] **dFactor** Factor(s) in VARIANT array.

Return values

- reference** load case reference number ID(s).
- 1 General error.

C++ Syntax

```
// Get load case(s) and factor(s) in reference load with index of 2
long RetVal = OSLoadUI::GetReferenceLoadByIndex(2, &iLoad, &dFactor);
```

VBA Syntax

```
' Get load case(s) and factor(s) in reference load with index of 2
Dim RetVal As long = OSLoadUI.GetReferenceLoadByIndex(2, &iLoad, &dFactor)
```

See also

- [OSLoadUI::GetReferenceLoadCaseCount](#)
- [OSLoadUI::GetReferenceLoadCaseNumbers](#)
- [OSLoadUI::CreateNewReferenceLoad](#)
- [OSLoadUI::SetReferenceLoadActive](#)
- [OSLoadUI::AddReferenceLoad](#)
- [OSLoadUI::GetReferenceLoadCount](#)
- [OSLoadUI::GetNoOfSetsInReferenceLoad](#)

◆ GetReferenceLoadCaseTitle()

VARIANT OSLoadUI::GetReferenceLoadCaseTitle (const VARIANT FAR & varLoadNo)

Gets reference load Type Name.

Parameters

[in] **varLoadNo** The Reference Load No(Type: Integer/Long).

Return values

Reference load Title.

VBA Syntax

```
Option Explicit
Sub Main
    Dim objOpenStaad As Object
    Dim stdFile As String
    Set objOpenStaad = GetObject(,"StaadPro.OpenSTAAD")
    objOpenStaad.GetSTAADFile stdFile, "TRUE"
    If stdFile="" Then
        MsgBox"Bad"
        Set objOpenStaad = Nothing
        Exit Sub
    End If
    Dim r1Type As Integer
    r1Type = objOpenStaad.Load.GetReferenceLoadCaseTitle(1)
    MsgBox strTitle
    Set objOpenStaad = Nothing
End Sub
```

See also

[OSLoadUI::GetReferenceLoadCaseCount](#)
[OSLoadUI::GetReferenceLoadCaseNumbers](#)
[OSLoadUI::CreateNewReferenceLoad](#)
[OSLoadUI::SetReferenceLoadActive](#)
[OSLoadUI::AddReferenceLoad](#)
[OSLoadUI::GetReferenceLoadCount](#)
[OSLoadUI::GetNoOfSetsInReferenceLoad](#)
[OSLoadUI::GetReferenceLoadType](#)

◆ GetReferenceLoadCount()

long OSLoadUI::GetReferenceLoadCount ()

Returns the number of reference load case item(s) in current active load case.

Return values

<Val> The number of reference load case item(s).

-1 General error.

C++ Syntax

```
// Count the load case.  
long nRefLoadCase = OSLoadUI::GetReferenceLoadCount();
```

VBA Syntax

```
' Count the load case.  
Dim nRefLoadCase As long = OSLoadUI.GetReferenceLoadCount()
```

See also

[OSLoadUI::GetReferenceLoadCaseCount](#)

[OSLoadUI::GetReferenceLoadCaseNumbers](#)

[OSLoadUI::CreateNewReferenceLoad](#)

[OSLoadUI::SetReferenceLoadActive](#)

[OSLoadUI::AddReferenceLoad](#)

[OSLoadUI::GetNoOfSetsInReferenceLoad](#)

[OSLoadUI::GetReferenceLoadByIndex](#)

◆ GetReferenceLoadType()

VARIANT OSLoadUI::GetReferenceLoadType (const VARIANT FAR & varLoadNo)

Gets reference load Type.

Parameters

[in] **varLoadNo** The Reference Load No(Type: Integer/Long).

Return values

-1 General error.

Others (value can be 0 to 23) Reference load Type, please ref [OSLoadUI::CreateNewPrimaryLoad](#).

VBA Syntax

```
Option Explicit
Sub Main
    Dim objOpenStaad As Object
    Dim stdFile As String
    Set objOpenStaad = GetObject(, "StaadPro.OpenSTAAD")
    objOpenStaad.GetSTAADFile stdFile, "TRUE"
    If stdFile="" Then
        MsgBox "Bad"
        Set objOpenStaad = Nothing
        Exit Sub
    End If
    Dim rlType As Integer
    rlType = objOpenStaad.Load.GetReferenceLoadType(1)
    Set objOpenStaad = Nothing
End Sub
```

See also

[OSLoadUI::GetReferenceLoadCaseCount](#)
[OSLoadUI::GetReferenceLoadCaseNumbers](#)
[OSLoadUI::CreateNewReferenceLoad](#)
[OSLoadUI::SetReferenceLoadActive](#)
[OSLoadUI::AddReferenceLoad](#)
[OSLoadUI::GetReferenceLoadCount](#)
[OSLoadUI::GetNoOfSetsInReferenceLoad](#)
[OSLoadUI::GetReferenceLoadCaseTitle](#)

◆ **GetRepeatLoadByIndex()**

```
long OSLoadUI::GetRepeatLoadByIndex ( const long nIndex,
                                     VARIANT * iLoad,
                                     VARIANT * dFactor )
```

This function gets the list of load case IDs and load factors for a given repeat load command in the active load case in the provided two pre-sized, zero indexed arrays. The size of the arrays should be first determined using the function **OSLoadUI::GetNoLoadFactorInRepeatLoad()**.

Parameters

- [in] **Index** The index for repeat load(One based).
- [out] **iLoad** Load case reference ID(s) in Long array.
- [out] **dFactor** Factor(s) in Double array.

Return values

- <Val> Number of load and factor pairs associated with a given repeat load command in the active load case. To set the active load case use: - VARIANT **OSLoadUI::SetLoadActive(const VARIANT FAR & varLoadNo)**. To get the active load case use:- VARIANT **OSLoadUI::GetActiveLoad()**.
- 1 invalid repeat load index used.

C++ Syntax

```
// Get the whole definition for repeat load #1.
long nEleRepeatLoad = OSLoadUI::GetRepeatLoadByIndex(1, &iLoad, &dFactor);
```

VBA Syntax

```
Option Explicit
Sub Main
    Dim objOpenStaad As Object
    Dim stdFile As String
    Dim i As Integer
    Dim j As Integer

    Set objOpenStaad = GetObject("StaadPro.OpenSTAAD")
    objOpenStaad.GetSTAADFile stdFile, "TRUE"

    Dim iLoad() As Long
    Dim dFactor() As Double
    Dim nRetVal As Long

    objOpenStaad.Load.SetLoadActive 8
    Dim repeatLoadCount As Long
    Dim loadSize As Long

    repeatLoadCount = objOpenStaad.Load.GetRepeatLoadCount()

    For i = 1 To repeatLoadCount
        loadSize = objOpenStaad.Load.GetNoLoadFactorInRepeatLoad(i)
        ReDim iLoad(loadSize-1)
        ReDim dFactor(loadSize-1)
        nRetVal = objOpenStaad.Load.GetRepeatLoadByIndex(i, iLoad, dFactor)
```

Loading [MathJax]/extensions/MathZoom.js


```
For j = 0 To nRetVal -1
    MsgBox("Load : " &iLoad(j))
    MsgBox("Factor: " &dFactor(j))
Next j
Next i
End Sub
```

See also[OSLoadUI::AddRepeatLoad](#)[OSLoadUI::GetRepeatLoadCount](#)[OSLoadUI::GetNoLoadFactorInRepeatLoad](#)**◆ GetRepeatLoadCount()**

long OSLoadUI::GetRepeatLoadCount ()

This function returns the number of repeat load commands in the active load case.

Return values

<Val> The number of repeat load commands in the active load case. To set the active load case use: -
VARIANT **OSLoadUI::SetLoadActive(const VARIANT FAR & varLoadNo)**. To get the active load case use:- VARIANT **OSLoadUI::GetActiveLoad()**

0 General error.

C++ Syntax

```
// Get the number of repeat load.
long nRepeatLoad = OSLoadUI::GetRepeatLoadCount();
```

VBA Syntax

```
Option Explicit
Sub Main
    Dim objOpenStaad As Object
    Dim stdFile As String
    Set objOpenStaad = GetObject(, "StaadPro.OpenSTAAD")
    objOpenStaad.GetSTAADFile stdFile, "TRUE"

    Dim nRepeatLoad As Long
    Dim bRes As Boolean

    bRes = objOpenStaad.Load.SetLoadActive(8)
    If bRes = True Then
        nRepeatLoad = objOpenStaad.Load.GetRepeatLoadCount()
        MsgBox("Number of repeat load: " & nRepeatLoad)
    Else
        MsgBox("Not Able to Set Active Load Case")
    End If
End Sub
```

See also

OSLoadUI::SetLoadActive

OSLoadUI::GetActiveLoad

OSLoadUI::GetRepeatLoadCount

© Copyright Bentley Systems, Inc. For more information, see <http://www.bentley.com>.