

Xilinx Standalone Library Documentation

XilSkey Library v7.3

UG1191 (v2022.1) April 20, 2022

Xilinx is creating an environment where employees, customers, and partners feel welcome and included. To that end, we're removing non-inclusive language from our products and related collateral. We've launched an internal initiative to remove language that could exclude people or reinforce historical biases, including terms embedded in our software and IPs. You may still find examples of non-inclusive language in our older products as we work to make these changes and align with evolving industry standards. Follow this [link](#) for more information.



Table of Contents

Chapter 1: Overview.....	4
BOARD Support Package Settings.....	5
Hardware Setup.....	6
Chapter 2: BBRAM PL API.....	10
Functions.....	11
Chapter 3: Zynq UltraScale+ MPSoC BBRAM PS API.....	12
Functions.....	12
Chapter 4: Zynq eFUSE PS API.....	14
Functions.....	14
Chapter 5: Zynq UltraScale+ MPSoC eFUSE PS API.....	17
Functions.....	20
Chapter 6: eFUSE PL API.....	43
Functions.....	44
Chapter 7: CRC Calculation API.....	47
Functions.....	47
Chapter 8: User-Configurable Parameters.....	49
Zynq User-Configurable PS eFUSE Parameters.....	49
Zynq User-Configurable PL eFUSE Parameters.....	50
Zynq User-Configurable PL BBRAM Parameters.....	53
UltraScale or UltraScale+ User-Configurable BBRAM PL Parameters.....	54
UltraScale or UltraScale+ User-Configurable PL eFUSE Parameters.....	59
Zynq UltraScale+ MPSoC User-Configurable PS eFUSE Parameters.....	65
Zynq UltraScale+ MPSoC User-Configurable PS BBRAM Parameters.....	72
Zynq UltraScale+ MPSoC User-Configurable PS PUF Parameters.....	73
Chapter 9: Error Codes.....	75

PL eFUSE Error Codes.....	75
PS eFUSE Error Codes.....	78
Zynq UltraScale+ MPSoC BBRAM PS Error Codes.....	82
Status Codes.....	82
Procedures.....	83
Chapter 10: Data Structure Index.....	85
XilSKey_JtagSlr.....	85
XilSKey_UsrFuses.....	85
Appendix A: Additional Resources and Legal Notices.....	87
Xilinx Resources.....	87
Documentation Navigator and Design Hubs.....	87
Please Read: Important Legal Notices.....	88

Overview

The XiLSKey library provides APIs for programming and reading eFUSE bits and for programming the battery-backed RAM (BBRAM) of Zynq-7000 SoC, UltraScale, UltraScale+ and the Zynq UltraScale+ MPSoC devices.

- In Zynq-7000 devices:
 - PS eFUSE holds the RSA primary key hash bits and user feature bits, which can enable or disable some Zynq-7000 processor features.
 - PL eFUSE holds the AES key, the user key and some of the feature bits.
 - PL BBRAM holds the AES key.
- In Kintex/Virtex UltraScale or UltraScale+:
 - PL eFUSE holds the AES key, 32 bit and 128 bit user key, RSA hash and some of the feature bits.
 - PL BBRAM holds AES key with or without DPA protection enable or obfuscated key programming.
- In Zynq UltraScale+ MPSoC:
 - PUF registration and Regeneration.
 - PS eFUSE holds:

Programming AES key and can perform CRC verification of AES key

- Programming/Reading User fuses
- Programming/Reading PPK0/PPK1 sha3 hash
- Programming/Reading SPKID
- Programming/Reading secure control bits
 - PS BBRAM holds the AES key.
 - PL eFUSE holds the AES key, 32 bit and 128 bit user key, RSA hash and some of the feature bits.
 - PL BBRAM holds AES key with or without DPA protection enable or obfuscated key programming.

BOARD Support Package Settings

There are few configurable parameters available under bsp settings, which can be configured during compilation of board support package.

Configurations For Adding New device

The below configurations helps in adding new device information not supported by default. Currently, MicroBlaze, Zynq UltraScale and Zynq UltraScale+ MPSoC devices are supported.

Parameter Name	Description
device_id	Mention the device ID
device_irlen	Mention IR length of the device. Default is 0
device_numslr	Mention number of SLRs available. Range of values can be 1 to 4. Default is 1. If no slaves are present and only one master SLR is available then only 1 number of SLR is available.
device_series	Select the device series. Default is FPGA SERIES ZYNQ. The following device series are supported: XSK_FPGA_SERIES_ZYNQ - Select if the device belongs to the Zynq-7000 family. XSK_FPGA_SERIES_ULTRA - Select if the device belongs to the Zynq UltraScale family. XSK_FPGA_SERIES_ULTRA_PLUS - Select if the device belongs to Zynq UltraScale MPSoC family.
device_masterslr	Mention the master SLR number. Default is 0.

Configurations For Zynq UltraScale+ MPSoC devices

Parameter Name	Description
override_sysmon_cfg	Default = TRUE, library configures sysmon before accessing efuse memory. If you are using the Sysmon library and XilSkey library together, XilSkey overwrites the user defined sysmon configuration by default. When override_sysmon_cfg is set to false, XilSkey expects you to configure the sysmon to read the 3 ADC channels - Supply 1 (VPINT), Supply 3 (VPAUX) and LPD Temperature. XilSkey validates the user defined sysmon configuration is correct before performing the eFuse operations.

.. note:: On Ultrascale and Ultrascale plus devices there can be multiple or single SLRs and among which one can be master and the others are slaves, where SLR 0 is not always the master SLR. Based on master and slave SLR order SLRs in this library are referred with config order index. Master SLR is mentioned with CONFIG ORDER 0, then follows the slaves config order, CONFIG ORDER 1,2 and 3 are for slaves in order. Due to the added support for the SSIT devices, it is recommended to use the updated library with updated examples only for the UltraScale and the UltraScale+ devices.

Hardware Setup

This section describes the hardware setup required for programming PL BBRAM or PL eFUSE.

Hardware setup for Zynq PL

This section describes the hardware setup required for programming BBRAM or eFUSE of Zynq PL devices. PL eFUSE or PL BBRAM is accessed through PS via MIO pins which are used for communication PL eFUSE or PL BBRAM through JTAG signals, these can be changed depending on the hardware setup. A hardware setup which dedicates four MIO pins for JTAG signals should be used and the MIO pins should be mentioned in application header file (xilskey_input.h). There should be a method to download this example and have the MIO pins connected to JTAG before running this application. You can change the listed pins at your discretion.

MUX Usage Requirements

To write the PL eFUSE or PL BBRAM using a driver you must:

- Use four MIO lines (TCK,TMS,TDO,TDI)
- Connect the MIO lines to a JTAG port

If you want to switch between the external JTAG and JTAG operation driven by the MIOs, you must:


- Include a MUX between the external JTAG and the JTAG operation driven by the MIOs
- Assign a MUX selection PIN

To rephrase, to select JTAG for PL EFUSE or PL BBRAM writing, you must define the following:

- The MIOs used for JTAG operations (TCK,TMS,TDI,TDO).
- The MIO used for the MUX Select Line.
- The Value on the MUX Select line, to select JTAG for PL eFUSE or PL BBRAM writing.

The following graphic illustrates the correct MUX usage:

Figure 1: MUX Usage



Note: If you use the Vivado Device Programmer tool to burn PL eFUSEs, there is no need for MUX circuitry or MIO pins.

Hardware setup for UltraScale or UltraScale+

This section describes the hardware setup required for programming BBRAM or eFUSE of UltraScale devices. Accessing UltraScale MicroBlaze eFuse is done by using block RAM initialization. UltraScale eFUSE programming is done through MASTER JTAG. Crucial Programming sequence will be taken care by Hardware module. It is mandatory to add Hardware module in the design. Use hardware module's vhd code and instructions provided to add Hardware module in the design.

- You need to add the Master JTAG primitive to design, that is, the MASTER_JTAG_inst instantiation has to be performed and AXI GPIO pins have to be connected to TDO, TDI, TMS and TCK signals of the MASTER_JTAG primitive.
- For programming eFUSE, along with master JTAG, hardware module(HWM) has to be added in design and it's signals XSK_EFUSEPL_AXI_GPIO_HWM_READY , XSK_EFUSEPL_AXI_GPIO_HWM_END and XSK_EFUSEPL_AXI_GPIO_HWM_START, needs to be connected to AXI GPIO pins to communicate with HWM. Hardware module is not mandatory for programming BBRAM. If your design has a HWM, it is not harmful for accessing BBRAM.
- All inputs (Master JTAG's TDO and HWM's HWM_READY, HWM_END) and all outputs (Master JTAG TDI, TMS, TCK and HWM's HWM_START) can be connected in one channel (or) inputs in one channel and outputs in other channel.
- Some of the outputs of GPIO in one channel and some others in different channels are not supported.
- The design should contain AXI BRAM control memory mapped (1MB).

Note: MASTER_JTAG will disable all other JTAGs.

For providing inputs of MASTER JTAG signals and HWM signals connected to the GPIO pins and GPIO channels, refer GPIO Pins Used for PL Master JTAG Signal and GPIO Channels sections of the UltraScale User-Configurable PL eFUSE Parameters and UltraScale User-Configurable PL BBRAM Parameters. The procedure for programming BBRAM of eFUSE of UltraScale or UltraScale+ can be referred at UltraScale BBRAM Access Procedure and UltraScale eFUSE Access Procedure.

Source Files

The following is a list of eFUSE and BBRAM application project files, folders and macros.

- xilskey_efuse_example.c: This file contains the main application code. The file helps in the PS/PL structure initialization and writes/reads the PS/PL eFUSE based on the user settings provided in the xilskey_input.h file.
- xilskey_input.h: This file contains all the actions that are supported by the eFUSE library. Using the preprocessor directives given in the file, you can read/write the bits in the PS/PL eFUSE. More explanation of each directive is provided in the following sections. Burning or reading the PS/PL eFUSE bits is based on the values set in the xilskey_input.h file. Also contains GPIO pins and channels connected to MASTER JTAG primitive and hardware module to access Ultrascale eFUSE.

In this file:

- specify the 256 bit key to be programmed into BBRAM.
- specify the AES(256 bit) key, User (32 bit and 128 bit) keys and RSA key hash(384 bit) key to be programmed into UltraScale eFUSE.

- XSK_EFUSEPS_DRIVER: Define to enable the writing and reading of PS eFUSE.
 - XSK_EFUSEPL_DRIVER: Define to enable the writing of PL eFUSE.
 - xilskey_bbram_example.c: This file contains the example to program a key into BBRAM and verify the key.
- Note:** This algorithm only works when programming and verifying key are both executed in the recommended order.
- xilskey_efuseps_zynqmp_example.c: This file contains the example code to program the PS eFUSE and read back of eFUSE bits from the cache.
 - xilskey_efuseps_zynqmp_input.h: This file contains all the inputs supported for eFUSE PS of Zynq UltraScale+ MPSoC. eFUSE bits are programmed based on the inputs from the xilskey_efuseps_zynqmp_input.h file.
 - xilskey_bbramps_zynqmp_example.c: This file contains the example code to program and verify BBRAM key of Zynq UltraScale+ MPSoC. Default is zero. You can modify this key on top of the file.
 - xilskey_bbram_ultrascale_example.c: This file contains example code to program and verify BBRAM key of UltraScale.

Note: Programming and verification of BBRAM key cannot be done separately.

- xilskey_bbram_ultrascale_input.h: This file contains all the preprocessor directives you need to provide. In this file, specify BBRAM AES key or Obfuscated AES key to be programmed, DPA protection enable and, GPIO pins and channels connected to MASTER JTAG primitive.
- xilskey_puf_registration.c: This file contains all the PUF related code. This example illustrates PUF registration and generating black key and programming eFUSE with PUF helper data, CHash and Auxiliary data along with the Black key.
- xilskey_puf_registration.h: This file contains all the preprocessor directives based on which read/write the eFUSE bits and Syndrome data generation. More explanation of each directive is provided in the following sections.



CAUTION! Ensure that you enter the correct information before writing or 'burning' eFUSE bits. Once burned, they cannot be changed. The BBRAM key can be programmed any number of times.

Note: POR reset is required for the eFUSE values to be recognized.

BBRAM PL API

This section provides a linked summary and detailed descriptions of the battery-backed RAM (BBRAM) APIs of Zynq PL and UltraScale devices.

Example Usage

- Zynq BBRAM PL example usage:
 - The Zynq BBRAM PL example application should contain the xilskey_bbram_example.c and xilskey_input.h files.
 - You should provide user configurable parameters in the xilskey_input.h file. For more information, refer [Zynq User-Configurable PL BBRAM Parameters](#).
- UltraScale BBRAM example usage:
 - The UltraScale BBRAM example application should contain the xilskey_bbram_ultrascale_input.h and xilskey_bbram_ultrascale_example.c files.
 - You should provide user configurable parameters in the xilskey_bbram_ultrascale_input.h file. For more information, refer [UltraScale or UltraScale+ User-Configurable BBRAM PL Parameters](#).

Note: It is assumed that you have set up your hardware prior to working on the example application. For more information, refer [Hardware Setup](#).

Table 1: Quick Function Reference

Type	Name	Arguments
int	XilSKey_Bbram_Program	XilSKey_Bbram * InstancePtr
int	XilSKey_Bbram_JTAGServerInit	XilSKey_Bbram * InstancePtr

Functions

XilSKey_Bbram_Program

This function implements the BBRAM algorithm for programming and verifying key. The program and verify will only work together in and in that order.

Note: This function will program BBRAM of Ultrascale and Zynq as well.

Prototype

```
int XilSKey_Bbram_Program(XilSKey_Bbram *InstancePtr);
```

Parameters

The following table lists the `XilSKey_Bbram_Program` function arguments.

Table 2: XilSKey_Bbram_Program Arguments

Type	Name	Description
XilSKey_Bbram *	InstancePtr	Pointer to XilSKey_Bbram

Returns

XilSKey_Bbram_JTAGServerInit

This function initializes JTAG server.

Prototype

```
int XilSKey_Bbram_JTAGServerInit(XilSKey_Bbram *InstancePtr);
```

Parameters

The following table lists the `XilSKey_Bbram_JTAGServerInit` function arguments.

Table 3: XilSKey_Bbram_JTAGServerInit Arguments

Type	Name	Description
XilSKey_Bbram *	InstancePtr	Pointer to XilSKey_Bbram

Returns

Zynq UltraScale+ MPSoC BBRAM PS API

This section provides a linked summary and detailed descriptions of the battery-backed RAM (BBRAM) APIs for Zynq UltraScale+ MPSoC devices.

Example Usage

- The Zynq UltraScale+ MPSoc example application should contain the `xilsky_bbramps_zynqmp_example.c` file.
- User configurable key can be modified in the same file (`xilsky_bbramps_zynqmp_example.c`), at the `XSK_ZYNQMP_BBRAMPS_AES_KEY` macro.

Table 4: Quick Function Reference

Type	Name	Arguments
u32	XilSKey_ZynqMp_Bbram_Program	const u32 * AesKey
u32	XilSKey_ZynqMp_Bbram_Zeroise	void

Functions

XilSKey_ZynqMp_Bbram_Program

This function implements the BBRAM programming and verifying the key written. Program and verification of AES will work only together. CRC of the provided key will be calculated internally and verified after programming.

Prototype

```
u32 XilSKey_ZynqMp_Bbram_Program(const u32 *AesKey);
```

Parameters

The following table lists the `XilSKey_ZynqMp_Bbram_Program` function arguments.

Table 5: XilSKey_ZynqMp_Bbram_Program Arguments

Type	Name	Description
const u32 *	AesKey	Pointer to the key which has to be programmed.

Returns

- Error code from `XskZynqMp_Ps_Bbram_ErrorCodes` enum if it fails
- `XST_SUCCESS` if programming is done.

XilSKey_ZynqMp_Bbram_Zeroise

This function zeroize's Bbram Key.

Note: BBRAM key will be zeroized.

Prototype

```
u32 XilSKey_ZynqMp_Bbram_Zeroise(void);
```

Zynq eFUSE PS API

This chapter provides a linked summary and detailed descriptions of the Zynq eFUSE PS APIs.

Example Usage

- The Zynq eFUSE PS example application should contain the `xilskey_efuse_example.c` and the `xilskey_input.h` files.
- There is no need of any hardware setup. By default, both the eFUSE PS and PL are enabled in the application. You can comment 'XSK_EFUSEPL_DRIVER' to execute only the PS. For more details, refer [Zynq User-Configurable PS eFUSE Parameters](#).

Table 6: Quick Function Reference

Type	Name	Arguments
u32	XilSKey_EfusePs_Write	InstancePtr
u32	XilSKey_EfusePs_Read	InstancePtr
u32	XilSKey_EfusePs_ReadStatus	XilSKey_EPs * InstancePtr u32 * StatusBits

Functions

XilSKey_EfusePs_Write

PS eFUSE interface functions

This function is used to write to the PS eFUSE.

Note: When called, this Initializes the timer, XADC subsystems. Unlocks the PS eFUSE controller. Configures the PS eFUSE controller. Writes the hash and control bits if requested. Programs the PS eFUSE to enable the RSA authentication if requested. Locks the PS eFUSE controller. Returns an error, if the reference clock frequency is not in between 20 and 60 MHz or if the system not in a position to write the requested PS eFUSE bits (because the bits are already written or not allowed to write) or if the temperature and voltage are not within range

Prototype

```
u32 XilSKey_EfusePs_Write(XilSKey_EPs *PsInstancePtr);
```

Parameters

The following table lists the `XilSKey_EfusePs_Write` function arguments.

Table 7: XilSKey_EfusePs_Write Arguments

Type	Name	Description
Commented parameter InstancePtr does not exist in function <code>XilSKey_EfusePs_Write</code> .	InstancePtr	Pointer to the <code>PsEfuseHandle</code> which describes which PS eFUSE bit should be burned.

Returns

- `XST_SUCCESS`.
- In case of error, value is as defined in `xilskey_utils.h` Error value is a combination of Upper 8 bit value and Lower 8 bit value. For example, `0x8A03` should be checked in `error.h` as `0x8A00` and `0x03`. Upper 8 bit value signifies the major error and lower 8 bit values tells more precisely.

XilSKey_EfusePs_Read

This function is used to read the PS eFUSE.

Note: When called: This API initializes the timer, XADC subsystems. Unlocks the PS eFUSE Controller. Configures the PS eFUSE Controller and enables read-only mode. Reads the PS eFUSE (Hash Value), and enables read-only mode. Locks the PS eFUSE Controller. Returns an error, if the reference clock frequency is not in between 20 and 60MHz. or if unable to unlock PS eFUSE controller or requested address corresponds to restricted bits. or if the temperature and voltage are not within range

Prototype

```
u32 XilSKey_EfusePs_Read(XilSKey_EPs *PsInstancePtr);
```

Parameters

The following table lists the `XilSKey_EfusePs_Read` function arguments.

Table 8: XilSKey_EfusePs_Read Arguments

Type	Name	Description
Commented parameter InstancePtr does not exist in function <code>XilSKey_EfusePs_Read</code> .	InstancePtr	Pointer to the <code>PsEfuseHandle</code> which describes which PS eFUSE should be burned.

Returns

- XST_SUCCESS no errors occurred.
- In case of error, value is as defined in xilsky_utils.h. Error value is a combination of Upper 8 bit value and Lower 8 bit value. For example, 0x8A03 should be checked in error.h as 0x8A00 and 0x03. Upper 8 bit value signifies the major error and lower 8 bit values tells more precisely.

XilSKey_EfusePs_ReadStatus

This function is used to read the PS efuse status register.

Note: This API unlocks the controller and reads the Zynq PS eFUSE status register.

Prototype

```
u32 XilSKey_EfusePs_ReadStatus(XilSKey_EPs *InstancePtr, u32 *StatusBits);
```

Parameters

The following table lists the `XilSKey_EfusePs_ReadStatus` function arguments.

Table 9: XilSKey_EfusePs_ReadStatus Arguments

Type	Name	Description
XilSKey_EPs *	InstancePtr	Pointer to the PS eFUSE instance.
u32 *	StatusBits	Buffer to store the status register read.

Returns

- XST_SUCCESS.
- XST_FAILURE

Zynq UltraScale+ MPSoC eFUSE PS API

This chapter provides a linked summary and detailed descriptions of the Zynq MPSoC UltraScale+ eFUSE PS APIs.

Example Usage

- For programming eFUSEs other than the PUF, the Zynq UltraScale+ MPSoC example application should contain the `xilsky_efuseps_zynqmp_example.c` and the `xilsky_efuseps_zynqmp_input.h` files.
- For PUF registration, programming PUF helper data, AUX, chash, and black key, the Zynq UltraScale+ MPSoC example application should contain the `xilsky_puf_registration.c` and the `xilsky_puf_registration.h` files.
- For more details on the user configurable parameters, refer [Zynq UltraScale+ MPSoC User-Configurable PS eFUSE Parameters](#) and [Zynq UltraScale+ MPSoC User-Configurable PS PUF Parameters](#).

This file contains the PS eFUSE API's of Zynq UltraScale+ MPSoC to program/read the eFUSE array.

Table 10: Quick Function Reference

Type	Name	Arguments
u32	XilSKey_ZynqMp_EfusePs_CheckAesKeyCrc	u32 CrcValue
u32	XilSKey_ZynqMp_EfusePs_ReadUserFuse	u32 * UseFusePtr u8 UserFuse_Num u8 ReadOption
u32	XilSKey_ZynqMp_EfusePs_ReadPpk0Hash	u32 * Ppk0Hash u8 ReadOption
u32	XilSKey_ZynqMp_EfusePs_ReadPpk1Hash	u32 * Ppk1Hash u8 ReadOption

Table 10: Quick Function Reference (cont'd)

Type	Name	Arguments
u32	XilSKey_ZynqMp_EfusePs_ReadSpkId	u32 * SpkId u8 ReadOption
void	XilSKey_ZynqMp_EfusePs_ReadDna	u32 * DnaRead
u32	XilSKey_ZynqMp_EfusePs_ReadSecCtrlBits	XilSKey_SecCtrlBits * ReadBackSecCtrlBits u8 ReadOption
u32	XilSKey_ZynqMp_EfusePs_CacheLoad	void
u32	XilSKey_ZynqMp_EfusePs_Write	XilSKey_ZynqMpEPs * InstancePtr
u32	XilSKey_ZynqMpEfuseAccess	const u32 AddrHigh const u32 AddrLow
void	XilSKey_ZynqMp_EfusePs_SetTimerValues	void
u32	XilSKey_ZynqMp_EfusePs_ReadRow	u8 Row XskEfusePs_Type EfuseType u32 * RowData
u32	XilSKey_ZynqMp_EfusePs_SetWriteConditions	void
u32	XilSKey_ZynqMp_EfusePs_WriteAndVerifyBit	u8 Row u8 Column XskEfusePs_Type EfuseType
u32	XilSKey_ZynqMp_EfusePs_Init	void
u32	XilSKey_ZynqMp_EfusePs_CheckForZeros	u8 RowStart u8 RowEnd XskEfusePs_Type EfuseType
u32	XilSKey_ZynqMp_EfusePs_WritePufHelpData	const XilSKey_Puf * InstancePtr
u32	XilSKey_ZynqMp_EfusePs_ReadPufHelpData	u32 * Address
u32	XilSKey_ZynqMp_EfusePs_WritePufHash	const XilSKey_Puf * InstancePtr

Table 10: Quick Function Reference (cont'd)

Type	Name	Arguments
u32	XilSKey_ZynqMp_EfusePs_ReadPufChash	u32 * Address u8 ReadOption
u32	XilSKey_ZynqMp_EfusePs_WritePufAux	const XilSKey_Puf * InstancePtr
u32	XilSKey_ZynqMp_EfusePs_ReadPufAux	u32 * Address u8 ReadOption
u32	XilSKey_Write_Puf_EfusePs_SecureBits	const XilSKey_Puf_Secure * WriteSecureBits
u32	XilSKey_Read_Puf_EfusePs_SecureBits	XilSKey_Puf_Secure * SecureBitsRead u8 ReadOption
u32	XilSKey_Puf_Registration	XilSKey_Puf * InstancePtr
u32	XilSKey_Puf_Regeneration	const XilSKey_Puf * InstancePtr
INLINE u32	XilSKey_ZynqMp_EfusePsWrite_Checks	XilSKey_ZynqMpEPs * InstancePtr
INLINE u32	XilSKey_ZynqMp_EfusePs_WriteAndVerify_RowRange	const u8 * Data u8 RowStart u8 RowEnd XskEfusePs_Type EfuseType
INLINE u32	XilSKey_ZynqMp_EfusePs_WriteBit	u8 Row u8 Column XskEfusePs_Type EfuseType
INLINE u32	XilSKey_ZynqMp_EfusePs_Write_SecCtrl	const XilSKey_ZynqMpEPs * InstancePtr
INLINE u32	XilSKey_ZynqMp_EfusePs_Write_SecCtrlBits	const XilSKey_ZynqMpEPs * InstancePtr
INLINE u32	XilSKey_ZynqMp_EfusePs_Write_UsrCtrlBits	const XilSKey_ZynqMpEPs * InstancePtr
INLINE void	XilSKey_ZynqMp_EfusePs_ReadSecCtrlBits_Regs	XilSKey_SecCtrlBits * ReadBackSecCtrlBits
INLINE u32	XilSKey_ZynqMp_EfusePs_CheckZeros_BfrPrgrmg	const XilSKey_ZynqMpEPs * InstancePtr
INLINE u32	XilSKey_ZynqMp_EfusePs_UserFuses_WriteChecks	const XilSKey_ZynqMpEPs * InstancePtr UserFuses_TobePrgrmd

Table 10: Quick Function Reference (cont'd)

Type	Name	Arguments
INLINE u32	XilSKey_ZynqMp_EfusePs_UserFuses_ToBeProgrammed	const u8 * UserFuses_Write const u8 * UserFuses_Read XilSKey_UsrFuses * UserFuses_ToBePrgrmd
INLINE u32	XilSKey_ZynqMp_EfusePs_Enable_Rsa	const u8 * SecBits_read
u32	XilSKey_ZynqMpEfuseRead	Offset Buffer Size UsrFuseNum const u32 AddrHigh const u32 AddrLow
u32	XilSKey_ZynqMpEfuseWrite	const u32 AddrHigh const u32 AddrLow

Functions

XilSKey_ZynqMp_EfusePs_CheckAesKeyCrc

This function performs the CRC check of AES key

Note: For Calculating the CRC of the AES key use the [XilSKey_CrcCalculation\(\)](#) function or [XilSKey_CrcCalculation_AesKey\(\)](#) function

Prototype

```
u32 XilSKey_ZynqMp_EfusePs_CheckAesKeyCrc(u32 CrcValue);
```

Parameters

The following table lists the [XilSKey_ZynqMp_EfusePs_CheckAesKeyCrc](#) function arguments.

Table 11: XilSKey_ZynqMp_EfusePs_CheckAesKeyCrc Arguments

Type	Name	Description
u32	CrcValue	A 32 bit CRC value of an expected AES key.

Returns

- XST_SUCCESS on successful CRC check.
- ErrorCode on failure

XilSKey_ZynqMp_EfusePs_ReadUserFuse

This function is used to read a user fuse from the eFUSE or cache

Note: It is highly recommended to read from eFuse cache. Because reading from efuse may reduce the life of the efuse. And Cache reload is required for obtaining updated values for ReadOption 0.

Prototype

```
u32 XilSKey_ZynqMp_EfusePs_ReadUserFuse(u32 *UseFusePtr, u8 UserFuse_Num,
u8 ReadOption);
```

Parameters

The following table lists the `XilSKey_ZynqMp_EfusePs_ReadUserFuse` function arguments.

Table 12: XilSKey_ZynqMp_EfusePs_ReadUserFuse Arguments

Type	Name	Description
u32 *	UseFusePtr	Pointer to an array which holds the readback user fuse.
u8	UserFuse_Num	A variable which holds the user fuse number. Range is (User fuses: 0 to 7)
u8	ReadOption	Indicates whether or not to read from the actual eFUSE array or from the eFUSE cache. <ul style="list-style-type: none"> • 0(XSK_EFUSEPS_READ_FROM_CACHE) Reads from eFUSE cache • 1(XSK_EFUSEPS_READ_FROM_EFUSE) Reads from eFUSE array

Returns

- XST_SUCCESS on successful read
- ErrorCode on failure

XilSKey_ZynqMp_EfusePs_ReadPpk0Hash

This function is used to read the PPK0 hash from an eFUSE or eFUSE cache.

Note: It is highly recommended to read from eFuse cache. Because reading from efuse may reduce the life of the efuse. And Cache reload is required for obtaining updated values for ReadOption 0.

Prototype

```
u32 XilSKey_ZynqMp_EfusePs_ReadPpk0Hash(u32 *Ppk0Hash, u8 ReadOption);
```

Parameters

The following table lists the `XilSKey_ZynqMp_EfusePs_ReadPpk0Hash` function arguments.

Table 13: XilSKey_ZynqMp_EfusePs_ReadPpk0Hash Arguments

Type	Name	Description
u32 *	Ppk0Hash	A pointer to an array which holds the readback PPK0 hash.
u8	ReadOption	Indicates whether or not to read from the actual eFUSE array or from the eFUSE cache. <ul style="list-style-type: none"> 0(XSK_EFUSEPS_READ_FROM_CACHE) Reads from eFUSE cache 1(XSK_EFUSEPS_READ_FROM_EFUSE) Reads from eFUSE array

Returns

- XST_SUCCESS on successful read
- ErrorCode on failure

XilSKey_ZynqMp_EfusePs_ReadPpk1Hash

This function is used to read the PPK1 hash from eFUSE or cache.

Note: It is highly recommended to read from eFuse cache. Because reading from efuse may reduce the life of the efuse. And Cache reload is required for obtaining updated values for ReadOption 0.

Prototype

```
u32 XilSKey_ZynqMp_EfusePs_ReadPpk1Hash(u32 *Ppk1Hash, u8 ReadOption);
```

Parameters

The following table lists the `XilSKey_ZynqMp_EfusePs_ReadPpk1Hash` function arguments.

Table 14: XilSKey_ZynqMp_EfusePs_ReadPpk1Hash Arguments

Type	Name	Description
u32 *	Ppk1Hash	Pointer to an array which holds the readback PPK1 hash.

Table 14: XilSKey_ZynqMp_EfusePs_ReadPpk1Hash Arguments (cont'd)

Type	Name	Description
u8	ReadOption	<p>Indicates whether or not to read from the actual eFUSE array or from the eFUSE cache.</p> <ul style="list-style-type: none"> 0(XSK_EFUSEPS_READ_FROM_CACHE) Reads from eFUSE cache 1(XSK_EFUSEPS_READ_FROM_EFUSE) Reads from eFUSE array

Returns

- XST_SUCCESS on successful read
- ErrorCode on failure

XilSKey_ZynqMp_EfusePs_ReadSpkId

This function is used to read SPKID from eFUSE or cache based on user's read option.

Note: It is highly recommended to read from eFuse cache. Because reading from efuse may reduce the life of the efuse. And Cache reload is required for obtaining updated values for ReadOption 0.

Prototype

```
u32 XilSKey_ZynqMp_EfusePs_ReadSpkId(u32 *SpkId, u8 ReadOption);
```

Parameters

The following table lists the XilSKey_ZynqMp_EfusePs_ReadSpkId function arguments.

Table 15: XilSKey_ZynqMp_EfusePs_ReadSpkId Arguments

Type	Name	Description
u32 *	SpkId	Pointer to a 32 bit variable which holds SPK ID.
u8	ReadOption	<p>Indicates whether or not to read from the actual eFUSE array or from the eFUSE cache.</p> <ul style="list-style-type: none"> 0(XSK_EFUSEPS_READ_FROM_CACHE) Reads from eFUSE cache 1(XSK_EFUSEPS_READ_FROM_EFUSE) Reads from eFUSE array

Returns

- XST_SUCCESS on successful read
- ErrorCode on failure

XilSKey_ZynqMp_EfusePs_ReadDna

This function is used to read DNA from eFUSE.

Prototype

```
void XilSKey_ZynqMp_EfusePs_ReadDna(u32 *DnaRead);
```

Parameters

The following table lists the `XilSKey_ZynqMp_EfusePs_ReadDna` function arguments.

Table 16: XilSKey_ZynqMp_EfusePs_ReadDna Arguments

Type	Name	Description
u32 *	DnaRead	Pointer to an array of 3 x u32 words which holds the readback DNA.

XilSKey_ZynqMp_EfusePs_ReadSecCtrlBits

This function is used to read the PS eFUSE secure control bits from cache or eFUSE based on user input provided.

Note: It is highly recommended to read from eFuse cache. Because reading from efuse may reduce the life of the efuse. And Cache reload is required for obtaining updated values for ReadOption 0.

Prototype

```
u32 XilSKey_ZynqMp_EfusePs_ReadSecCtrlBits(XilSKey_SecCtrlBits
*ReadBackSecCtrlBits, u8 ReadOption);
```

Parameters

The following table lists the `XilSKey_ZynqMp_EfusePs_ReadSecCtrlBits` function arguments.

Table 17: XilSKey_ZynqMp_EfusePs_ReadSecCtrlBits Arguments

Type	Name	Description
XilSKey_SecCtrlBits *	ReadBackSecCtrlBits	Pointer to the XilSKey_SecCtrlBits which holds the read secure control bits.
u8	ReadOption	Indicates whether or not to read from the actual eFUSE array or from the eFUSE cache. <ul style="list-style-type: none"> 0(XSK_EFUSEPS_READ_FROM_CACHE) Reads from eFUSE cache 1(XSK_EFUSEPS_READ_FROM_EFUSE) Reads from eFUSE array

Returns

- XST_SUCCESS if reads successfully
- XST_FAILURE if reading is failed

XilSKey_ZynqMp_EfusePs_CacheLoad

This function reloads the cache of eFUSE so that can be directly read from cache.

Note: Not recommended to call this API frequently, if this API is called all the cache memory is reloaded by reading eFUSE array, reading eFUSE bit multiple times may diminish the life time.

Prototype

```
u32 XilSKey_ZynqMp_EfusePs_CacheLoad(void);
```

Returns

- XST_SUCCESS on successful cache reload
- ErrorCode on failure

XilSKey_ZynqMp_EfusePs_Write

This function is used to program the PS eFUSE of ZynqMP, based on user inputs

Note: After eFUSE programming is complete, the cache is automatically reloaded so all programmed eFUSE bits can be directly read from cache.

Prototype

```
u32 XilSKey_ZynqMp_EfusePs_Write(XilSKey_ZynqMpEPs *InstancePtr);
```

Parameters

The following table lists the `XilSKey_ZynqMp_EfusePs_Write` function arguments.

Table 18: XilSKey_ZynqMp_EfusePs_Write Arguments

Type	Name	Description
XilSKey_ZynqMpEPs *	InstancePtr	Pointer to the XilSKey_ZynqMpEPs.

Returns

- XST_SUCCESS if programs successfully.
- Errorcode on failure

XilSkey_ZynqMpEfuseAccess

This function is used by PMUFW IPI call handler for programming eFUSE.

Register	Read	Write	Size in bytes	Offset
DNA	YES	NO	0xc	0xC
User0	YES	YES	0x4	0x20
User1	YES	YES	0x4	0x24
User2	YES	YES	0x4	0x28
User3	YES	YES	0x4	0x2c
User4	YES	YES	0x4	0x30
User5	YES	YES	0x4	0x34
User6	YES	YES	0x4	0x38
User7	YES	YES	0x4	0x3C
Misc user	YES	YES	0x4	0x40
Secure control	YES	YES	0x4	0x58
SPK ID	YES	YES	0x4	0x5C
AES key	NO	YES	0x20	0x60
PPK0 hash	YES	YES	0x30	0xA0
PPK1 hash	YES	YES	0x30	0xD0

Prototype

```
u32 XilSkey_ZynqMpEfuseAccess(const u32 AddrHigh, const u32 AddrLow);
```

Parameters

The following table lists the `XilSkey_ZynqMpEfuseAccess` function arguments.

Table 19: XilSkey_ZynqMpEfuseAccess Arguments

Type	Name	Description
const u32	AddrHigh	Higher 32-bit address of the XilSkey_Efuse structure.
const u32	AddrLow	Lower 32-bit address of the XilSkey_Efuse structure.

Returns

- XST_SUCCESS - On success
- ErrorCode - on Failure

XilSkey_ZynqMp_EfusePs_SetTimerValues

This function sets timers for programming and reading from eFUSE.

Prototype

```
void XilSKey_ZynqMp_EfusePs_SetTimerValues(void);
```

XilSKey_ZynqMp_EfusePs_ReadRow

This function returns particular row data directly from eFUSE array.

Prototype

```
u32 XilSKey_ZynqMp_EfusePs_ReadRow(u8 Row, XskEfusePs_Type EfuseType, u32 *RowData);
```

Parameters

The following table lists the `XilSKey_ZynqMp_EfusePs_ReadRow` function arguments.

Table 20: XilSKey_ZynqMp_EfusePs_ReadRow Arguments

Type	Name	Description
u8	Row	specifies the row number to read.
XskEfusePs_Type	EfuseType	specifies the eFUSE type.
u32 *	RowData	is a pointer to 32 bit variable to hold the data read from provided data

Returns

XST_SUCCESS - On success ErrorCode - on Failure

XilSKey_ZynqMp_EfusePs_SetWriteConditions

This function sets all the required parameters to program eFUSE array.

Prototype

```
u32 XilSKey_ZynqMp_EfusePs_SetWriteConditions(void);
```

Returns

XST_SUCCESS - On success ErrorCode - on Failure

XilSKey_ZynqMp_EfusePs_WriteAndVerifyBit

This function programs and verifies the particular bit of eFUSE array

Prototype

```
u32 XilSKey_ZynqMp_EfusePs_WriteAndVerifyBit(u8 Row, u8 Column,
XskEfusePs_Type EfuseType);
```

Parameters

The following table lists the `XilSKey_ZynqMp_EfusePs_WriteAndVerifyBit` function arguments.

Table 21: XilSKey_ZynqMp_EfusePs_WriteAndVerifyBit Arguments

Type	Name	Description
u8	Row	specifies the row number.
u8	Column	specifies the column number.
XskEfusePs_Type	EfuseType	specifies the eFUSE type.

Returns

XST_SUCCESS - On success ErrorCode - on Failure

XilSKey_ZynqMp_EfusePs_Init

This function initializes sysmonpsu driver.

Prototype

```
u32 XilSKey_ZynqMp_EfusePs_Init(void);
```

Returns

XST_SUCCESS - On success ErrorCode - on Failure

XilSKey_ZynqMp_EfusePs_CheckForZeros

This function is used verify eFUSE keys for Zeros

Prototype

```
u32 XilSKey_ZynqMp_EfusePs_CheckForZeros(u8 RowStart, u8 RowEnd,
XskEfusePs_Type EfuseType);
```

Parameters

The following table lists the `XilSKey_ZynqMp_EfusePs_CheckForZeros` function arguments.

Table 22: XilSKey_ZynqMp_EfusePs_CheckForZeros Arguments

Type	Name	Description
u8	RowStart	is row number from which verification has to be started.
u8	RowEnd	is row number till which verification has to be ended.
XskEfusePs_Type	EfuseType	is the type of the eFUSE in which these rows reside.

Returns

XST_SUCCESS if keys are not programmed. Errorcode on failure.

XilSKey_ZynqMp_EfusePs_WritePufHelprData

This function programs the PS eFUSEs with the PUF helper data.

Note: To generate PufSyndromeData please use XilSKey_Puf_Registration API

Prototype

```
u32 XilSKey_ZynqMp_EfusePs_WritePufHelprData(const XilSKey_Puf
*InstancePtr);
```

Parameters

The following table lists the XilSKey_ZynqMp_EfusePs_WritePufHelprData function arguments.

Table 23: XilSKey_ZynqMp_EfusePs_WritePufHelprData Arguments

Type	Name	Description
const XilSKey_Puf *	InstancePtr	Pointer to the XilSKey_Puf instance.

Returns

- XST_SUCCESS if programs successfully.
- Errorcode on failure

XilSKey_ZynqMp_EfusePs_ReadPufHelprData

This function reads the PUF helper data from eFUSE.

Note: This function only reads from eFUSE non-volatile memory. There is no option to read from Cache.

Prototype

```
u32 XilSKey_ZynqMp_EfusePs_ReadPufHelprData(u32 *Address);
```

Parameters

The following table lists the `XilSKey_ZynqMp_EfusePs_ReadPufHelprData` function arguments.

Table 24: XilSKey_ZynqMp_EfusePs_ReadPufHelprData Arguments

Type	Name	Description
u32 *	Address	Pointer to data array which holds the PUF helper data read from eFUSEs.

Returns

- XST_SUCCESS if reads successfully.
- Errorcode on failure.

XilSKey_ZynqMp_EfusePs_WritePufChash

This function programs eFUSE with CHash value.

Note: To generate the CHash value, please use `XilSKey_Puf_Registration` function.

Prototype

```
u32 XilSKey_ZynqMp_EfusePs_WritePufChash(const XilSKey_Puf *InstancePtr);
```

Parameters

The following table lists the `XilSKey_ZynqMp_EfusePs_WritePufChash` function arguments.

Table 25: XilSKey_ZynqMp_EfusePs_WritePufChash Arguments

Type	Name	Description
const XilSKey_Puf *	InstancePtr	Pointer to the XilSKey_Puf instance.

Returns

- XST_SUCCESS if chash is programmed successfully.
- An Error code on failure

XilSKey_ZynqMp_EfusePs_ReadPufChash

This function reads eFUSE PUF CHash data from the eFUSE array or cache based on the user read option.

Note: Cache reload is required for obtaining updated values for reading from cache..

Prototype

```
u32 XilSKey_ZynqMp_EfusePs_ReadPufChash(u32 *Address, u8 ReadOption);
```

Parameters

The following table lists the `XilSKey_ZynqMp_EfusePs_ReadPufChash` function arguments.

Table 26: XilSKey_ZynqMp_EfusePs_ReadPufChash Arguments

Type	Name	Description
u32 *	Address	Pointer which holds the read back value of the chash.
u8	ReadOption	Indicates whether or not to read from the actual eFUSE array or from the eFUSE cache. <ul style="list-style-type: none"> 0(XSK_EFUSEPS_READ_FROM_CACHE) Reads from cache 1(XSK_EFUSEPS_READ_FROM_EFUSE) Reads from eFUSE array

Returns

- XST_SUCCESS if programs successfully.
- Errorcode on failure

XilSKey_ZynqMp_EfusePs_WritePufAux

This function programs eFUSE PUF auxiliary data.

Note: To generate auxiliary data, please use `XilSKey_Puf_Registration` function.

Prototype

```
u32 XilSKey_ZynqMp_EfusePs_WritePufAux(const XilSKey_Puf *InstancePtr);
```

Parameters

The following table lists the `XilSKey_ZynqMp_EfusePs_WritePufAux` function arguments.

Table 27: XilSKey_ZynqMp_EfusePs_WritePufAux Arguments

Type	Name	Description
const XilSKey_Puf *	InstancePtr	Pointer to the XilSKey_Puf instance.

Returns

- XST_SUCCESS if the eFUSE is programmed successfully.
- Errorcode on failure

XilSKey_ZynqMp_EfusePs_ReadPufAux

This function reads eFUSE PUF auxiliary data from eFUSE array or cache based on user read option.

Note: Cache reload is required for obtaining updated values for reading from cache.

Prototype

```
u32 XilSKey_ZynqMp_EfusePs_ReadPufAux(u32 *Address, u8 ReadOption);
```

Parameters

The following table lists the `XilSKey_ZynqMp_EfusePs_ReadPufAux` function arguments.

Table 28: XilSKey_ZynqMp_EfusePs_ReadPufAux Arguments

Type	Name	Description
u32 *	Address	Pointer which holds the read back value of PUF's auxiliary data.
u8	ReadOption	Indicates whether or not to read from the actual eFUSE array or from the eFUSE cache. <ul style="list-style-type: none"> • 0(XSK_EFUSEPS_READ_FROM_CACHE) Reads from cache • 1(XSK_EFUSEPS_READ_FROM_EFUSE) Reads from eFUSE array

Returns

- XST_SUCCESS if PUF auxiliary data is read successfully.
- Errorcode on failure

XilSKey_Write_Puf_EfusePs_SecureBits

This function programs the eFUSE PUF secure bits

Prototype

```
u32 XilSKey_Write_Puf_EfusePs_SecureBits(const XilSKey_Puf_Secure
*WriteSecureBits);
```


Parameters

The following table lists the `XilSKey_Write_Puf_EfusePs_SecureBits` function arguments.

Table 29: XilSKey_Write_Puf_EfusePs_SecureBits Arguments

Type	Name	Description
const XilSKey_Puf_Secure *	WriteSecureBits	Pointer to the XilSKey_Puf_Secure structure

Returns

- XST_SUCCESS if eFUSE PUF secure bits are programmed successfully.
- Errorcode on failure.

XilSKey_Read_Puf_EfusePs_SecureBits

This function is used to read the PS eFUSE PUF secure bits from cache or from eFUSE array.

Prototype

```
u32 XilSKey_Read_Puf_EfusePs_SecureBits(XilSKey_Puf_Secure *SecureBitsRead,
u8 ReadOption);
```

Parameters

The following table lists the `XilSKey_Read_Puf_EfusePs_SecureBits` function arguments.

Table 30: XilSKey_Read_Puf_EfusePs_SecureBits Arguments

Type	Name	Description
XilSKey_Puf_Secure *	SecureBitsRead	Pointer to the XilSKey_Puf_Secure structure which holds the read eFUSE secure bits from the PUF.
u8	ReadOption	Indicates whether or not to read from the actual eFUSE array or from the eFUSE cache. <ul style="list-style-type: none"> • 0(XSK_EFUSEPS_READ_FROM_CACHE) Reads from cache • 1(XSK_EFUSEPS_READ_FROM_EFUSE) Reads from eFUSE array

Returns

- XST_SUCCESS if reads successfully.
- Errorcode on failure.

XilSKey_Puf_Registration

This function performs registration of PUF which generates a new KEK and associated CHash, Auxiliary and PUF-syndrome data which are unique for each silicon.

Note: With the help of generated PUF syndrome data, it will be possible to re-generate same PUF KEK.

Prototype

```
u32 XilSKey_Puf_Registration(XilSKey_Puf *InstancePtr);
```

Parameters

The following table lists the `XilSKey_Puf_Registration` function arguments.

Table 31: XilSKey_Puf_Registration Arguments

Type	Name	Description
XilSKey_Puf *	InstancePtr	Pointer to the XilSKey_Puf instance.

Returns

- XST_SUCCESS if registration/re-registration was successful.
- ERROR if registration was unsuccessful

XilSKey_Puf_Regeneration

This function regenerates the PUF data so that the PUF's output can be used as the key source to the AES-GCM hardware cryptographic engine.

Prototype

```
u32 XilSKey_Puf_Regeneration(const XilSKey_Puf *InstancePtr);
```

Parameters

The following table lists the `XilSKey_Puf_Regeneration` function arguments.

Table 32: XilSKey_Puf_Regeneration Arguments

Type	Name	Description
const XilSKey_Puf *	InstancePtr	is a pointer to the XilSKey_Puf instance.

Returns

- XST_SUCCESS if regeneration was successful.

- ERROR if regeneration was unsuccessful

XilSKey_ZynqMp_EfusePsWrite_Checks

This function performs pre checks for programming all the specified bits.

Prototype

```
INLINE u32 XilSKey_ZynqMp_EfusePsWrite_Checks(XilSKey_ZynqMpEPs
*InstancePtr);
```

Parameters

The following table lists the `XilSKey_ZynqMp_EfusePsWrite_Checks` function arguments.

Table 33: XilSKey_ZynqMp_EfusePsWrite_Checks Arguments

Type	Name	Description
XilSKey_ZynqMpEPs *	InstancePtr	is the pointer to the XilSKey_ZynqMpEPs.

Returns

XST_SUCCESS - if all the conditions for programming is satisfied
 Errorcode - if any of the conditions are not met

XilSKey_ZynqMp_EfusePs_WriteAndVerify_RowRange

This function programs and verifys the row range provided with provided data.

Prototype

```
INLINE u32 XilSKey_ZynqMp_EfusePs_WriteAndVerify_RowRange(const u8 *Data,
u8 RowStart, u8 RowEnd, XskEfusePs_Type EfuseType);
```

Parameters

The following table lists the `XilSKey_ZynqMp_EfusePs_WriteAndVerify_RowRange` function arguments.

Table 34: XilSKey_ZynqMp_EfusePs_WriteAndVerify_RowRange Arguments

Type	Name	Description
const u8 *	Data	is a pointer to an array which contains data to be programmed.
u8	RowStart	holds the row number from which data programming has to be started.
u8	RowEnd	holds the row number till which data programming has to be performed.

Table 34: XilSKey_ZynqMp_EfusePs_WriteAndVerify_RowRange Arguments (cont'd)

Type	Name	Description
XskEfusePs_Type	EfuseType	holds the type of the efuse in which programming rows resides in.

Returns

XST_SUCCESS - On success XST_FAILURE - on Failure

XilSKey_ZynqMp_EfusePs_WriteBit

This function programs a particular bit.

Prototype

```

INLINE u32 XilSKey_ZynqMp_EfusePs_WriteBit(u8 Row, u8 Column,
XskEfusePs_Type EfuseType);

```

Parameters

The following table lists the XilSKey_ZynqMp_EfusePs_WriteBit function arguments.

Table 35: XilSKey_ZynqMp_EfusePs_WriteBit Arguments

Type	Name	Description
u8	Row	specifies the row number to program.
u8	Column	specifies the column number to program.
XskEfusePs_Type	EfuseType	specifies the eFUSE type.

Returns

XST_SUCCESS - On success ErrorCode - on Failure

XilSKey_ZynqMp_EfusePs_Write_SecCtrl

This function programs secure control bits specified by user.

Prototype

```

INLINE u32 XilSKey_ZynqMp_EfusePs_Write_SecCtrl(const XilSKey_ZynqMpEPs
*InstancePtr);

```

Parameters

The following table lists the XilSKey_ZynqMp_EfusePs_Write_SecCtrl function arguments.

Table 36: XilSKey_ZynqMp_EfusePs_Write_SecCtrl Arguments

Type	Name	Description
const XilSKey_ZynqMpEPs *	InstancePtr	is an instance of efuseps of Zynq MP.

Returns

XST_SUCCESS - On success ErrorCode - on Failure

XilSKey_ZynqMp_EfusePs_Write_SecCtrlBits

This function programs secure control bits of eFUSE

Prototype

```

INLINE u32 XilSKey_ZynqMp_EfusePs_Write_SecCtrlBits(const XilSKey_ZynqMpEPs
*InstancePtr);

```

Parameters

The following table lists the XilSKey_ZynqMp_EfusePs_Write_SecCtrlBits function arguments.

Table 37: XilSKey_ZynqMp_EfusePs_Write_SecCtrlBits Arguments

Type	Name	Description
const XilSKey_ZynqMpEPs *	InstancePtr	is an instance of efuseps of ZynqMP.

Returns

XST_SUCCESS - On success ErrorCode - on Failure

XilSKey_ZynqMp_EfusePs_Write_UsrCtrlBits

This function programs misc user control bits of eFUSE

Prototype

```

INLINE u32 XilSKey_ZynqMp_EfusePs_Write_UsrCtrlBits(const XilSKey_ZynqMpEPs
*InstancePtr);

```

Parameters

The following table lists the XilSKey_ZynqMp_EfusePs_Write_UsrCtrlBits function arguments.

Table 38: XilSKey_ZynqMp_EfusePs_Write_UsrCtrlBits Arguments

Type	Name	Description
const XilSKey_ZynqMpEPs *	InstancePtr	is an instance of efuseps of ZynqMp.

Returns

XST_SUCCESS - On success ErrorCode - on Failure

XilSKey_ZynqMp_EfusePs_ReadSecCtrlBits_Regs

This function is used to read the PS eFUSE secure control bits from cache or from eFUSE array based on user selection.

Note: It is highly recommended to read from eFuse cache. Because reading from efuse may reduce the life of the efuse. And Cache reload is required for obtaining updated values for ReadOption 0.

Prototype

```

INLINE void XilSKey_ZynqMp_EfusePs_ReadSecCtrlBits_Regs(XilSKey_SecCtrlBits
*ReadBackSecCtrlBits);

```

Parameters

The following table lists the XilSKey_ZynqMp_EfusePs_ReadSecCtrlBits_Regs function arguments.

Table 39: XilSKey_ZynqMp_EfusePs_ReadSecCtrlBits_Regs Arguments

Type	Name	Description
XilSKey_SecCtrlBits *	ReadBackSecCtrlBits	is the pointer to the XilSKey_SecCtrlBits which holds the read secure control bits.

Returns

- XST_SUCCESS if reads successfully
- XST_FAILURE if reading is failed

XilSKey_ZynqMp_EfusePs_CheckZeros_BfrPrgrmg

This function is used verify eFUSE keys for Zeros before programming.

- ErrorCode if keys are already programmed.

Prototype

```

INLINE u32 XilSKey_ZynqMp_EfusePs_CheckZeros_BfrPrgrmg(const
XilSKey_ZynqMpEPs *InstancePtr);

```

Parameters

The following table lists the `XilSKey_ZynqMp_EfusePs_CheckZeros_BfrPrgrmg` function arguments.

Table 40: XilSKey_ZynqMp_EfusePs_CheckZeros_BfrPrgrmg Arguments

Type	Name	Description
const XilSKey_ZynqMpEPs *	InstancePtr	is a pointer to eFUSE ps instance.

Returns

- XST_SUCCESS if keys are not programmed

XilSKey_ZynqMp_EfusePs_UserFuses_WriteChecks

This function throws an error if user requests already programmed User FUSE bit to revert, and copies the User FUSE bits which needs actually to be programmed into provided `UserFuses_TobePrgrmd` pointer.

Note: If user requests a non-zero bit for making to zero throws an error which is not possible

Prototype

```

INLINE u32 XilSKey_ZynqMp_EfusePs_UserFuses_WriteChecks(const
XilSKey_ZynqMpEPs *InstancePtr, XilSKey_UsrFuses *ToBePrgrmd);

```

Parameters

The following table lists the `XilSKey_ZynqMp_EfusePs_UserFuses_WriteChecks` function arguments.

Table 41: XilSKey_ZynqMp_EfusePs_UserFuses_WriteChecks Arguments

Type	Name	Description
const XilSKey_ZynqMpEPs *	InstancePtr	is a pointer to eFUSE ps instance.
Commented parameter <code>UserFuses_TobePrgrmd</code> does not exist in function <code>XilSKey_ZynqMp_EfusePs_UserFuses_WriteChecks</code> .	UserFuses_TobePrgrmd	holds User FUSE bits which needs to be actually programmed.

Returns

- ErrorCode if user requests programmed bit to revert.
- XST_SUCCESS if user requests valid bits

XilSKey_ZynqMp_EfusePs_UserFuses_TobeProgrammed

This function throws an error if user requests already programmed User FUSE bit to revert, and copies the bits to be programmed in particular row into provided UserFuses_TobePrgrmd pointer.

Note: If user requests a non-zero bit for making to zero throws an error which is not possible

Prototype

```

INLINE u32 XilSKey_ZynqMp_EfusePs_UserFuses_TobeProgrammed(const u8
*UserFuses_Write, const u8 *UserFuses_Read, XilSKey_UsrFuses
*UserFuses_ToBePrgrmd);

```

Parameters

The following table lists the XilSKey_ZynqMp_EfusePs_UserFuses_TobeProgrammed function arguments.

Table 42: XilSKey_ZynqMp_EfusePs_UserFuses_TobeProgrammed Arguments

Type	Name	Description
const u8 *	UserFuses_Write	is a pointer to user requested programming bits of an User FUSE row.
const u8 *	UserFuses_Read	is a pointer to already programmed bits of User FUSE row on eFUSE.
XilSKey_UsrFuses *	UserFuses_ToBePrgrmd	holds User FUSE row bits which needs to be programmed actually.

Returns

- XST_FAILURE: Returns error if user requests programmed bit to revert
- XST_SUCCESS: If User requests valid bits.

XilSKey_ZynqMp_EfusePs_Enable_Rsa

This function programs RSA enable secure control bits of eFUSE

Note: For ZynqMP silicon version 1.0 and 2.0 RSA authentication is enabled only by programming 24 and 25 bits of SEC_CTRL register but from silicon V3.0 bits 11:25 should be programmed

Prototype

```
INLINE u32 XilSKey_ZynqMp_EfusePs_Enable_Rsa(const u8 *SecBits_read);
```

Parameters

The following table lists the `XilSKey_ZynqMp_EfusePs_Enable_Rsa` function arguments.

Table 43: XilSKey_ZynqMp_EfusePs_Enable_Rsa Arguments

Type	Name	Description
const u8 *	SecBits_read	is a pointer which holds 32 bits of secure control register.

Returns

XST_SUCCESS - On success
 ErrorCode - on Failure

XilSKey_ZynqMpEfuseRead

This function provides support to read user eFUSES

Prototype

```
u32 XilSKey_ZynqMpEfuseRead(const u32 AddrHigh, const u32 AddrLow);
```

Parameters

The following table lists the `XilSKey_ZynqMpEfuseRead` function arguments.

Table 44: XilSKey_ZynqMpEfuseRead Arguments

Type	Name	Description
Commented parameter Offset does not exist in function <code>XilSKey_ZynqMpEfuseRead</code> .	Offset	Offset specifies the user fuses offset to be read.
Commented parameter Buffer does not exist in function <code>XilSKey_ZynqMpEfuseRead</code> .	Buffer	Requested user fuses values will be stored in this pointer.
Commented parameter Size does not exist in function <code>XilSKey_ZynqMpEfuseRead</code> .	Size	To be specified in words.

Table 44: XilSKey_ZynqMpEfuseRead Arguments (cont'd)

Type	Name	Description
Commented parameter UsrFuseNum does not exist in function XilSKey_ZynqMpEfuseRead.	UsrFuseNum	Userfuse number
const u32	AddrHigh	Higher 32-bit address of the XilSKey_Efuse structure.
const u32	AddrLow	Lower 32-bit address of the XilSKey_Efuse structure.

Returns

XST_SUCCESS - On success
 ErrorCode - on Failure
 This function provides support to read eFUSE memory

XilSKey_ZynqMpEfuseWrite

This function provides support to program eFUSE memory

Prototype

```
u32 XilSKey_ZynqMpEfuseWrite(const u32 AddrHigh, const u32 AddrLow);
```

Parameters

The following table lists the XilSKey_ZynqMpEfuseWrite function arguments.

Table 45: XilSKey_ZynqMpEfuseWrite Arguments

Type	Name	Description
const u32	AddrHigh	Higher 32-bit address of the XilSKey_Efuse structure.
const u32	AddrLow	Lower 32-bit address of the XilSKey_Efuse structure.

Returns

XST_SUCCESS - On success
 ErrorCode - on Failure

eFUSE PL API

This chapter provides a linked summary and detailed descriptions of the eFUSE APIs of Zynq eFUSE PL and UltraScale eFUSE.

Example Usage

- The Zynq eFUSE PL and UltraScale example application should contain the xilskey_efuse_example.c and the xilskey_input.h files.
- By default, both the eFUSE PS and PL are enabled in the application. You can comment 'XSK_EFUSEPL_DRIVER' to execute only the PS.
- For UltraScale, it is mandatory to comment 'XSK_EFUSEPS_DRIVER' else the example will generate an error.
- For more details on the user configurable parameters, refer [Zynq User-Configurable PL eFUSE Parameters](#) and [UltraScale or UltraScale+ User-Configurable PL eFUSE Parameters](#).
- Requires hardware setup to program PL eFUSE of Zynq or UltraScale.

Table 46: Quick Function Reference

Type	Name	Arguments
u32	XilSKey_EfusePl_SystemInit	XilSKey_EPI * InstancePtr
u32	XilSKey_EfusePl_Program	InstancePtr
u32	XilSKey_EfusePl_ReadStatus	XilSKey_EPI * InstancePtr u32 * StatusBits
u32	XilSKey_EfusePl_ReadKey	XilSKey_EPI * InstancePtr

Functions

XilSKey_EfusePl_SystemInit

Note: Updates the global variable ErrorCode with error code(if any).

Prototype

```
u32 XilSKey_EfusePl_SystemInit(XilSKey_EPl *InstancePtr);
```

Parameters

The following table lists the XilSKey_EfusePl_SystemInit function arguments.

Table 47: XilSKey_EfusePl_SystemInit Arguments

Type	Name	Description
XilSKey_EPl *	InstancePtr	- Input data to be written to PL eFUSE

Returns

XilSKey_EfusePl_Program

Programs PL eFUSE with input data given through InstancePtr.

Note: When this API is called: Initializes the timer, XADC/xsysmon and JTAG server subsystems. Returns an error in the following cases, if the reference clock frequency is not in the range or if the PL DAP ID is not identified, if the system is not in a position to write the requested PL eFUSE bits (because the bits are already written or not allowed to write) if the temperature and voltage are not within range.

Prototype

```
u32 XilSKey_EfusePl_Program(XilSKey_EPl *PlInstancePtr);
```

Parameters

The following table lists the XilSKey_EfusePl_Program function arguments.

Table 48: XilSKey_EfusePl_Program Arguments

Type	Name	Description
Commented parameter InstancePtr does not exist in function XilSKey_EfusePl_Program.	InstancePtr	Pointer to PL eFUSE instance which holds the input data to be written to PL eFUSE.

Returns

- XST_FAILURE - In case of failure
- XST_SUCCESS - In case of Success

XilSKey_EfusePl_ReadStatus

Reads the PL efuse status bits and gets all secure and control bits.

Prototype

```
u32 XilSKey_EfusePl_ReadStatus(XilSKey_EPl *InstancePtr, u32 *StatusBits);
```

Parameters

The following table lists the `XilSKey_EfusePl_ReadStatus` function arguments.

Table 49: XilSKey_EfusePl_ReadStatus Arguments

Type	Name	Description
XilSKey_EPl *	InstancePtr	Pointer to PL eFUSE instance.
u32 *	StatusBits	Buffer to store the status bits read.

Returns

XilSKey_EfusePl_ReadKey

Reads the PL efuse keys and stores them in the corresponding arrays in instance structure.

Note: This function initializes the timer, XADC and JTAG server subsystems, if not already done so. In Zynq - Reads AES key and User keys. In Ultrascale - Reads 32 bit and 128 bit User keys and RSA hash But AES key cannot be read directly it can be verified with CRC check (for that we need to update the instance with 32 bit CRC value, API updates whether provided CRC value is matched with actuals or not). To calculate the CRC of expected AES key one can use any of the following APIs [XilSKey_CrcCalculation\(\)](#) or [XilSKey_CrcCalculation_AesKey\(\)](#)

Prototype

```
u32 XilSKey_EfusePl_ReadKey(XilSKey_EPl *InstancePtr);
```

Parameters

The following table lists the `XilSKey_EfusePl_ReadKey` function arguments.

Table 50: XilSKey_EfusePl_ReadKey Arguments

Type	Name	Description
XilSKey_EPI *	InstancePtr	Pointer to PL eFUSE instance.

Returns

CRC Calculation API

This chapter provides a linked summary and detailed descriptions of the CRC calculation APIs. For UltraScale and Zynq UltraScale+ MPSoC devices, the programmed AES cannot be read back. The programmed AES key can only be verified by reading the CRC value of AES key.

Table 51: Quick Function Reference

Type	Name	Arguments
u32	XilSKey_CrcCalculation	const u8 * Key
u32	XilSKey_CrcCalculation_AesKey	const u8 * Key

Functions

XilSKey_CrcCalculation

This function Calculates CRC value based on hexadecimal string passed.

Note: If the length of the string provided is less than 64, this function appends the string with zeros. For calculation of AES key's CRC one can use u32 [XilSKey_CrcCalculation\(u8 *Key\)](#) API or reverse polynomial 0x82F63B78.

Prototype

```
u32 XilSKey_CrcCalculation(const u8 *Key);
```

Parameters

The following table lists the `XilSKey_CrcCalculation` function arguments.

Table 52: XilSKey_CrcCalculation Arguments

Type	Name	Description
const u8 *	Key	Pointer to the string contains AES key in hexadecimal of length less than or equal to 64.

Returns

- On Success returns the Crc of AES key value.
- On failure returns the error code when string length is greater than 64

XilSkey_CrcCalculation_AesKey

Calculates CRC value of the provided key. Key should be provided in hexa buffer.

Prototype

```
u32 XilSkey_CrcCalculation_AesKey(const u8 *Key);
```

Parameters

The following table lists the `XilSkey_CrcCalculation_AesKey` function arguments.

Table 53: XilSkey_CrcCalculation_AesKey Arguments

Type	Name	Description
const u8 *	Key	Pointer to an array of 32 bytes, which holds an AES key.

Returns

Crc of provided AES key value. To calculate CRC on the AES key in string format please use `XilSkey_CrcCalculation`.

User-Configurable Parameters

This section provides detailed descriptions of the various user configurable parameters.

Zynq User-Configurable PS eFUSE Parameters

Define the XSK_EFUSEPS_DRIVER macro to use the PS eFUSE. After defining the macro, provide the inputs defined with XSK_EFUSEPS_DRIVER to burn the bits in PS eFUSE. If the bit is to be burned, define the macro as TRUE; otherwise define the macro as FALSE. For details, refer the following table.

Macro Name	Description
XSK_EFUSEPS_ENABLE_WRITE_PROTECT	<p>Default = FALSE.</p> <p>TRUE to burn the write-protect bits in eFUSE array. Write protect has two bits. When either of the bits is burned, it is considered write-protected. So, while burning the write-protected bits, even if one bit is blown, write API returns success. As previously mentioned, POR reset is required after burning for write protection of the eFUSE bits to go into effect. It is recommended to do the POR reset after write protection. Also note that, after write-protect bits are burned, no more eFUSE writes are possible.</p> <p>If the write-protect macro is TRUE with other macros, write protect is burned in the last iteration, after burning all the defined values, so that for any error while burning other macros will not effect the total eFUSE array.</p> <p>FALSE does not modify the write-protect bits.</p>
XSK_EFUSEPS_ENABLE_RSA_AUTH	<p>Default = FALSE.</p> <p>Use TRUE to burn the RSA enable bit in the PS eFUSE array. After enabling the bit, every successive boot must be RSA-enabled apart from JTAG. Before burning (blowing) this bit, make sure that eFUSE array has the valid PPK hash. If the PPK hash burning is enabled, only after writing the hash successfully, RSA enable bit will be blown. For the RSA enable bit to take effect, POR reset is required. FALSE does not modify the RSA enable bit.</p>
XSK_EFUSEPS_ENABLE_ROM_128K_CRC	<p>Default = FALSE.</p> <p>TRUE burns the ROM 128K CRC bit. In every successive boot, BootROM calculates 128k CRC. FALSE does not modify the ROM CRC 128K bit.</p>

Macro Name	Description
XSK_EFUSEPS_ENABLE_RSA_KEY_HASH	Default = FALSE. TRUE burns (blows) the eFUSE hash, that is given in XSK_EFUSEPS_RSA_KEY_HASH_VALUE when write API is used. TRUE reads the eFUSE hash when the read API is used and is read into structure. FALSE ignores the provided value.
XSK_EFUSEPS_RSA_KEY_HASH_VALUE	Default = The specified value is converted to a hexadecimal buffer and written into the PS eFUSE array when the write API is used. This value should be the Primary Public Key (PPK) hash provided in string format. The buffer must be 64 characters long: valid characters are 0-9, a-f, and A-F. Any other character is considered an invalid string and will not burn RSA hash. When the Xilsky_EfusePs_Write() API is used, the RSA hash is written, and the XSK_EFUSEPS_ENABLE_RSA_KEY_HASH must have a value of TRUE.
XSK_EFUSEPS_DISABLE_DFT_JTAG	Default = FALSE TRUE disables DFT JTAG permanently. FALSE will not modify the eFuse PS DFT JTAG disable bit.
XSK_EFUSEPS_DISABLE_DFT_MODE	Default = FALSE TRUE disables DFT mode permanently. FALSE will not modify the eFuse PS DFT mode disable bit.

Zynq User-Configurable PL eFUSE Parameters

Define the XSK_EFUSEPL_DRIVER macro to use the PL eFUSE. After defining the macro, provide the inputs defined with XSK_EFUSEPL_DRIVER to burn the bits in PL eFUSE bits. If the bit is to be burned, define the macro as TRUE; otherwise define the macro as FALSE. The table below lists the user-configurable PL eFUSE parameters for Zynq devices.

Macro Name	Description
XSK_EFUSEPL_FORCE_PCYCLE_RECONFIG	Default = FALSE If the value is set to TRUE, then the part has to be power-cycled to be reconfigured. FALSE does not set the eFUSE control bit.
XSK_EFUSEPL_DISABLE_KEY_WRITE	Default = FALSE TRUE disables the eFUSE write to FUSE_AES and FUSE_USER blocks. FALSE does not affect the eFUSE bit.
XSK_EFUSEPL_DISABLE_AES_KEY_READ	Default = FALSE TRUE disables the write to FUSE_AES and FUSE_USER key and disables the read of FUSE_AES. FALSE does not affect the eFUSE bit.
XSK_EFUSEPL_DISABLE_USER_KEY_READ	Default = FALSE. TRUE disables the write to FUSE_AES and FUSE_USER key and disables the read of FUSE_USER. FALSE does not affect the eFUSE bit.

Macro Name	Description
XSK_EFUSEPL_DISABLE_FUSE_CNTRL_WRITE	Default = FALSE. TRUE disables the eFUSE write to FUSE_CTRL block. FALSE does not affect the eFUSE bit.
XSK_EFUSEPL_FORCE_USE_AES_ONLY	Default = FALSE. TRUE forces the use of secure boot with eFUSE AES key only. FALSE does not affect the eFUSE bit.
XSK_EFUSEPL_DISABLE_JTAG_CHAIN	Default = FALSE. TRUE permanently disables the Zynq ARM DAP and PL TAP. FALSE does not affect the eFUSE bit.
XSK_EFUSEPL_BBRAM_KEY_DISABLE	Default = FALSE. TRUE forces the eFUSE key to be used if booting Secure Image. FALSE does not affect the eFUSE bit.

MIO Pins for Zynq PL eFUSE JTAG Operations

The table below lists the MIO pins for Zynq PL eFUSE JTAG operations. You can change the listed pins at your discretion.

Note: The pin numbers listed in the table below are examples. You must assign appropriate pin numbers as per your hardware design.

Pin Name	Pin Number
XSK_EFUSEPL_MIO_JTAG_TDI	(17)
XSK_EFUSEPL_MIO_JTAG_TDO	(21)
XSK_EFUSEPL_MIO_JTAG_TCK	(19)
XSK_EFUSEPL_MIO_JTAG_TMS	(20)

MUX Selection Pin for Zynq PL eFUSE JTAG Operations

The table below lists the MUX selection pin.

Pin Name	Pin Number	Description
XSK_EFUSEPL_MIO_JTAG_MUX_SELECT	(11)	This pin toggles between the external JTAG or MIO driving JTAG operations.

MUX Parameter for Zynq PL eFUSE JTAG Operations

The table below lists the MUX parameter.

Parameter Name	Description
XSK_EFUSEPL_MIO_MUX_SEL_DEFAULT_VAL	<p>Default = LOW.</p> <p>LOW writes zero on the MUX select line before PL_eFUSE writing.</p> <p>HIGH writes one on the MUX select line before PL_eFUSE writing.</p>

AES and User Key Parameters

The table below lists the AES and user key parameters.

Parameter Name	Description
XSK_EFUSEPL_PROGRAM_AES_AND_USER_LOW_KEY	Default = FALSE. TRUE burns the AES and User Low hash key, which are given in the XSK_EFUSEPL_AES_KEY and the XSK_EFUSEPL_USER_LOW_KEY respectively. FALSE ignores the provided values. You cannot write the AES Key and the User Low Key separately.
XSK_EFUSEPL_PROGRAM_USER_HIGH_KEY	Default =FALSE. TRUE burns the User High hash key, given in XSK_EFUSEPL_PROGRAM_USER_HIGH_KEY. FALSE ignores the provided values.
XSK_EFUSEPL_AES_KEY	Default = 000 0000000000000 This value converted to hex buffer and written into the PL eFUSE array when write API is used. This value should be the AES Key, given in string format. It must be 64 characters long. Valid characters are 0-9, a-f, A-F. Any other character is considered an invalid string and will not burn AES Key. To write AES Key, XSK_EFUSEPL_PROGRAM_AES_AND_USER_LOW_KEY must have a value of TRUE.
XSK_EFUSEPL_USER_LOW_KEY	Default = 00 This value is converted to a hexadecimal buffer and written into the PL eFUSE array when the write API is used. This value is the User Low Key given in string format. It must be two characters long; valid characters are 0-9,a-f, and A-F. Any other character is considered as an invalid string and will not burn the User Low Key. To write the User Low Key, XSK_EFUSEPL_PROGRAM_AES_AND_USER_LOW_KEY must have a value of TRUE.

Parameter Name	Description
XSK_EFUSEPL_USER_HIGH_KEY	<p>Default = 000000</p> <p>The default value is converted to a hexadecimal buffer and written into the PL eFUSE array when the write API is used. This value is the User High Key given in string format. The buffer must be six characters long: valid characters are 0-9, a-f, A-F. Any other character is considered to be an invalid string and does not burn User High Key.</p> <p>To write the User High Key, the XSK_EFUSEPL_PROGRAM_USER_HIGH_KEY must have a value of TRUE.</p>

Zynq User-Configurable PL BBRAM Parameters

The table below lists the MIO pins for Zynq PL BBRAM JTAG operations.

The table below lists the MUX selection pin for Zynq BBRAM PL JTAG operations.

Note: The pin numbers listed in the table below are examples. You must assign appropriate pin numbers as per your hardware design.

Pin Name	Pin Number
XSK_BBRAM_MIO_JTAG_TDI	(17)
XSK_BBRAM_MIO_JTAG_TDO	(21)
XSK_BBRAM_MIO_JTAG_TCK	(19)
XSK_BBRAM_MIO_JTAG_TMS	(20)

Pin Name	Pin Number
XSK_BBRAM_MIO_JTAG_MUX_SELECT	(11)

MUX Parameter for Zynq BBRAM PL JTAG Operations

The table below lists the MUX parameter for Zynq BBRAM PL JTAG operations.

Parameter Name	Description
XSK_BBRAM_MIO_MUX_SEL_DEFAULT_VAL	<p>Default = LOW.</p> <p>LOW writes zero on the MUX select line before PL_eFUSE writing.</p> <p>HIGH writes one on the MUX select line before PL_eFUSE writing.</p>

AES and User Key Parameters

The table below lists the AES and user key parameters.

Parameter Name	Description
XSK_BBRAM_AES_KEY	Default = XX. AES key (in HEX) that must be programmed into BBRAM.
XSK_BBRAM_AES_KEY_SIZE_IN_BITS	Default = 256. Size of AES key. Must be 256 bits.

UltraScale or UltraScale+ User-Configurable BBRAM PL Parameters

Following parameters need to be configured. Based on your inputs, BBRAM is programmed with the provided AES key.

AES Keys and Related Parameters

The following table shows AES key related parameters.

Parameter Name	Description
XSK_BBRAM_PGM_OBFUSCATED_KEY_SLR_CONFIG_ORDER_0	Default = FALSE By default, XSK_BBRAM_PGM_OBFUSCATED_KEY_SLR_CONFIG_ORDER_0 is FALSE. BBRAM is programmed with a non-obfuscated key provided in XSK_BBRAM_AES_KEY_SLR_CONFIG_ORDER_0 and DPA protection can be either in enabled/disabled state. TRUE programs the BBRAM with key provided in XSK_BBRAM_OBFUSCATED_KEY_SLR_CONFIG_ORDER_0 and DPA protection cannot be enabled.
XSK_BBRAM_PGM_OBFUSCATED_KEY_SLR_CONFIG_ORDER_1	Default = FALSE By default, XSK_BBRAM_PGM_OBFUSCATED_KEY_SLR_CONFIG_ORDER_1 is FALSE. BBRAM is programmed with a non-obfuscated key provided in XSK_BBRAM_AES_KEY_SLR_CONFIG_ORDER_1 and DPA protection can be either in enabled/disabled state. TRUE programs the BBRAM with key provided in XSK_BBRAM_OBFUSCATED_KEY_SLR_CONFIG_ORDER_1 and DPA protection cannot be enabled.

Parameter Name	Description
XSK_BBRAM_PGM_OBFUSCATED_KEY_SLR_CONFIG_ORDER_2	<p>Default = FALSE</p> <p>By default, XSK_BBRAM_PGM_OBFUSCATED_KEY_SLR_CONFIG_ORDER_2 is FALSE. BBRAM is programmed with a non-obfuscated key provided in XSK_BBRAM_AES_KEY_SLR_CONFIG_ORDER_2 and DPA protection can be either in enabled/disabled state. TRUE programs the BBRAM with key provided in XSK_BBRAM_OBFUSCATED_KEY_SLR_CONFIG_ORDER_2 and DPA protection cannot be enabled.</p>
XSK_BBRAM_PGM_OBFUSCATED_KEY_SLR_CONFIG_ORDER_3	<p>Default = FALSE</p> <p>By default, XSK_BBRAM_PGM_OBFUSCATED_KEY_SLR_CONFIG_ORDER_3 is FALSE. BBRAM is programmed with a non-obfuscated key provided in XSK_BBRAM_AES_KEY_SLR_CONFIG_ORDER_3 and DPA protection can be either in enabled/disabled state. TRUE programs the BBRAM with key provided in XSK_BBRAM_OBFUSCATED_KEY_SLR_CONFIG_ORDER_3 and DPA protection cannot be enabled.</p>
XSK_BBRAM_OBFUSCATED_KEY_SLR_CONFIG_ORDER_0	<p>Default = b1c276899d71fb4cdd4a0a7905ea46c2e11f9574d09c7ea23b70b67de713ccd1</p> <p>The value mentioned in this will be converted to hex buffer and the key is programmed into BBRAM, when program API is called. It should be 64 characters long, valid characters are 0-9,a-f,A-F. Any other character is considered as invalid string and will not program BBRAM.</p> <p>Note: For writing the OBFUSCATED Key, XSK_BBRAM_PGM_OBFUSCATED_KEY_</p> <p>SLR_CONFIG_ORDER_0 should have TRUE value.</p>
XSK_BBRAM_OBFUSCATED_KEY_SLR_CONFIG_ORDER_1	<p>Default = b1c276899d71fb4cdd4a0a7905ea46c2e11f9574d09c7ea23b70b67de713ccd1</p> <p>The value mentioned in this will be converted to hex buffer and the key is programmed into BBRAM, when program API is called. It should be 64 characters long, valid characters are 0-9,a-f,A-F. Any other character is considered as invalid string and will not program BBRAM.</p> <p>Note: For writing the OBFUSCATED Key, XSK_BBRAM_PGM_OBFUSCATED_KEY_</p> <p>SLR_CONFIG_ORDER_1 should have TRUE value.</p>

Parameter Name	Description
XSK_BBRAM_OBFUSCATED_KEY_SLR_CONFIG_ORDER_2	<p>Default = b1c276899d71fb4cdd4a0a7905ea46c2e11f9574d09c7ea23b70b67de713ccd1</p> <p>The value mentioned in this will be converted to hex buffer and the key is programmed into BBRAM, when program API is called. It should be 64 characters long, valid characters are 0-9,a-f,A-F. Any other character is considered as invalid string and will not program BBRAM.</p> <p>Note: For writing the OBFUSCATED Key, XSK_BBRAM_PGM_OBFUSCATED_KEY_</p> <p>SLR_CONFIG_ORDER_2 should have TRUE value.</p>
XSK_BBRAM_OBFUSCATED_KEY_SLR_CONFIG_ORDER_3	<p>Default = b1c276899d71fb4cdd4a0a7905ea46c2e11f9574d09c7ea23b70b67de713ccd1</p> <p>The value mentioned in this will be converted to hex buffer and the key is programmed into BBRAM, when program API is called. It should be 64 characters long, valid characters are 0-9,a-f,A-F. Any other character is considered as invalid string and will not program BBRAM.</p> <p>Note: For writing the OBFUSCATED Key, XSK_BBRAM_PGM_OBFUSCATED_KEY_</p> <p>SLR_CONFIG_ORDER_3 should have TRUE value.</p>
XSK_BBRAM_PGM_AES_KEY_SLR_CONFIG_ORDER_0	<p>Default = FALSE</p> <p>TRUE will program BBRAM with AES key provided in XSK_BBRAM_AES_KEY_SLR_CONFIG_ORDER_0</p>
XSK_BBRAM_PGM_AES_KEY_SLR_CONFIG_ORDER_1	<p>Default = FALSE</p> <p>TRUE will program BBRAM with AES key provided in XSK_BBRAM_AES_KEY_SLR_CONFIG_ORDER_1</p>
XSK_BBRAM_PGM_AES_KEY_SLR_CONFIG_ORDER_2	<p>Default = FALSE</p> <p>TRUE will program BBRAM with AES key provided in XSK_BBRAM_AES_KEY_SLR_CONFIG_ORDER_2</p>
XSK_BBRAM_PGM_AES_KEY_SLR_CONFIG_ORDER_3	<p>Default = FALSE</p> <p>TRUE will program BBRAM with AES key provided in XSK_BBRAM_AES_KEY_SLR_CONFIG_ORDER_3</p>

Parameter Name	Description
XSK_BBRAM_AES_KEY_SLR_CONFIG_ORDER_0	<p>Default = 0000000000000000524156a63950bcedafeadcdeabaadee34216615aaaabbbaa</p> <p>The value mentioned in this will be converted to hex buffer and the key is programmed into BBRAM,when program API is called. It should be 64 characters long, valid characters are 0-9,a-f,A-F. Any other character is considered as invalid string and will not program BBRAM.</p> <p>Note: For writing AES key, XSK_BBRAM_PGM_AES_KEY_SLR_CONFIG</p> <p>_ORDER_0 should have TRUE value , and XSK_BBRAM_PGM_OBFUSCATED_KEY_SLR</p> <p>_CONFIG_ORDER_0 should have FALSE value.</p>
XSK_BBRAM_AES_KEY_SLR_CONFIG_ORDER_1	<p>Default = 0000000000000000524156a63950bcedafeadcdeabaadee34216615aaaabbbaa</p> <p>The value mentioned in this will be converted to hex buffer and the key is programmed into BBRAM,when program API is called. It should be 64 characters long, valid characters are 0-9,a-f,A-F. Any other character is considered as invalid string and will not program BBRAM.</p> <p>Note: For writing AES key, XSK_BBRAM_PGM_AES_KEY_SLR_CONFIG</p> <p>_ORDER_1 should have TRUE value , and XSK_BBRAM_PGM_OBFUSCATED_KEY_SLR</p> <p>_CONFIG_ORDER_1 should have FALSE value</p>
XSK_BBRAM_AES_KEY_SLR_CONFIG_ORDER_2	<p>Default = 0000000000000000524156a63950bcedafeadcdeabaadee34216615aaaabbbaa</p> <p>The value mentioned in this will be converted to hex buffer and the key is programmed into BBRAM, when program API is called. It should be 64 characters long, valid characters are 0-9,a-f,A-F. Any other character is considered as invalid string and will not program BBRAM.</p> <p>Note: For writing AES key, XSK_BBRAM_PGM_AES_KEY_SLR_CONFIG</p> <p>_ORDER_2 should have TRUE value , and XSK_BBRAM_PGM_OBFUSCATED_KEY_SLR</p> <p>_CONFIG_ORDER_2 should have FALSE value</p>

Parameter Name	Description
XSK_BBRAM_AES_KEY_SLR_CONFIG_ORDER_3	<p>Default = 0000000000000000524156a63950bcedafeadcdeabaadee34216615aaaabbaaa</p> <p>The value mentioned in this will be converted to hex buffer and the key is programmed into BBRAM, when program API is called. It should be 64 characters long, valid characters are 0-9,a-f,A-F. Any other character is considered as invalid string and will not program BBRAM.</p> <p>Note: For writing AES key, XSK_BBRAM_PGM_AES_KEY_SLR_CONFIG_ORDER_3 should have TRUE value , and XSK_BBRAM_PGM_OBFUSCATED_KEY_SLR_CONFIG_ORDER_3 should have FALSE value</p>
XSK_BBRAM_AES_KEY_SIZE_IN_BITS	Default= 256 Size of AES key must be 256 bits.

DPA Protection for BBRAM key

The following table shows DPA protection configurable parameter

Parameter Name	Description
XSK_BBRAM_DPA_PROTECT_ENABLE	<p>Default = FALSE</p> <p>By default, the DPA protection will be in disabled state.</p> <p>TRUE will enable DPA protection with provided DPA count and configuration in XSK_BBRAM_DPA_COUNT and XSK_BBRAM_DPA_MODE respectively.</p> <p>DPA protection cannot be enabled if BBRAM is been programmed with an obfuscated key.</p>
XSK_BBRAM_DPA_COUNT	<p>Default = 0</p> <p>This input is valid only when DPA protection is enabled.</p> <p>Valid range of values are 1 - 255 when DPA protection is enabled else 0.</p>
XSK_BBRAM_DPA_MODE	<p>Default = XSK_BBRAM_INVALID_CONFIGURATIONS</p> <p>When DPA protection is enabled it can be XSK_BBRAM_INVALID_CONFIGURATIONS or XSK_BBRAM_ALL_CONFIGURATIONS If DPA protection is disabled this input provided over here is ignored.</p>

GPIO Device Used for Connecting PL Master JTAG Signals

In hardware design MASTER JTAG can be connected to any one of the available GPIO devices, based on the design the following parameter should be provided with corresponding device ID of selected GPIO device.

Master JTAG Signal	Description
XSK_BBRAM_AXI_GPIO_DEVICE_ID	Default = XPAR_AXI_GPIO_0_DEVICE_ID This is for providing exact GPIO device ID, based on the design configuration this parameter can be modified to provide GPIO device ID which is used for connecting master jtag pins.

GPIO Pins Used for PL Master JTAG Signals

In Ultrascale the following GPIO pins are used for connecting MASTER_JTAG pins to access BBRAM. These can be changed depending on your hardware. The table below shows the GPIO pins used for PL MASTER JTAG signals.

Master JTAG Signal	Default PIN Number
XSK_BBRAM_AXI_GPIO_JTAG_TDO	0
XSK_BBRAM_AXI_GPIO_JTAG_TDI	0
XSK_BBRAM_AXI_GPIO_JTAG_TMS	1
XSK_BBRAM_AXI_GPIO_JTAG_TCK	2

GPIO Channels

The following table shows GPIO channel number.

Parameter	Default Channel Number	Master JTAG Signal Connected
XSK_BBRAM_GPIO_INPUT_CH	2	TDO
XSK_BBRAM_GPIO_OUTPUT_CH	1	TDI, TMS, TCK

Note: All inputs and outputs of GPIO should be configured in single channel. For example, XSK_BBRAM_GPIO_INPUT_CH = XSK_BBRAM_GPIO_OUTPUT_CH = 1 or 2. Among (TDI, TCK, TMS) Outputs of GPIO cannot be connected to different GPIO channels all the 3 signals should be in same channel. TDO can be a other channel of (TDI, TCK, TMS) or the same. DPA protection can be enabled only when programming non-obfuscated key.

UltraScale or UltraScale+ User-Configurable PL eFUSE Parameters

The table below lists the user-configurable PL eFUSE parameters for UltraScale devices.

Macro Name	Description
XSK_EFUSEPL_DISABLE_AES_KEY_READ	Default = FALSE TRUE will permanently disable the write to FUSE_AES and check CRC for AES key by programming control bit of FUSE. FALSE will not modify this control bit of eFuse.
XSK_EFUSEPL_DISABLE_USER_KEY_READ	Default = FALSE TRUE will permanently disable the write to 32 bit FUSE_USER and read of FUSE_USER key by programming control bit of FUSE. FALSE will not modify this control bit of eFuse.
XSK_EFUSEPL_DISABLE_SECURE_READ	Default = FALSE TRUE will permanently disable the write to FUSE_Secure block and reading of secure block by programming control bit of FUSE. FALSE will not modify this control bit of eFuse.
XSK_EFUSEPL_DISABLE_FUSE_CNTRL_WRITE	Default = FALSE. TRUE will permanently disable the write to FUSE_CNTRL block by programming control bit of FUSE. FALSE will not modify this control bit of eFuse.
XSK_EFUSEPL_DISABLE_RSA_KEY_READ	Default = FALSE. TRUE will permanently disable the write to FUSE_RSA block and reading of FUSE_RSA Hash by programming control bit of FUSE. FALSE will not modify this control bit of eFuse.
XSK_EFUSEPL_DISABLE_KEY_WRITE	Default = FALSE. TRUE will permanently disable the write to FUSE_AES block by programming control bit of FUSE. FALSE will not modify this control bit of eFuse.
XSK_EFUSEPL_DISABLE_USER_KEY_WRITE	Default = FALSE. TRUE will permanently disable the write to FUSE_USER block by programming control bit of FUSE. FALSE will not modify this control bit of eFuse.
XSK_EFUSEPL_DISABLE_SECURE_WRITE	Default = FALSE. TRUE will permanently disable the write to FUSE_SECURE block by programming control bit of FUSE. FALSE will not modify this control bit of eFuse.
XSK_EFUSEPL_DISABLE_RSA_HASH_WRITE	Default = FALSE. TRUE will permanently disable the write to FUSE_RSA authentication key by programming control bit of FUSE. FALSE will not modify this control bit of eFuse.
XSK_EFUSEPL_DISABLE_128BIT_USER_KEY_WRITE	Default = FALSE. TRUE will permanently disable the write to 128 bit FUSE_USER by programming control bit of FUSE. FALSE will not modify this control bit of eFuse.
XSK_EFUSEPL_ALLOW_ENCRYPTED_ONLY	Default = FALSE. TRUE will permanently allow encrypted bitstream only. FALSE will not modify this Secure bit of eFuse.

Macro Name	Description
XSK_EFUSEPL_FORCE_USE_FUSE_AES_ONLY	Default = FALSE. TRUE then allows only FUSE's AES key as source of encryption FALSE then allows FPGA to configure an unencrypted bitstream or bitstream encrypted using key stored BBRAM or eFuse.
XSK_EFUSEPL_ENABLE_RSA_AUTH	Default = FALSE. TRUE will enable RSA authentication of bitstream FALSE will not modify this secure bit of eFuse.
XSK_EFUSEPL_DISABLE_JTAG_CHAIN	Default = FALSE. TRUE will disable JTAG permanently. FALSE will not modify this secure bit of eFuse.
XSK_EFUSEPL_DISABLE_TEST_ACCESS	Default = FALSE. TRUE will disables Xilinx test access. FALSE will not modify this secure bit of eFuse.
XSK_EFUSEPL_DISABLE_AES_DECRYPTOR	Default = FALSE. TRUE will disables decoder completely. FALSE will not modify this secure bit of eFuse.
XSK_EFUSEPL_ENABLE_OBFUSCATION_EFUSEAES	Default = FALSE. TRUE will enable obfuscation feature for eFUSE AES key.

GPIO Device Used for Connecting PL Master JTAG Signals

In hardware design MASTER JTAG can be connected to any one of the available GPIO devices, based on the design the following parameter should be provided with corresponding device ID of selected GPIO device.

Master JTAG Signal	Description
XSK_EFUSEPL_AXI_GPIO_DEVICE_ID	Default = XPAR_AXI_GPIO_0_DEVICE_ID This is for providing exact GPIO device ID, based on the design configuration this parameter can be modified to provide GPIO device ID which is used for connecting master jtag pins.

GPIO Pins Used for PL Master JTAG and HWM Signals

In Ultrascale the following GPIO pins are used for connecting MASTER_JTAG pins to access eFUSE. These can be changed depending on your hardware. The table below shows the GPIO pins used for PL MASTER JTAG signals.

Master JTAG Signal	Default PIN Number
XSK_EFUSEPL_AXI_GPIO_JTAG_TDO	0
XSK_EFUSEPL_AXI_GPIO_HWM_READY	0
XSK_EFUSEPL_AXI_GPIO_HWM_END	1
XSK_EFUSEPL_AXI_GPIO_JTAG_TDI	2

Master JTAG Signal	Default PIN Number
XSK_EFUSEPL_AXI_GPIO_JTAG_TMS	1
XSK_EFUSEPL_AXI_GPIO_JTAG_TCK	2
XSK_EFUSEPL_AXI_GPIO_HWM_START	3

GPIO Channels

The following table shows GPIO channel number.

Parameter	Default Channel Number	Master JTAG Signal Connected
XSK_EFUSEPL_GPIO_INPUT_CH	2	TDO
XSK_EFUSEPL_GPIO_OUTPUT_CH	1	TDI, TMS, TCK

Note: All inputs and outputs of GPIO should be configured in single channel. For example, XSK_EFUSEPL_GPIO_INPUT_CH = XSK_EFUSEPL_GPIO_OUTPUT_CH = 1 or 2. Among (TDI, TCK, TMS) Outputs of GPIO cannot be connected to different GPIO channels all the 3 signals should be in same channel. TDO can be a other channel of (TDI, TCK, TMS) or the same.

SLR Selection to Program eFUSE on MONO/SSIT Devices

The following table shows parameters for programming different SLRs.

Parameter Name	Description
XSK_EFUSEPL_PGM_SLR_CONFIG_ORDER_0	Default = FALSE TRUE will enable programming SLR config order 0's eFUSE. FALSE will disable programming.
XSK_EFUSEPL_PGM_SLR_CONFIG_ORDER_1	Default = FALSE TRUE will enable programming SLR config order 1's eFUSE. FALSE will disable programming.
XSK_EFUSEPL_PGM_SLR_CONFIG_ORDER_2	Default = FALSE TRUE will enable programming SLR config order 2's eFUSE. FALSE will disable programming.
XSK_EFUSEPL_PGM_SLR_CONFIG_ORDER_3	Default = FALSE TRUE will enable programming SLR config order 3's eFUSE. FALSE will disable programming.

eFUSE PL Read Parameters

The following table shows parameters related to read USER 32/128bit keys and RSA hash.

By enabling any of the below parameters, by default will read corresponding hash/key associated with all the available SLRs. For example, if XSK_EFUSEPL_READ_USER_KEY is TRUE, USER key for all the available SLRs will be read.

Note: For only reading keys it is not required to enable XSK_EFUSEPL_PGM_SLR1, XSK_EFUSEPL_PGM_SLR2, XSK_EFUSEPL_PGM_SLR3, XSK_EFUSEPL_PGM_SLR4 macros, they can be in FALSE state.

Parameter Name	Description
XSK_EFUSEPL_READ_USER_KEY	Default = FALSE TRUE will read 32 bit FUSE_USER from eFUSE of all available SLRs and each time updates in XiISKey_EPI instance parameter UserKeyReadback, which will be displayed on UART by example before reading next SLR. FALSE 32-bit FUSE_USER key read will not be performed.
XSK_EFUSEPL_READ_RSA_KEY_HASH	Default = FALSE TRUE will read FUSE_USER from eFUSE of all available SLRs and each time updates in XiISKey_EPI instance parameter RSAHashReadback, which will be displayed on UART by example before reading next SLR. FALSE FUSE_RSA_HASH read will not be performed.
XSK_EFUSEPL_READ_USER_KEY128_BIT	Default = FALSE TRUE will read 128 bit USER key eFUSE of all available SLRs and each time updates in XiISKey_EPI instance parameter User128BitReadBack, which will be displayed on UART by example before reading next SLR. FALSE 128 bit USER key read will not be performed.

AES Keys and Related Parameters

Note: For programming AES key for MONO/SSIT device, the corresponding SLR should be selected and AES key programming should be enabled.

USER Keys (32-bit) and Related Parameters

Note: For programming USER key for MONO/SSIT device, the corresponding SLR should be selected and USER key programming should be enabled.

RSA Hash and Related Parameters

Note: For programming RSA hash for MONO/SSIT device, the corresponding SLR should be selected and RSA hash programming should be enabled.

USER Keys (128-bit) and Related Parameters

Note: For programming USER key 128 bit for MONO/SSIT device, the corresponding SLR and programming for USER key 128 bit should be enabled.

AES key CRC verification

You cannot read the AES key. You can verify only by providing the CRC of the expected AES key. The following lists the parameters that may help you in verifying the AES key:

Parameter Name	Description
XSK_EFUSEPL_CHECK_AES_KEY_CRC	<p>Default = FALSE</p> <p>TRUE will perform CRC check of FUSE_AES with provided CRC value in macro XSK_EFUSEPL_CRC_OF_EXPECTED_AES_KEY. And result of CRC check will be updated in XiLSKey_EPI instance parameter AESKeyMatched with either TRUE or FALSE. FALSE CRC check of FUSE_AES will not be performed.</p>
XSK_EFUSEPL_CRC_OF_EXPECTED_AES_KEY_CONFIG_ORDER_0	<p>Default = XSK_EFUSEPL_AES_CRC_OF_ALL_ZEROS</p> <p>CRC value of FUSE_AES with all Zeros. Expected FUSE_AES key's CRC value of SLR config order 0 has to be updated in place of XSK_EFUSEPL_AES_CRC_OF_ALL_ZEROS. For Checking CRC of FUSE_AES XSK_EFUSEPL_CHECK_AES_KEY_ULTRA macro should be TRUE otherwise CRC check will not be performed. For calculation of AES key's CRC one can use u32 XiLSKey_CrcCalculation(u8_Key) API.</p> <p>For UltraScale, the value of XSK_EFUSEPL_AES_CRC_OF_ALL_ZEROS is 0x621C42AA(XSK_EFUSEPL_CRC_OF_EXPECTED_AES_KEY_CONFIG_ORDER_0).</p> <p>For UltraScale+, the value of XSK_EFUSEPL_AES_CRC_OF_ALL_ZEROS is 0x3117503A(XSK_EFUSEPL_CRC_OF_EXPECTED_AES_KEY_CONFIG_ORDER_0).</p>
XSK_EFUSEPL_CRC_OF_EXPECTED_AES_KEY_CONFIG_ORDER_1	<p>Default = XSK_EFUSEPL_AES_CRC_OF_ALL_ZEROS</p> <p>CRC value of FUSE_AES with all Zeros. Expected FUSE_AES key's CRC value of SLR config order 1 has to be updated in place of XSK_EFUSEPL_AES_CRC_OF_ALL_ZEROS. For Checking CRC of FUSE_AES XSK_EFUSEPL_CHECK_AES_KEY_ULTRA macro should be TRUE otherwise CRC check will not be performed. For calculation of AES key's CRC one can use u32 XiLSKey_CrcCalculation(u8_Key) API.</p> <p>For UltraScale, the value of XSK_EFUSEPL_AES_CRC_OF_ALL_ZEROS is 0x621C42AA(XSK_EFUSEPL_CRC_OF_EXPECTED_AES_KEY_CONFIG_ORDER_1).</p> <p>For UltraScale+, the value of XSK_EFUSEPL_AES_CRC_OF_ALL_ZEROS is 0x3117503A(XSK_EFUSEPL_CRC_OF_EXPECTED_AES_KEY_CONFIG_ORDER_1).</p>

Parameter Name	Description
XSK_EFUSEPL_CRC_OF_EXPECTED_AES_KEY_CONFIG_ORDER_2	<p>Default = XSK_EFUSEPL_AES_CRC_OF_ALL_ZEROS</p> <p>CRC value of FUSE_AES with all Zeros. Expected FUSE_AES key's CRC value of SLR config order 2 has to be updated in place of XSK_EFUSEPL_AES_CRC_OF_ALL_ZEROS. For Checking CRC of FUSE_AES XSK_EFUSEPL_CHECK_AES_KEY_ULTRA macro should be TRUE otherwise CRC check will not be performed. For calculation of AES key's CRC one can use u32 XilSKey_CrcCalculation(u8_Key) API.</p> <p>For UltraScale, the value of XSK_EFUSEPL_AES_CRC_OF_ALL_ZEROS is 0x621C42AA(XSK_EFUSEPL_CRC_OF_EXPECTED_AES_KEY_CONFIG_ORDER_2).</p> <p>For UltraScale+, the value of XSK_EFUSEPL_AES_CRC_OF_ALL_ZEROS is 0x3117503A(XSK_EFUSEPL_CRC_OF_EXPECTED_AES_KEY_CONFIG_ORDER_2_ULTRA_PLUS)</p>
XSK_EFUSEPL_CRC_OF_EXPECTED_AES_KEY_CONFIG_ORDER_3	<p>Default = XSK_EFUSEPL_AES_CRC_OF_ALL_ZEROS</p> <p>CRC value of FUSE_AES with all Zeros. Expected FUSE_AES key's CRC value of SLR config order 3 has to be updated in place of XSK_EFUSEPL_AES_CRC_OF_ALL_ZEROS. For Checking CRC of FUSE_AES XSK_EFUSEPL_CHECK_AES_KEY_ULTRA macro should be TRUE otherwise CRC check will not be performed. For calculation of AES key's CRC one can use u32 XilSKey_CrcCalculation(u8_Key) API.</p> <p>For UltraScale, the value of XSK_EFUSEPL_AES_CRC_OF_ALL_ZEROS is 0x621C42AA(XSK_EFUSEPL_CRC_OF_EXPECTED_AES_KEY_CONFIG_ORDER_3).</p> <p>For UltraScale+, the value of XSK_EFUSEPL_AES_CRC_OF_ALL_ZEROS is 0x3117503A(XSK_EFUSEPL_CRC_OF_EXPECTED_AES_KEY_CONFIG_ORDER_3_ULTRA_PLUS)</p>

Zynq UltraScale+ MPSoC User-Configurable PS eFUSE Parameters

The table below lists the user-configurable PS eFUSE parameters for Zynq UltraScale+ MPSoC devices.

Macro Name	Description
XSK_EFUSEPS_AES_RD_LOCK	<p>Default = FALSE</p> <p>TRUE will permanently disable the CRC check of FUSE_AES. FALSE will not modify this control bit of eFuse.</p>

Macro Name	Description
XSK_EFUSEPS_AES_WR_LOCK	Default = FALSE TRUE will permanently disable the writing to FUSE_AES block. FALSE will not modify this control bit of eFuse.
XSK_EFUSEPS_ENC_ONLY	Default = FALSE TRUE will permanently enable encrypted booting only using the Fuse key. FALSE will not modify this control bit of eFuse.
XSK_EFUSEPS_BBRAM_DISABLE	Default = FALSE TRUE will permanently disable the BBRAM key. FALSE will not modify this control bit of eFuse.
XSK_EFUSEPS_ERR_DISABLE	Default = FALSE TRUE will permanently disables the error messages in JTAG status register. FALSE will not modify this control bit of eFuse.
XSK_EFUSEPS_JTAG_DISABLE	Default = FALSE TRUE will permanently disable JTAG controller. FALSE will not modify this control bit of eFuse.
XSK_EFUSEPS_DFT_DISABLE	Default = FALSE TRUE will permanently disable DFT boot mode. FALSE will not modify this control bit of eFuse.
XSK_EFUSEPS_PROG_GATE_DISABLE	Default = FALSE TRUE will permanently disable PROG_GATE feature in PPD. FALSE will not modify this control bit of eFuse.
XSK_EFUSEPS_SECURE_LOCK	Default = FALSE TRUE will permanently disable reboot into JTAG mode when doing a secure lockdown. FALSE will not modify this control bit of eFuse.
XSK_EFUSEPS_RSA_ENABLE	Default = FALSE TRUE will permanently enable RSA authentication during boot. FALSE will not modify this control bit of eFuse.
XSK_EFUSEPS_PPK0_WR_LOCK	Default = FALSE TRUE will permanently disable writing to PPK0 efuses. FALSE will not modify this control bit of eFuse.
XSK_EFUSEPS_PPK0_INVLD	Default = FALSE TRUE will permanently revoke PPK0. FALSE will not modify this control bit of eFuse.
XSK_EFUSEPS_PPK1_WR_LOCK	Default = FALSE TRUE will permanently disable writing PPK1 efuses. FALSE will not modify this control bit of eFuse.
XSK_EFUSEPS_PPK1_INVLD	Default = FALSE TRUE will permanently revoke PPK1. FALSE will not modify this control bit of eFuse.
XSK_EFUSEPS_USER_WRLK_0	Default = FALSE TRUE will permanently disable writing to USER_0 efuses. FALSE will not modify this control bit of eFuse.
XSK_EFUSEPS_USER_WRLK_1	Default = FALSE TRUE will permanently disable writing to USER_1 efuses. FALSE will not modify this control bit of eFuse.

Macro Name	Description
XSK_EFUSEPS_USER_WRLK_2	Default = FALSE TRUE will permanently disable writing to USER_2 efuses. FALSE will not modify this control bit of eFuse.
XSK_EFUSEPS_USER_WRLK_3	Default = FALSE TRUE will permanently disable writing to USER_3 efuses. FALSE will not modify this control bit of eFuse.
XSK_EFUSEPS_USER_WRLK_4	Default = FALSE TRUE will permanently disable writing to USER_4 efuses. FALSE will not modify this control bit of eFuse.
XSK_EFUSEPS_USER_WRLK_5	Default = FALSE TRUE will permanently disable writing to USER_5 efuses. FALSE will not modify this control bit of eFuse.
XSK_EFUSEPS_USER_WRLK_6	Default = FALSE TRUE will permanently disable writing to USER_6 efuses. FALSE will not modify this control bit of eFuse.
XSK_EFUSEPS_USER_WRLK_7	Default = FALSE TRUE will permanently disable writing to USER_7 efuses. FALSE will not modify this control bit of eFuse.
XSK_EFUSEPS_LBIST_EN	Default = FALSE TRUE will permanently enables logic BIST to be run during boot. FALSE will not modify this control bit of eFUSE.
XSK_EFUSEPS_LPD_SC_EN	Default = FALSE TRUE will permanently enables zeroization of registers in Low Power Domain(LPD) during boot. FALSE will not modify this control bit of eFUSE.
XSK_EFUSEPS_FPD_SC_EN	Default = FALSE TRUE will permanently enables zeroization of registers in Full Power Domain(FPD) during boot. FALSE will not modify this control bit of eFUSE.
XSK_EFUSEPS_PBR_BOOT_ERR	Default = FALSE TRUE will permanently enables the boot halt when there is any PMU error. FALSE will not modify this control bit of eFUSE.

AES Keys and Related Parameters

The following table shows AES key related parameters.

Parameter Name	Description
XSK_EFUSEPS_WRITE_AES_KEY	Default = FALSE TRUE will burn the AES key provided in XSK_EFUSEPS_AES_KEY. FALSE will ignore the key provide XSK_EFUSEPS_AES_KEY.

Parameter Name	Description
XSK_EFUSEPS_AES_KEY	<p>Default = 00 00000000000000</p> <p>The value mentioned in this will be converted to hex buffer and written into the Zynq UltraScale+ MPSoC PS eFUSE array when write API used. This value should be given in string format. It should be 64 characters long, valid characters are 0-9,a-f,A-F. Any other character is considered as invalid string and will not burn AES Key.</p> <p>Note: For writing the AES Key, XSK_EFUSEPS_WRITE_AES_KEY should have TRUE value.</p>
XSK_EFUSEPS_CHECK_AES_KEY_CRC	<p>Default value is FALSE. TRUE will check the CRC provided in XSK_EFUSEPS_AES_KEY. CRC verification is done after programming AES key to verify the key is programmed properly or not, if not library error outs the same. So While programming AES key it is not necessary to verify the AES key again.</p> <p>Note: Please make sure if intention is to check only CRC of the provided key and not programming AES key then do not modify XSK_EFUSEPS_WRITE_AES_</p> <p>KEY (TRUE will Program key).</p>

User Keys and Related Parameters

Single bit programming is allowed for all the user eFUSEs. When you request to revert already programmed bit, the library will return an error. Also, if the user eFUSEs is non-zero, the library will not throw an error for valid requests. The following table shows the user keys and related parameters.

Parameter Name	Description
XSK_EFUSEPS_WRITE_USER0_FUSE	Default = FALSE TRUE will burn User0 Fuse provided in XSK_EFUSEPS_USER0_FUSES. FALSE will ignore the value provided in XSK_EFUSEPS_USER0_FUSES
XSK_EFUSEPS_WRITE_USER1_FUSE	Default = FALSE TRUE will burn User1 Fuse provided in XSK_EFUSEPS_USER1_FUSES. FALSE will ignore the value provided in XSK_EFUSEPS_USER1_FUSES
XSK_EFUSEPS_WRITE_USER2_FUSE	Default = FALSE TRUE will burn User2 Fuse provided in XSK_EFUSEPS_USER2_FUSES. FALSE will ignore the value provided in XSK_EFUSEPS_USER2_FUSES
XSK_EFUSEPS_WRITE_USER3_FUSE	Default = FALSE TRUE will burn User3 Fuse provided in XSK_EFUSEPS_USER3_FUSES. FALSE will ignore the value provided in XSK_EFUSEPS_USER3_FUSES

Parameter Name	Description
XSK_EFUSEPS_WRITE_USER4_FUSE	<p>Default = FALSE</p> <p>TRUE will burn User4 Fuse provided in XSK_EFUSEPS_USER4_FUSES. FALSE will ignore the value provided in XSK_EFUSEPS_USER4_FUSES</p>
XSK_EFUSEPS_WRITE_USER5_FUSE	<p>Default = FALSE</p> <p>TRUE will burn User5 Fuse provided in XSK_EFUSEPS_USER5_FUSES. FALSE will ignore the value provided in XSK_EFUSEPS_USER5_FUSES</p>
XSK_EFUSEPS_WRITE_USER6_FUSE	<p>Default = FALSE</p> <p>TRUE will burn User6 Fuse provided in XSK_EFUSEPS_USER6_FUSES. FALSE will ignore the value provided in XSK_EFUSEPS_USER6_FUSES</p>
XSK_EFUSEPS_WRITE_USER7_FUSE	<p>Default = FALSE</p> <p>TRUE will burn User7 Fuse provided in XSK_EFUSEPS_USER7_FUSES. FALSE will ignore the value provided in XSK_EFUSEPS_USER7_FUSES</p>
XSK_EFUSEPS_USER0_FUSES	<p>Default = 00000000</p> <p>The value mentioned in this will be converted to hex buffer and written into the Zynq UltraScale+ MPSoC PS eFUSE array when write API used. This value should be given in string format. It should be 8 characters long, valid characters are 0-9,a-f,A-F. Any other character is considered as invalid string and will not burn SPK ID.</p> <p>Note: For writing the User0 Fuse, XSK_EFUSEPS_WRITE_USER0_FUSE should have TRUE value</p>
XSK_EFUSEPS_USER1_FUSES	<p>Default = 00000000</p> <p>The value mentioned in this will be converted to hex buffer and written into the Zynq UltraScale+ MPSoC PS eFUSE array when write API used. This value should be given in string format. It should be 8 characters long, valid characters are 0-9,a-f,A-F. Any other character is considered as invalid string and will not burn SPK ID.</p> <p>Note: For writing the User1 Fuse, XSK_EFUSEPS_WRITE_USER1_FUSE should have TRUE value</p>
XSK_EFUSEPS_USER2_FUSES	<p>Default = 00000000</p> <p>The value mentioned in this will be converted to hex buffer and written into the Zynq UltraScale+ MPSoC PS eFUSE array when write API used. This value should be given in string format. It should be 8 characters long, valid characters are 0-9,a-f,A-F. Any other character is considered as invalid string and will not burn SPK ID.</p> <p>Note: For writing the User2 Fuse, XSK_EFUSEPS_WRITE_USER2_FUSE should have TRUE value</p>

Parameter Name	Description
XSK_EFUSEPS_USER3_FUSES	<p>Default = 00000000</p> <p>The value mentioned in this will be converted to hex buffer and written into the Zynq UltraScale+ MPSoC PS eFUSE array when write API used. This value should be given in string format. It should be 8 characters long, valid characters are 0-9,a-f,A-F. Any other character is considered as invalid string and will not burn SPK ID.</p> <p>Note: For writing the User3 Fuse, XSK_EFUSEPS_WRITE_USER3_FUSE should have TRUE value</p>
XSK_EFUSEPS_USER4_FUSES	<p>Default = 00000000</p> <p>The value mentioned in this will be converted to hex buffer and written into the Zynq UltraScale+ MPSoC PS eFUSE array when write API used. This value should be given in string format. It should be 8 characters long, valid characters are 0-9,a-f,A-F. Any other character is considered as invalid string and will not burn SPK ID.</p> <p>Note: For writing the User4 Fuse, XSK_EFUSEPS_WRITE_USER4_FUSE should have TRUE value</p>
XSK_EFUSEPS_USER5_FUSES	<p>Default = 00000000</p> <p>The value mentioned in this will be converted to hex buffer and written into the Zynq UltraScale+ MPSoC PS eFUSE array when write API used. This value should be given in string format. It should be 8 characters long, valid characters are 0-9,a-f,A-F. Any other character is considered as invalid string and will not burn SPK ID.</p> <p>Note: For writing the User5 Fuse, XSK_EFUSEPS_WRITE_USER5_FUSE should have TRUE value</p>
XSK_EFUSEPS_USER6_FUSES	<p>Default = 00000000</p> <p>The value mentioned in this will be converted to hex buffer and written into the Zynq UltraScale+ MPSoC PS eFUSE array when write API used. This value should be given in string format. It should be 8 characters long, valid characters are 0-9,a-f,A-F. Any other character is considered as invalid string and will not burn SPK ID.</p> <p>Note: For writing the User6 Fuse, XSK_EFUSEPS_WRITE_USER6_FUSE should have TRUE value</p>
XSK_EFUSEPS_USER7_FUSES	<p>Default = 00000000</p> <p>The value mentioned in this will be converted to hex buffer and written into the Zynq UltraScale+ MPSoC PS eFUSE array when write API used. This value should be given in string format. It should be 8 characters long, valid characters are 0-9,a-f,A-F. Any other character is considered as invalid string and will not burn SPK ID.</p> <p>Note: For writing the User7 Fuse, XSK_EFUSEPS_WRITE_USER7_FUSE should have TRUE value</p>

PPK0 Keys and Related Parameters

The following table shows the PPK0 keys and related parameters.

[illegible]

PPK1 Keys and Related Parameters

The following table shows the PPK1 keys and related parameters.

Parameter Name	Description
XSK_EFUSEPS_WRITE_PPK1_SHA3_HASH	Default = FALSE TRUE will burn PPK1 sha3 hash provided in XSK_EFUSEPS_PPK1_SHA3_HASH. FALSE will ignore the hash provided in XSK_EFUSEPS_PPK1_SHA3_HASH.
XSK_EFUSEPS_PPK1_IS_SHA3	Default = TRUE TRUE XSK_EFUSEPS_PPK1_SHA3_HASH should be of string length 96 it specifies that PPK1 is used to program SHA3 hash. FALSE XSK_EFUSEPS_PPK1_SHA3_HASH should be of string length 64 it specifies that PPK1 is used to program SHA2 hash.

Parameter Name	Description
XSK_EFUSEPS_PPK1_HASH	Default = 000 The value mentioned in this will be converted to hex buffer and written into the Zynq UltraScale + MPSoC PS eFUSE array when write API used. This value should be given in string format. It should be 64 or 96 characters long, valid characters are 0-9,a-f,A-F. Any other character is considered as invalid string and will not burn PPK1 hash. Note that,for writing the PPK1 hash, XSK_EFUSEPS_WRITE_PPK1_SHA3_HASH should have TRUE value. By default, PPK1 hash will be provided with 64 character length to program PPK1 hash with sha2 hash so XSK_EFUSEPS_PPK1_IS_SHA3 also will be in FALSE state. But to program PPK1 hash with SHA3 hash make XSK_EFUSEPS_PPK1_IS_SHA3 to TRUE and provide sha3 hash of length 96 characters XSK_EFUSEPS_PPK1_HASH so that one can program sha3 hash.

SPK ID and Related Parameters

The following table shows the SPK ID and related parameters.

Parameter Name	Description
XSK_EFUSEPS_WRITE_SPKID	<p>Default = FALSE</p> <p>TRUE will burn SPKID provided in XSK_EFUSEPS_SPK_ID. FALSE will ignore the hash provided in XSK_EFUSEPS_SPK_ID.</p>
XSK_EFUSEPS_SPK_ID	<p>Default = 00000000</p> <p>The value mentioned in this will be converted to hex buffer and written into the Zynq UltraScale+ MPSoC PS eFUSE array when write API used. This value should be given in string format. It should be 8 characters long, valid characters are 0-9,a-f,A-F. Any other character is considered as invalid string and will not burn SPK ID.</p> <p>Note: For writing the SPK ID, XSK_EFUSEPS_WRITE_SPKID should have TRUE value.</p>

Note: PPK hash should be unmodified hash generated by bootgen. Single bit programming is allowed for User FUSES (0 to 7), if you specify a value that tries to set a bit that was previously programmed to 1 back to 0, you will get an error. you have to provide already programmed bits also along with new requests.

Zynq UltraScale+ MPSoC User-Configurable PS BBRAM Parameters

The table below lists the AES and user key parameters.

Parameter Name	Description
XSK_ZYNQMP_BBRAMPS_AES_KEY	Default = 00 0000000000000000 AES key (in HEX) that must be programmed into BBRAM.
XSK_ZYNQMP_BBRAMPS_AES_KEY_LEN_IN_BYTES	Default = 32. Length of AES key in bytes.
XSK_ZYNQMP_BBRAMPS_AES_KEY_LEN_IN_BITS	Default = 256. Length of AES key in bits.
XSK_ZYNQMP_BBRAMPS_AES_KEY_STR_LEN	Default = 64. String length of the AES key.

Zynq UltraScale+ MPSoC User-Configurable PS PUF Parameters

The table below lists the user-configurable PS PUF parameters for Zynq UltraScale+ MPSoC devices.

Macro Name	Description
XSK_PUF_INFO_ON_UART	Default = FALSE TRUE will display syndrome data on UART com port FALSE will display any data on UART com port.
XSK_PUF_PROGRAM_EFUSE	Default = FALSE TRUE will program the generated syndrome data, CHash and Auxilary values, Black key. FALSE will not program data into eFUSE.
XSK_PUF_IF_CONTRACT_MANUFACTURER	Default = FALSE This should be enabled when application is hand over to contract manufacturer. TRUE will allow only authenticated application. FALSE authentication is not mandatory.
XSK_PUF_REG_MODE	Default = XSK_PUF_MODE4K PUF registration is performed in 4K mode. For only understanding it is provided in this file, but user is not supposed to modify this.
XSK_PUF_READ_SECUREBITS	Default = FALSE TRUE will read status of the puf secure bits from eFUSE and will be displayed on UART. FALSE will not read secure bits.
XSK_PUF_PROGRAM_SECUREBITS	Default = FALSE TRUE will program PUF secure bits based on the user input provided at XSK_PUF_SYN_INVALID, XSK_PUF_SYN_WRLK and XSK_PUF_REGISTER_DISABLE. FALSE will not program any PUF secure bits.

Error Codes

The application error code is 32 bits long. For example, if the error code for PS is 0x8A05:

- 0x8A indicates that a write error has occurred while writing RSA Authentication bit.
- 0x05 indicates that write error is due to the write temperature out of range.

Applications have the following options on how to show error status. Both of these methods of conveying the status are implemented by default. However, UART is required to be present and initialized for status to be displayed through UART.

- Send the error code through UART pins
- Write the error code in the reboot status register

PL eFUSE Error Codes

Enumerations

Enumeration XSKEfusePI_ErrorCodes

Table 54: Enumeration XSKEfusePI_ErrorCodes Values

Value	Description
XSK_EFUSEPL_ERROR_NONE	0 No error.
XSK_EFUSEPL_ERROR_ROW_NOT_ZERO	0x10 Row is not zero.
XSK_EFUSEPL_ERROR_READ_ROW_OUT_OF_RANGE	0x11 Read Row is out of range.
XSK_EFUSEPL_ERROR_READ_MARGIN_OUT_OF_RANGE	0x12 Read Margin is out of range.
XSK_EFUSEPL_ERROR_READ_BUFFER_NULL	0x13 No buffer for read.
XSK_EFUSEPL_ERROR_READ_BIT_VALUE_NOT_SET	0x14 Read bit not set.
XSK_EFUSEPL_ERROR_READ_BIT_OUT_OF_RANGE	0x15 Read bit is out of range.
XSK_EFUSEPL_ERROR_READ_TEMPERATURE_OUT_OF_RANGE	0x16 Temperature obtained from XADC is out of range to read.

Table 54: Enumeration XSKEfusePl_ErrorCodes Values (cont'd)

Value	Description
XSK_EFUSEPL_ERROR_READ_VCCAUX_VOLTAGE_OUT_OF_RANGE	0x17 VCCAUX obtained from XADC is out of range to read.
XSK_EFUSEPL_ERROR_READ_VCCINT_VOLTAGE_OUT_OF_RANGE	0x18 VCCINT obtained from XADC is out of range to read.
XSK_EFUSEPL_ERROR_WRITE_ROW_OUT_OF_RANGE	0x19 To write row is out of range.
XSK_EFUSEPL_ERROR_WRITE_BIT_OUT_OF_RANGE	0x1A To read bit is out of range.
XSK_EFUSEPL_ERROR_WRITE_TEMPERATURE_OUT_OF_RANGE	0x1B To eFUSE write Temperature obtained from XADC is out of range.
XSK_EFUSEPL_ERROR_WRITE_VCCAUX_VOLTAGE_OUT_OF_RANGE	0x1C To write eFUSE VCCAUX obtained from XADC is out of range.
XSK_EFUSEPL_ERROR_WRITE_VCCINT_VOLTAGE_OUT_OF_RANGE	0x1D To write into eFUSE VCCINT obtained from XADC is out of range.
XSK_EFUSEPL_ERROR_FUSE_CNTRL_WRITE_DISABLED	0x1E Fuse control write is disabled.
XSK_EFUSEPL_ERROR_CNTRL_WRITE_BUFFER_NULL	0x1F Buffer pointer that is supposed to contain control data is null.
XSK_EFUSEPL_ERROR_NOT_VALID_KEY_LENGTH	0x20 Key length invalid.
XSK_EFUSEPL_ERROR_ZERO_KEY_LENGTH	0x21 Key length zero.
XSK_EFUSEPL_ERROR_NOT_VALID_KEY_CHAR	0x22 Invalid key characters.
XSK_EFUSEPL_ERROR_NULL_KEY	0x23 Null key.
XSK_EFUSEPL_ERROR_FUSE_SEC_WRITE_DISABLED	0x24 Secure bits write is disabled.
XSK_EFUSEPL_ERROR_FUSE_SEC_READ_DISABLED	0x25 Secure bits reading is disabled.
XSK_EFUSEPL_ERROR_SEC_WRITE_BUFFER_NULL	0x26 Buffer to write into secure block is NULL.
XSK_EFUSEPL_ERROR_READ_PAGE_OUT_OF_RANGE	0x27 Page is out of range.
XSK_EFUSEPL_ERROR_FUSE_ROW_RANGE	0x28 Row is out of range.
XSK_EFUSEPL_ERROR_IN_PROGRAMMING_ROW	0x29 Error programming fuse row.
XSK_EFUSEPL_ERROR_PRGRMG_ROWS_NOT_EMPTY	0x2A Error when tried to program non Zero rows of eFUSE.
XSK_EFUSEPL_ERROR_HWM_TIMEOUT	0x80 Error when hardware module is exceeded the time for programming eFUSE.
XSK_EFUSEPL_ERROR_USER_FUSE_REVERT	0x90 Error occurs when user requests to revert already programmed user eFUSE bit.
XSK_EFUSEPL_ERROR_KEY_VALIDATION	0xF000 Invalid key.
XSK_EFUSEPL_ERROR_PL_STRUCT_NULL	0x1000 Null PL structure.
XSK_EFUSEPL_ERROR_JTAG_SERVER_INIT	0x1100 JTAG server initialization error.
XSK_EFUSEPL_ERROR_READING_FUSE_CNTRL	0x1200 Error reading fuse control.

Table 54: Enumeration XSKefusePl_ErrorCodes Values (cont'd)

Value	Description
XSK_EFUSEPL_ERROR_DATA_PROGRAMMING_NOT_ALLOWED	0x1300 Data programming not allowed.
XSK_EFUSEPL_ERROR_FUSE_CTRL_WRITE_NOT_ALLOWED	0x1400 Fuse control write is disabled.
XSK_EFUSEPL_ERROR_READING_FUSE_AES_ROW	0x1500 Error reading fuse AES row.
XSK_EFUSEPL_ERROR_AES_ROW_NOT_EMPTY	0x1600 AES row is not empty.
XSK_EFUSEPL_ERROR_PROGRAMMING_FUSE_AES_ROW	0x1700 Error programming fuse AES row.
XSK_EFUSEPL_ERROR_READING_FUSE_USER_DATA_ROW	0x1800 Error reading fuse user row.
XSK_EFUSEPL_ERROR_USER_DATA_ROW_NOT_EMPTY	0x1900 User row is not empty.
XSK_EFUSEPL_ERROR_PROGRAMMING_FUSE_USER_DATA_ROW	0x1A00 Error programming fuse user row.
XSK_EFUSEPL_ERROR_PROGRAMMING_FUSE_CTRL_ROW	0x1B00 Error programming fuse control row.
XSK_EFUSEPL_ERROR_XADC	0x1C00 XADC error.
XSK_EFUSEPL_ERROR_INVALID_REF_CLK	0x3000 Invalid reference clock.
XSK_EFUSEPL_ERROR_FUSE_SEC_WRITE_NOT_ALLOWED	0x1D00 Error in programming secure block.
XSK_EFUSEPL_ERROR_READING_FUSE_STATUS	0x1E00 Error in reading FUSE status.
XSK_EFUSEPL_ERROR_FUSE_BUSY	0x1F00 Fuse busy.
XSK_EFUSEPL_ERROR_READING_FUSE_RSA_ROW	0x2000 Error in reading FUSE RSA block.
XSK_EFUSEPL_ERROR_TIMER_INITIALISE_ULTRA	0x2200 Error in initiating Timer.
XSK_EFUSEPL_ERROR_READING_FUSE_SEC	0x2300 Error in reading FUSE secure bits.
XSK_EFUSEPL_ERROR_PRGRMG_FUSE_SEC_ROW	0x2500 Error in programming Secure bits of efuse.
XSK_EFUSEPL_ERROR_PRGRMG_USER_KEY	0x4000 Error in programming 32 bit user key.
XSK_EFUSEPL_ERROR_PRGRMG_128BIT_USER_KEY	0x5000 Error in programming 128 bit User key.
XSK_EFUSEPL_ERROR_PRGRMG_RSA_HASH	0x8000 Error in programming RSA hash.

PS eFUSE Error Codes

Enumerations

Enumeration XSKEfusePs_ErrorCodes

Table 55: Enumeration XSKEfusePs_ErrorCodes Values

Value	Description
XSK_EFUSEPS_ERROR_NONE	0 No error.
XSK_EFUSEPS_ERROR_ADDRESS_XIL_RESTRICTED	0x01 Address is restricted.
XSK_EFUSEPS_ERROR_READ_TEMPERATURE_OUT_OF_RANGE	0x02 Temperature obtained from XADC is out of range.
XSK_EFUSEPS_ERROR_READ_VCCPAUX_VOLTAGE_OUT_OF_RANGE	0x03 VCCAUX obtained from XADC is out of range.
XSK_EFUSEPS_ERROR_READ_VCCPINT_VOLTAGE_OUT_OF_RANGE	0x04 VCCINT obtained from XADC is out of range.
XSK_EFUSEPS_ERROR_WRITE_TEMPERATURE_OUT_OF_RANGE	0x05 Temperature obtained from XADC is out of range.
XSK_EFUSEPS_ERROR_WRITE_VCCPAUX_VOLTAGE_OUT_OF_RANGE	0x06 VCCAUX obtained from XADC is out of range.
XSK_EFUSEPS_ERROR_WRITE_VCCPINT_VOLTAGE_OUT_OF_RANGE	0x07 VCCINT obtained from XADC is out of range.
XSK_EFUSEPS_ERROR_VERIFICATION	0x08 Verification error.
XSK_EFUSEPS_ERROR_RSA_HASH_ALREADY_PROGRAMMED	0x09 RSA hash was already programmed.
XSK_EFUSEPS_ERROR_CONTROLLER_MODE	0x0A Controller mode error
XSK_EFUSEPS_ERROR_REF_CLOCK	0x0B Reference clock not between 20 to 60MHz
XSK_EFUSEPS_ERROR_READ_MODE	0x0C Not supported read mode
XSK_EFUSEPS_ERROR_XADC_CONFIG	0x0D XADC configuration error.
XSK_EFUSEPS_ERROR_XADC_INITIALIZE	0x0E XADC initialization error.
XSK_EFUSEPS_ERROR_XADC_SELF_TEST	0x0F XADC self-test failed.
XSK_EFUSEPS_ERROR_PARAMETER_NULL	0x10 Passed parameter null.
XSK_EFUSEPS_ERROR_STRING_INVALID	0x20 Passed string is invalid.
XSK_EFUSEPS_ERROR_AES_ALREADY_PROGRAMMED	0x12 AES key is already programmed.
XSK_EFUSEPS_ERROR_SPKID_ALREADY_PROGRAMMED	0x13 SPK ID is already programmed.
XSK_EFUSEPS_ERROR_PPK0_HASH_ALREADY_PROGRAMMED	0x14 PPK0 hash is already programmed.
XSK_EFUSEPS_ERROR_PPK1_HASH_ALREADY_PROGRAMMED	0x15 PPK1 hash is already programmed.

Table 55: Enumeration XSKefusePs_ErrorCodes Values (cont'd)

Value	Description
XSK_EFUSEPS_ERROR_IN_TBIT_PATTERN	0x16 Error in TBITS pattern .
XSK_EFUSEPS_ERROR_INVALID_PARAM	0x17 Error for invalid parameters.
XSK_EFUSEPS_ERROR_PROGRAMMING	0x00A0 Error in programming eFUSE.
XSK_EFUSEPS_ERROR_PGM_NOT_DONE	0x00A1 Program not done
XSK_EFUSEPS_ERROR_READ	0x00B0 Error in reading.
XSK_EFUSEPS_ERROR_BYTES_REQUEST	0x00C0 Error in requested byte count.
XSK_EFUSEPS_PUF_CANT_BE_USED_FOR_USER_DATA	0x00C0 Error when requested for PUF HD eFuses programming for user data, but as Chash is already programmed which means that PUF HD is already programmed with syndrome data
XSK_EFUSEPS_ERROR_RESRVD_BITS_PRGRMG	0x00D0 Error in programming reserved bits.
XSK_EFUSEPS_ERROR_ADDR_ACCESS	0x00E0 Error in accessing requested address.
XSK_EFUSEPS_ERROR_READ_NOT_DONE	0x00F0 Read not done
XSK_EFUSEPS_ERROR_PS_STRUCT_NULL	0x8100 PS structure pointer is null.
XSK_EFUSEPS_ERROR_XADC_INIT	0x8200 XADC initialization error.
XSK_EFUSEPS_ERROR_CONTROLLER_LOCK	0x8300 PS eFUSE controller is locked.
XSK_EFUSEPS_ERROR_EFUSE_WRITE_PROTECTED	0x8400 PS eFUSE is write protected.
XSK_EFUSEPS_ERROR_CONTROLLER_CONFIG	0x8500 Controller configuration error.
XSK_EFUSEPS_ERROR_PS_PARAMETER_WRONG	0x8600 PS eFUSE parameter is not TRUE/FALSE.
XSK_EFUSEPS_ERROR_WRITE_128K_CRC_BIT	0x9100 Error in enabling 128K CRC.
XSK_EFUSEPS_ERROR_WRITE_NONSECURE_INIT_BIT	0x9200 Error in programming NON secure bit.
XSK_EFUSEPS_ERROR_WRITE_UART_STATUS_BIT	0x9300 Error in writing UART status bit.
XSK_EFUSEPS_ERROR_WRITE_RSA_HASH	0x9400 Error in writing RSA key.
XSK_EFUSEPS_ERROR_WRITE_RSA_AUTH_BIT	0x9500 Error in enabling RSA authentication bit.
XSK_EFUSEPS_ERROR_WRITE_WRITE_PROTECT_BIT	0x9600 Error in writing write-protect bit.
XSK_EFUSEPS_ERROR_READ_HASH_BEFORE_PROGRAMMING	0x9700 Check RSA key before trying to program.
XSK_EFUSEPS_ERROR_WRTIE_DFT_JTAG_DIS_BIT	0x9800 Error in programming DFT JTAG disable bit.
XSK_EFUSEPS_ERROR_WRTIE_DFT_MODE_DIS_BIT	0x9900 Error in programming DFT MODE disable bit.
XSK_EFUSEPS_ERROR_WRTIE_AES_CRC_LK_BIT	0x9A00 Error in enabling AES's CRC check lock.
XSK_EFUSEPS_ERROR_WRTIE_AES_WR_LK_BIT	0x9B00 Error in programming AES write lock bit.
XSK_EFUSEPS_ERROR_WRTIE_USE_AESONLY_EN_BIT	0x9C00 Error in programming use AES only bit.
XSK_EFUSEPS_ERROR_WRTIE_BBRAM_DIS_BIT	0x9D00 Error in programming BBRAM disable bit.

Table 55: Enumeration XSKefusePs_ErrorCodes Values (cont'd)

Value	Description
XSK_EFUSEPS_ERROR_WRTIE_PMU_ERR_DIS_BIT	0x9E00 Error in programming PMU error disable bit.
XSK_EFUSEPS_ERROR_WRTIE_JTAG_DIS_BIT	0x9F00 Error in programming JTAG disable bit.
XSK_EFUSEPS_ERROR_READ_RSA_HASH	0xA100 Error in reading RSA key.
XSK_EFUSEPS_ERROR_WRONG_TBIT_PATTERN	0xA200 Error in programming TBIT pattern.
XSK_EFUSEPS_ERROR_WRITE_AES_KEY	0xA300 Error in programming AES key.
XSK_EFUSEPS_ERROR_WRITE_SPK_ID	0xA400 Error in programming SPK ID.
XSK_EFUSEPS_ERROR_WRITE_USER_KEY	0xA500 Error in programming USER key.
XSK_EFUSEPS_ERROR_WRITE_PPK0_HASH	0xA600 Error in programming PPK0 hash.
XSK_EFUSEPS_ERROR_WRITE_PPK1_HASH	0xA700 Error in programming PPK1 hash.
XSK_EFUSEPS_ERROR_WRITE_USER0_FUSE	0xC000 Error in programming USER 0 Fuses.
XSK_EFUSEPS_ERROR_WRITE_USER1_FUSE	0xC100 Error in programming USER 1 Fuses.
XSK_EFUSEPS_ERROR_WRITE_USER2_FUSE	0xC200 Error in programming USER 2 Fuses.
XSK_EFUSEPS_ERROR_WRITE_USER3_FUSE	0xC300 Error in programming USER 3 Fuses.
XSK_EFUSEPS_ERROR_WRITE_USER4_FUSE	0xC400 Error in programming USER 4 Fuses.
XSK_EFUSEPS_ERROR_WRITE_USER5_FUSE	0xC500 Error in programming USER 5 Fuses.
XSK_EFUSEPS_ERROR_WRITE_USER6_FUSE	0xC600 Error in programming USER 6 Fuses.
XSK_EFUSEPS_ERROR_WRITE_USER7_FUSE	0xC700 Error in programming USER 7 Fuses.
XSK_EFUSEPS_ERROR_WRTIE_USER0_LK_BIT	0xC800 Error in programming USER 0 fuses lock bit.
XSK_EFUSEPS_ERROR_WRTIE_USER1_LK_BIT	0xC900 Error in programming USER 1 fuses lock bit.
XSK_EFUSEPS_ERROR_WRTIE_USER2_LK_BIT	0xCA00 Error in programming USER 2 fuses lock bit.
XSK_EFUSEPS_ERROR_WRTIE_USER3_LK_BIT	0xCB00 Error in programming USER 3 fuses lock bit.
XSK_EFUSEPS_ERROR_WRTIE_USER4_LK_BIT	0xCC00 Error in programming USER 4 fuses lock bit.
XSK_EFUSEPS_ERROR_WRTIE_USER5_LK_BIT	0xCD00 Error in programming USER 5 fuses lock bit.
XSK_EFUSEPS_ERROR_WRTIE_USER6_LK_BIT	0xCE00 Error in programming USER 6 fuses lock bit.
XSK_EFUSEPS_ERROR_WRTIE_USER7_LK_BIT	0xCF00 Error in programming USER 7 fuses lock bit.
XSK_EFUSEPS_ERROR_WRTIE_PROG_GATE0_DIS_BIT	0xD000 Error in programming PROG_GATE0 disabling bit.
XSK_EFUSEPS_ERROR_WRTIE_PROG_GATE1_DIS_BIT	0xD100 Error in programming PROG_GATE1 disabling bit.
XSK_EFUSEPS_ERROR_WRTIE_PROG_GATE2_DIS_BIT	0xD200 Error in programming PROG_GATE2 disabling bit.
XSK_EFUSEPS_ERROR_WRTIE_SEC_LOCK_BIT	0xD300 Error in programming SEC_LOCK bit.
XSK_EFUSEPS_ERROR_WRTIE_PPK0_WR_LK_BIT	0xD400 Error in programming PPK0 write lock bit.
XSK_EFUSEPS_ERROR_WRTIE_PPK0_RVK_BIT	0xD500 Error in programming PPK0 revoke bit.

Table 55: Enumeration XSKefusePs_ErrorCodes Values (cont'd)

Value	Description
XSK_EFUSEPS_ERROR_WRTIE_PPK1_WR_LK_BIT	0xD600 Error in programming PPK1 write lock bit.
XSK_EFUSEPS_ERROR_WRTIE_PPK1_RVK_BIT	0xD700 Error in programming PPK0 revoke bit.
XSK_EFUSEPS_ERROR_WRITE_PUF_SYN_INVLD	0xD800 Error while programming the PUF syndrome invalidate bit.
XSK_EFUSEPS_ERROR_WRITE_PUF_SYN_WRLK	0xD900 Error while programming Syndrome write lock bit.
XSK_EFUSEPS_ERROR_WRITE_PUF_SYN_REG_DIS	0xDA00 Error while programming PUF syndrome register disable bit.
XSK_EFUSEPS_ERROR_WRITE_PUF_RESERVED_BIT	0xDB00 Error while programming PUF reserved bit.
XSK_EFUSEPS_ERROR_WRITE_LBIST_EN_BIT	0xDC00 Error while programming LBIST enable bit.
XSK_EFUSEPS_ERROR_WRITE_LPD_SC_EN_BIT	0xDD00 Error while programming LPD SC enable bit.
XSK_EFUSEPS_ERROR_WRITE_FPD_SC_EN_BIT	0xDE00 Error while programming FPD SC enable bit.
XSK_EFUSEPS_ERROR_WRITE_PBR_BOOT_ERR_BIT	0xDF00 Error while programming PBR boot error bit.
XSK_EFUSEPS_ERROR_PUF_INVALID_REG_MODE	0xE000 Error when PUF registration is requested with invalid registration mode.
XSK_EFUSEPS_ERROR_PUF_REG_WO_AUTH	0xE100 Error when write not allowed without authentication enabled.
XSK_EFUSEPS_ERROR_PUF_REG_DISABLED	0xE200 Error when trying to do PUF registration and when PUF registration is disabled.
XSK_EFUSEPS_ERROR_PUF_INVALID_REQUEST	0xE300 Error when an invalid mode is requested.
XSK_EFUSEPS_ERROR_PUF_DATA_ALREADY_PROGRAMMED	0xE400 Error when PUF is already programmed in eFUSE.
XSK_EFUSEPS_ERROR_PUF_DATA_OVERFLOW	0xE500 Error when an over flow occurs.
XSK_EFUSEPS_ERROR_SPKID_BIT_CANT_REVERT	0xE600 Already programmed SPKID bit cannot be reverted
XSK_EFUSEPS_ERROR_PUF_DATA_UNDERFLOW	0xE700 Error when an under flow occurs.
XSK_EFUSEPS_ERROR_PUF_TIMEOUT	0xE800 Error when an PUF generation timedout.
XSK_EFUSEPS_ERROR_PUF_ACCESS	0xE900 Error when an PUF Access violation.
XSK_EFUSEPS_ERROR_PUF_CHASH_ALREADY_PROGRAMMED	0xEA00 Error When PUF Chash already programmed in eFuse.
XSK_EFUSEPS_ERROR_PUF_AUX_ALREADY_PROGRAMMED	0xEB00 Error When PUF AUX already programmed in eFuse.
XSK_EFUSEPS_ERROR_CMPLTD_EFUSE_PRGRM_WITH_ERR	0x10000 eFUSE programming is completed with temp and vol read errors.
XSK_EFUSEPS_ERROR_CACHE_LOAD	0x20000U Error in re-loading CACHE.
XSK_EFUSEPS_RD_FROM_EFUSE_NOT_ALLOWED	0x30000U Read from eFuse is not allowed.
XSK_EFUSEPS_ERROR_FUSE_PROTECTED	0x00080000 Requested eFUSE is write protected.
XSK_EFUSEPS_ERROR_USER_BIT_CANT_REVERT	0x00800000 Already programmed user FUSE bit cannot be reverted.
XSK_EFUSEPS_ERROR_BEFORE_PROGRAMMING	0x08000000U Error occurred before programming.

Zynq UltraScale+ MPSoC BBRAM PS Error Codes

Enumerations

Enumeration XskZynqMp_Ps_Bbram_ErrorCodes

Table 56: Enumeration XskZynqMp_Ps_Bbram_ErrorCodes Values

Value	Description
XSK_ZYNQMP_BBRAMPS_ERROR_NONE	0 No error.
XSK_ZYNQMP_BBRAMPS_ERROR_IN_PRGRMG_ENABLE	0x010 If this error is occurred programming is not possible.
XSK_ZYNQMP_BBRAMPS_ERROR_IN_ZEROISE	0x20 zeroize bbram is failed.
XSK_ZYNQMP_BBRAMPS_ERROR_IN_CRC_CHECK	0xB000 If this error is occurred programming is done but CRC check is failed.
XSK_ZYNQMP_BBRAMPS_ERROR_IN_PRGRMG	0xC000 programming of key is failed.
XSK_ZYNQMP_BBRAMPS_ERROR_IN_WRITE_CRC	0xE800 error write CRC value.

Status Codes

For Zynq and UltraScale, the status in the xilskey_efuse_example.c file is conveyed through a UART or reboot status register in the following format: 0xYYYYZZZZ, where:

- YYYY represents the PS eFUSE Status.
- ZZZZ represents the PL eFUSE Status.

The table below lists the status codes.

Status Code Values	Description
0x0000ZZZZ	Represents PS eFUSE is successful and PL eFUSE process returned with error.
0xYYYY0000	Represents PL eFUSE is successful and PS eFUSE process returned with error.
0xFFFF0000	Represents PS eFUSE is not initiated and PL eFUSE is successful.
0x0000FFFF	Represents PL eFUSE is not initiated and PS eFUSE is successful.
0xFFFFZZZZ	Represents PS eFUSE is not initiated and PL eFUSE is process returned with error.

Status Code Values	Description
0xYYYYFFFF	Represents PL eFUSE is not initiated and PS eFUSE is process returned with error.

For Zynq UltraScale+ MPSoC, the status in the `xilskey_bbramps_zynqmp_example.c`, `xilskey_puf_registration.c` and `xilskey_efuseps_zynqmp_example.c` files is conveyed as 32 bit error code. Where Zero represents that no error has occurred and if the value is other than Zero, a 32 bit error code is returned.

Procedures

This section provides detailed descriptions of the various procedures.

Zynq eFUSE Writing Procedure Running from DDR as an Application

This sequence is same as the existing flow described below.

1. Provide the required inputs in `xilskey_input.h`, then compile the platform project.
2. Take the latest FSBL (ELF), stitch the `<output>.elf` generated to it (using the bootgen utility), and generate a bootable image.
3. Write the generated binary image into the flash device (for example: QSPI, NAND).
4. To burn the eFUSE key bits, execute the image.

Zynq eFUSE Driver Compilation Procedure for OCM

The procedure is as follows:

1. Open the linker script (`lscript.ld`) in the platform project.
2. Map all the sections to point to `ps7_ram_0_S_AXI_BASEADDR` instead of `ps7_ddr_0_S_AXI_BASEADDR`. For example, Click the Memory Region tab for the `.text` section and select `ps7_ram_0_S_AXI_BASEADDR` from the drop-down list.
3. Copy the `ps7_init.c` and `ps7_init.h` files from the `hw_platform` folder into the example folder.
4. In `xilskey_efuse_example.c`, un-comment the code that calls the `ps7_init()` routine.
5. Compile the project.

The `<Project name>.elf` file is generated and is executed out of OCM.

When executed, this example displays the success/failure of the eFUSE application in a display message via UART (if UART is present and initialized) or the reboot status register.

UltraScale eFUSE Access Procedure

The procedure is as follows:

1. After providing the required inputs in `xilskey_input.h`, compile the project.
2. Generate a memory mapped interface file using TCL command `write_mem_info`
3. Update memory has to be done using the tcl command `updatemem`.
4. Program the board using `$Final.bit` bitstream.
5. Output can be seen in UART terminal.

UltraScale BBRAM Access Procedure

The procedure is as follows:

1. After providing the required inputs in the `xilskey_bbram_ultrascale_input.h`` file, compile the project.
2. Generate a memory mapped interface file using TCL command
3. Update memory has to be done using the tcl command `updatemem`:
4. Program the board using `$Final.bit` bitstream.
5. Output can be seen in UART terminal.

Data Structure Index

The following is a list of data structures:

- [XilSKey_JtagSlr](#)
- [XilSKey_UsrFuses](#)

XilSKey_JtagSlr

Declaration

```
typedef struct
{
    u32 NumSlr,
    u32 CurSlr,
    u32 IrLen
} XilSKey_JtagSlr;
```

Table 57: Structure XilSKey_JtagSlr member description

Member	Description
NumSlr	Number of SLRs to iterate through
CurSlr	Current SLR to iterate through
IrLen	Device IR length

XilSKey_UsrFuses

`XilSKey_UsrFuses` holds the User FUSES which needs to be actually programmed

Declaration

```
typedef struct
{
    u8 UserFuse[XSK_ZYNQMP_EFUSEPS_USER_FUSE_ROW_LEN_IN_BITS]
} XilSKey_UsrFuses;
```

Table 58: Structure XilSKey_UsrFuses member description

Member	Description
UserFuse	User fuses which need to be programmed

Additional Resources and Legal Notices

Xilinx Resources

For support resources such as Answers, Documentation, Downloads, and Forums, see [Xilinx Support](#).

Documentation Navigator and Design Hubs

Xilinx[®] Documentation Navigator (DocNav) provides access to Xilinx documents, videos, and support resources, which you can filter and search to find information. To open DocNav:

- From the Vivado[®] IDE, select **Help** → **Documentation and Tutorials**.
- On Windows, select **Start** → **All Programs** → **Xilinx Design Tools** → **DocNav**.
- At the Linux command prompt, enter `docnav`.

Xilinx Design Hubs provide links to documentation organized by design tasks and other topics, which you can use to learn key concepts and address frequently asked questions. To access the Design Hubs:

- In DocNav, click the **Design Hubs View** tab.
- On the Xilinx website, see the [Design Hubs](#) page.

Note: For more information on DocNav, see the [Documentation Navigator](#) page on the Xilinx website.

Please Read: Important Legal Notices

The information disclosed to you hereunder (the "Materials") is provided solely for the selection and use of Xilinx products. To the maximum extent permitted by applicable law: (1) Materials are made available "AS IS" and with all faults, Xilinx hereby DISCLAIMS ALL WARRANTIES AND CONDITIONS, EXPRESS, IMPLIED, OR STATUTORY, INCLUDING BUT NOT LIMITED TO WARRANTIES OF MERCHANTABILITY, NON-INFRINGEMENT, OR FITNESS FOR ANY PARTICULAR PURPOSE; and (2) Xilinx shall not be liable (whether in contract or tort, including negligence, or under any other theory of liability) for any loss or damage of any kind or nature related to, arising under, or in connection with, the Materials (including your use of the Materials), including for any direct, indirect, special, incidental, or consequential loss or damage (including loss of data, profits, goodwill, or any type of loss or damage suffered as a result of any action brought by a third party) even if such damage or loss was reasonably foreseeable or Xilinx had been advised of the possibility of the same. Xilinx assumes no obligation to correct any errors contained in the Materials or to notify you of updates to the Materials or to product specifications. You may not reproduce, modify, distribute, or publicly display the Materials without prior written consent. Certain products are subject to the terms and conditions of Xilinx's limited warranty, please refer to Xilinx's Terms of Sale which can be viewed at <https://www.xilinx.com/legal.htm#tos>; IP cores may be subject to warranty and support terms contained in a license issued to you by Xilinx. Xilinx products are not designed or intended to be fail-safe or for use in any application requiring fail-safe performance; you assume sole risk and liability for use of Xilinx products in such critical applications, please refer to Xilinx's Terms of Sale which can be viewed at <https://www.xilinx.com/legal.htm#tos>.

AUTOMOTIVE APPLICATIONS DISCLAIMER

AUTOMOTIVE PRODUCTS (IDENTIFIED AS "XA" IN THE PART NUMBER) ARE NOT WARRANTED FOR USE IN THE DEPLOYMENT OF AIRBAGS OR FOR USE IN APPLICATIONS THAT AFFECT CONTROL OF A VEHICLE ("SAFETY APPLICATION") UNLESS THERE IS A SAFETY CONCEPT OR REDUNDANCY FEATURE CONSISTENT WITH THE ISO 26262 AUTOMOTIVE SAFETY STANDARD ("SAFETY DESIGN"). CUSTOMER SHALL, PRIOR TO USING OR DISTRIBUTING ANY SYSTEMS THAT INCORPORATE PRODUCTS, THOROUGHLY TEST SUCH SYSTEMS FOR SAFETY PURPOSES. USE OF PRODUCTS IN A SAFETY APPLICATION WITHOUT A SAFETY DESIGN IS FULLY AT THE RISK OF CUSTOMER, SUBJECT ONLY TO APPLICABLE LAWS AND REGULATIONS GOVERNING LIMITATIONS ON PRODUCT LIABILITY.

Copyright

© Copyright 2020-2022 Xilinx, Inc. Xilinx, the Xilinx logo, Alveo, Artix, Kintex, Kria, Spartan, Versal, Vitis, Virtex, Vivado, Zynq, and other designated brands included herein are trademarks of Xilinx in the United States and other countries. All other trademarks are the property of their respective owners.