

## Flashing Guideline for MGM111A256V2 (ZigBee Module)

<b>Version</b>	1.0
<b>Status</b>	Baselined
<b>Date</b>	11-Jul-2019

### Confidentiality Notice

Copyright (c) 2018 eInfochips. - All rights reserved

This document is authored by eInfochips and is eInfochips intellectual property, including the copyrights in all countries in the world. This document is provided under a license to use only with all other rights, including ownership rights, being retained by eInfochips. This file may not be distributed, copied, or reproduced in any manner, electronic or otherwise, without the express written consent of eInfochips.

# CONTENTS

<b>1</b>	<b>DOCUMENT DETAILS.....</b>	<b>4</b>
1.1	Document History .....	4
1.2	Definition, Acronyms and Abbreviations.....	4
<b>2</b>	<b>INTRODUCTION .....</b>	<b>5</b>
2.1	ZigBee Cable assembly .....	5
2.2	Pre-requisites/Software requirements .....	6
<b>3</b>	<b>ZIGBEE FLASHING .....</b>	<b>7</b>
3.1	ZigBee flashing with simplicity studio .....	7
3.2	ZigBee flashing with J-Link flasher .....	9

FIGURES

FIGURE 1: J-LINK CONNECTION ..... 5

FIGURE 2: CONNECTION DETAILS ..... 5

TABLES

TABLE 1: DOCUMENT HISTORY ..... 4

TABLE 2: DEFINITION, ACRONYMS AND ABBREVIATIONS ..... 4

TABLE 3: PRE-REQUISITES ..... 6

# 1 DOCUMENT DETAILS

## 1.1 Document History

Version	Author		Reviewer		Approver	
	Name	Date (DD-MM-YYYY)	Name	Date (DD-MMM-YYYY)	Name	Date (DD-MM-YYYY)
Version1.0	Richa Prajapati	21-Jun-19	Anirudha Chougule	11-Jul-2019	Anirudha Chougule	11-Jul-2019

Version	Description of Change
Version1.0	ZigBee flashing document created and baselined

Table 1: Document History

## 1.2 Definition, Acronyms and Abbreviations

Definition/Acronym/Abbreviation	Description
HMI	Human Machine Interface

Table 2: Definition, Acronyms and Abbreviations

## 2 INTRODUCTION

- This document explains how to flash ZigBee module MGM111A256V2 (U13) of Thor96 Board (17\_00666\_03)
- This process should be followed before running production script on the board
- J-link plus debugger is used to flash ZigBee. One end of debugger will be connected to host PC and another end will be connected to J11 of HMI board
- We have to make 20 pin to 10 pin cable in-house.



Figure 1: j-link connection

### 2.1 ZigBee Cable assembly

- J-link debugger has 20 pin connector. Below is the pin connection for ZigBee Flashing Cable Assembly for THOR96 Board.
- 20 pin and 10 pin connectors details is as below.

20 pin Connector mating Part Number - 1658623-4 (TE Connectivity)

10 pin Connector mating Part Number - 20021311-00010T4LF (Amphenol ICC (FCI))

- Below is the pin details of Thor96 board and J-link debugger




Figure 2: Connection details

## 2.2 Pre-requisites/Software requirements

Sr.No	Component	Specification
1	Linux Machine	Ubuntu 16.04 LTS Installed
2	Windows machine	Windows 7 64 bit
3	Simplicity studio tool	To flash ZigBee
4	In-house cable 20 pin to 10 pin	To connect Thor96 board
5	J-link flasher utility	<a href="https://www.segger.com/downloads/flasher/JLink_Linux_arm.tgz">https://www.segger.com/downloads/flasher/JLink_Linux_arm.tgz</a>


**Table 3: Pre-requisites**

### 3 ZIGBEE FLASHING


- ZigBee flashing can be done with two software.
  1. Simplicity studio by silicon labs
  2. J-link flasher by J-link segger

#### 3.1 ZigBee flashing with simplicity studio


Step 1: Open Simplicity studio and select Simplicity Commander. Connect Target Device using simplicity Commander. Windows PC is mandatory for if you are flashing through simplicity studio.




Step 2: For Program to target device, press flash button.




Step 3: Press Connect target device as below.



Step 4: Press button to connect Target device.




Step 5: Get information of Device which is connected.





Step 6: After device is detected, first erase the chip. And Flash below two files in sequence.

- 1) bootloader-spi-ezsp\_MGM111A256V2-combined.s37
- 2) ncp-spi\_MGM111A256V2\_NEW.hex




## 3.2 ZigBee flashing with J-Link flasher


Step 1: Download the utility from below link. This utility is for Linux only.

[https://www.segger.com/downloads/flasher/JLink\\_Linux\\_arm.tgz](https://www.segger.com/downloads/flasher/JLink_Linux_arm.tgz)

Step 1: Download the utility from below link. Open the J-link segger lite from the folder which is plug and play application. Select the device from silicon labs "BGM111"





Step 2: After selecting the device, erase the chip



Step 3: After erasing the chip successfully, flash below two files in sequence.

- 1) bootloader-spi-ezsp\_MGM111A256V2-combined.s37
- 2) ncp-spi\_MGM111A256V2\_NEW.hex





Step 3: Flash hex file

