

Configuration Files

Remote database connection

To enable remote synchronisation the system requires a configuration text file that is used on startup to set up the remote connection to the database. If this file is not available or incorrectly populated then remote connection is not possible.

This file is typically set up by Faraday during system configuration, but sometimes has to be changed at a later time. **Because it is encrypted for security, you have to contact Faraday Support to make any changes.**

The text file is located in the application directory in the following folder: 'HorizonConfigV2Server1/HorizonConfig'

DatabaseConnectionServer-CONN.txt contains the connection strings for the remote database. It contains three rows as follows:

- The remote server name or URL and port number (such as acme.uswest.cloudapp.azure.com,1433)
- The remote server user name (such as sa)
- The remote server password

When connecting to a new server through the FILE menu, this text file is updated with the new connection strings and then becomes the default connection on startup.