

P100 Series Quick Start Guide

Important information

It is assumed that you have read the installation manual before using the P100 Series unit and that it is installed and ready to start testing. If you do not know how to install it, or you haven't done it yet, please refer to Hardware Manual for more information about installation set up. Please follow safety guidelines mentioned in relevant sections.













Tips:

- ❖ When changing a value within a text box, make sure you press Enter to update value. If the text box remains pink means that the value hasn't been updated yet. In this case, press Enter to set the new entry.
- ❖ Click buttons for Modes (SCOPE, BASELINE, MONITOR) and Charts (TIME, FREQ, COND) become grey when selected, i.e. they merge with the background.
- ❖ You can recall default settings at any time. Just go to FILE/RECALL SETTINGS.
- ❖ STORE and RECALL ADHOC is used for Scope mode data only.
- ❖ RECALL MEAS is for that data that has been taken after a baseline, and it is stored under the Monitor mode. Please bear in mind that not all Monitoring data is saved; this can be customized under Project settings.

Software set up

If you have already made a project and would like to connect to it, select SETTINGS/PROJECT. Under the block *Connect to a project* select one of the list and click *Connect*. You can now start assessing the health of your equipment. Otherwise, you must create a new project.

- ❖ Create a new Project
 - Go to SETTINGS/PROJECT. Under the block *Create new project* enter the name of your new project, select whether your machine is a *Motor* or a *Generator* and use *Default* settings. If you select *Clone* then the settings for the new project will be copied from the present project.
 - The project will be created, and a blank chart will appear. Close the *Project settings* window.
- ❖ Type in Basic Equipment Information
 - Go to *Basic Equipment Info*. This is located in the left hand panel of the main form.
 - Enter motor rated frequency (this is independent of whether the motor is driven by an inverter or not).
 - Enter motor rated current and speed (please refer to *Hardware manual – Installation* for information on how to read a motor plate). The system will then automatically set the number of poles and rated slip of the motor.
 - Enter calibration factors, which will depend upon the selected hardware set up. See table below for calibration factors. If you haven't connected the P100 Series Unit yet, please refer to *Hardware manual – Installation*.

		Measuring points					
		Motor supply		Protection System Transformers		Test blocks	
Current	CT model	Split core 300A:10mA 		Spring clamp 10A:10mA 		Miniature 10A:10mA 	
	Measuring range	3 - 30A	30 - 300A	0.1 - 1A	1 - 10A	0.1 - 1A	1 - 10A
	Calibration factor	3,000	30,000	100 x Protection CT ratio	1,000 x Protection CT ratio	100 x Protection CT ratio	1,000 x Protection CT ratio
	Switch position	UP 	DOWN 	UP 	DOWN 	UP 	DOWN 
Voltage	Probe model	Dolphin clip 		Dolphin clip 		Banana adapter 	
	Measuring range	110 - 400V (Line to Line)		110 - 400V (Line to Line)		110 - 300V (Line to Line)	
	Calibration factor	1		Protection VT Ratio		Protection VT Ratio	

NOTE: Protection Current Transformer (CT) and Voltage Transformer (VT) ratios can be easily calculated by dividing its primary rated value by its secondary rated value.

❖ Enter Equipment Information

- Go to SETTINGS/EQUIPMENT.
- Enter mechanical related information such as bearing types, belt drives dimensions, etc. Make sure you enable the relevant component by clicking on the tick box next to it. Click on *Specific* under *Select fault table* to allow the software to use those values for diagnostic interpretation. If no mechanical information is available, click on *Generic* instead.
- On the text box *Other information*, enter motor rated values (Voltage, Frequency, Current and Speed), type of equipment (Pump, Fan, etc) and any other relevant information about the equipment and/or the site.
- Click on *Save other info*.

The system is now ready to start assessing the health of your equipment.

Equipment health assessment (SCOPE mode)

The following steps will allow you to take a snapshot of your Equipment's health within a few minutes.

- ❖ Select SCOPE mode and click START button. The software will now carry out a measurement loop which takes around 6 seconds.
- ❖ Once finished, have a look at the electrical waveforms and measured electrical parameters to make sure they look correct:
 - Click on TIME chart.


- Select V1, V2, V3 and I1, I2 and I3 to be displayed on the chart. Those should have a sinusoidal shape, and should be out of phase by the same amount. Have a go at playing with them to make they look like a 3-phase system of voltages and currents.
- Have a look at the *Electrical* measured parameters in the right hand panel of the main form. Compare those against the motor rated values to make sure they look correct.
- ❖ Now select the REPORT button, located at the top of the main screen to print out comprehensive diagnostic results.
- ❖ If you click on SPECTRUM chart you will see the frequency domain of the measured electrical waveforms. Every single peak has a meaning, although not all of them represent an incipient fault.
- ❖ If you click on CONDITION chart you will see an overview diagnostic of your equipment's health. If you click on any of those bars, you will find a description of the fault type below the chart.
- ❖ You can now save the measurement. Go to FILE/STORE ADHOC and click on *Save*. This measurement will now be part of your project and will be available on the Database to look at it at any time.
- ❖ Click on REPORT to get a full report of your equipment's condition based on this measurement. You can now carry out more measurements or learn the pre-existing condition of your equipment and monitor it.

Equipment health monitoring (BASELINE and MONITOR Modes)

For monitoring the health of the equipment over time, it is required to learn its present condition with Baseline mode. This allows to identify incipient faults on the equipment and to measure their present level for future comparison.

- ❖ Set the number of iterations for Baseline mode. For doing so, go to SCOPE mode. Click on the tick box *Show processing* (in the left hand panel of the main form), and a list of settings will appear below. The first one is called *Baseline* and is under the *Measurement settings* block. Type in the number of iterations to create the Baseline (30 recommended).
- ❖ Select BASELINE mode and click START. Wait for the process to complete, where the total time required depends on the number of iterations selected (each iteration takes roughly 6 seconds).
- ❖ Once the Baseline mode finishes, select MONITOR Mode and click START. You are now monitoring your equipment. It is advised to select the Condition chart for looking at the condition bars. Those will display the number of Standard Deviations of any existing faults from the baseline. You can click on any of those at any time to see their trend over time.
- ❖ You can stop monitoring at any time by clicking STOP.

Motor Current Signature Analysis (MCSA)



MCSA measures the spectrum at high resolution, to identify peaks related with rotor bar deterioration. This technique can only be used in Induction Machines, where slip is present and inherent to the machine performance.

When an induction motor is connected to the three-phase electrical supply, the rotating field created on the stator induces an electro motive force in the rotor, which in return creates a current that flows through the rotor bars. The amplitude and frequency of this current is maximum on the start-up, and reduce as the rotor increases in speed. The rotor will never reach the synchronous speed, and the difference is called slip, which depends upon the load applied on the machine.

If one or more of the rotor bars is developing cracking or other deterioration, the electrical resistance of this bar increases with respect to the others, creating a pulse pattern in the stator current as the bar crosses the synchronous field. This pattern can easily be analysed in the frequency domain, appearing as sidebands of the main frequency supply. Those sidebands will depend upon the slip of the machine, being further apart as the slip increases (as load increases).

Analysing Sidebands

MCSA analysis is usually performed using the measured current, although it is easier to spot those sidebands when displaying the residual current as well. The range where those sidebands can be found is within $\pm 20\%$ of the frequency of the supply, as sideband of this and depending upon the slip present on the machine at the time when the data was taken.

Using Auto slip will simplify the identification process. This estimates the slip of the machine, using a linear approximation between the motor rated current and the current being drawn at the time when the data was collected.

The process to identify and measure rotor band responses is as follows:

- ❖ Take a measurement using SCOPE Mode, with a high number of Nominal sampling points to allow high resolution spectral analysis (32768 or 65536 points are recommended). Make sure the number of Baseline cycles is set to 1, and that Auto slip is checked.

- ❖ Nominal sampling rate should be set to a low value (where 2.5 kHz is recommended).
- ❖ Select the maximum FFT size and Overlap (16384 and 90% respectively). Then select the maximum number of Averages that gives you a low Zero padding value. A value below 10% is suitable for MCSA purposes.
- ❖ On the Frequency Plot, you now need to select the view range for spotting the pole pass sidebands. The maximum and minimum frequency are usually within $\pm 20\%$ of the supply frequency. For a 50Hz supply the viewing range shall be set from 40Hz to 60Hz.
- ❖ On the same plot, select now either of the measured currents (I1, I2 or I3), either of the residuals (Iar or Ibr) and the Pole Pass (PP). If modelling is not available the residual currents will not be shown, but this does not present a problem for carrying out MCSA.
- ❖ Selection Pole Pass (PP) causes two bars to appear at sidebands of the fundamental frequency. If Auto Slip is enabled, those should lie on top of the pole pass peaks. Two values will be displayed below the frequency Chart, on the text boxes PPlo (Pole Pass Low) and PPhi (Pole Pass High). Those values will give an indication of the rotor bars condition as per the table below.

Category	I (line) / I (pole pass)	Assessment	Action
1	60dB or more	Excellent	None
2	54-60dB	Good	None
3	48-54dB	Moderate	Continue surveys, trend
4	42-48dB	Rotor bar crack developing or high-resistance joints	Reduce survey interval, trend closely
5	36-42dB	2 bars likely to be cracked or broken, high resistance joint likely	Perform vibration tests to confirm problem source
6	30-36dB	Multiple cracked/broken bars or end rings indicated	Overhaul asap
7	< 30 dB	Multiple cracked/broken bars or end rings very likely; severe problems throughout	Overhaul or replace asap

If you think the pole pass bands are incorrectly located, you can change those by modifying the Rated speed of the motor.