

1235 N. Union Bower Rd
Irving, TX 75061
Phone: 916-457-5129
Fax: 916-457-4948

The Angeline Bldg 1

The Angeline Bldg 1 > Simplex 1 > > Riser1

In Pin	In Function	Out Pin	Out Function
501	HOISTWAY SENSOR	601	FIRE LAMP LOBBY
502	MACHINE ROOM SENSOR	602	EMS 1 LAMP
503	SMOKE AT LOBBY FLOOR	603	
504	SMOKES AT UPPER FLOORS	604	
505	FIRE RECALL OFF	605	
506	FIRE RECALL RESET	606	
507	EMS 1	607	
508	BROKEN ROPE	608	

The Angeline Bldg 1 > Simplex 1 > 1 > CarTop

In Pin	In Function	Out Pin	Out Function
501	GATESWITCH (GSW-F)	601	BUZZER
502		602	FIRE PHASE I LAMP
503	DOOR ZONE (DZ1)	603	LIGHT/FAN TIMER
504	DOOR ZONE (DZ2)	604	FIRE PHASE II ACTIVE LAMP
505	INSPECTION CT UP	605	Fire Phase 1
506	INSPECTION CT DOWN	606	
507	INSPECTION CT ENABLE	607	
508		608	
509		609	
510		610	
511		611	
512		612	
513	POSITION MON. (DPM-F)	613	
514	PHOTOEYE (PHE-F)	614	OPEN (DO-F)
515	OPEN LIMIT (DOL-F)	615	CLOSE (DC-F)
516	CLOSE LIMIT (DCL-F)	616	

1235 N. Union Bower Rd
Irving, TX 75061
Phone: 916-457-5129
Fax: 916-457-4948

The Angeline Bldg 1 > Simplex 1 > 1 > COP

In Pin	In Function	Out Pin	Out Function
501		601	FIRE PHASE I LAMP
502		602	CHIME (COP)
503	FIRE PHASE II CANCEL CALL	603	CAR LANTERN UP FRONT
504	FIRE PHASE II ON	604	CAR LANTERN DOWN FRONT
505	FIRE PHASE II HOLD	605	
506	FIRE PHASE II OFF	606	
507	INDEPENDENT SERVICE	607	BUZZER
508	DOOR CLOSE BUTTON FRONT	608	
509	DOOR OPEN BUTTON FRONT	609	
510	MEDICAL IN-CAR ENABLE	610	MEDICAL IN-CAR LAMP
511	Car Call Button F 1	611	CAR CALL LAMP F 1
512	Car Call Button F 2	612	CAR CALL LAMP F 2
513	Car Call Button F 3	613	CAR CALL LAMP F 3
514	Car Call Button F 4	614	CAR CALL LAMP F 4
515		615	
516		616	

The Angeline Bldg 1 > Simplex 1 > 1 > MachineRoom

In Pin	In Function	Out Pin	Out Function
501		601	SAFETY RESCUE
502		602	BATTERY POWER
503	MANUAL PICK	603	
504	BATTERY POWER	604	
505	LIGHT LOAD NO	605	
506	OVERLOADED NO	606	
507	FULL LOAD NO	607	
508	BATTERY FAULT	608	