

Channel settings

- Voltage (volts)
- Current (microamps)

Channel monitor

- Present voltage (volts)
- Drawn current (microamps)

Channel power button ("OFF" state)

Channel power button ("ON" state)

Toggle real-time monitoring of HV channels

HV channel 0

HV channel 1

HV channel 2

HV channel 3

HV channel 4

HV channel 5

