

ZebraPrinter_LIB

Generated by Doxygen 1.8.20

1 Class Index	1
1.1 Class List	1
2 File Index	3
2.1 File List	3
3 Class Documentation	5
3.1 ZebraPrinter_ContentParams Struct Reference	5
4 File Documentation	7
4.1 C:/Users/jai_prajapati/Documents/SourceLibraries/Serial_LIB/ZebraPrinter_LIB/ZebraPrinter_Lib.c File Reference	7
4.1.1 Detailed Description	8
4.1.2 Function Documentation	8
4.1.2.1 ZebraPrinter_AddToPrintCode()	8
4.2 C:/Users/jai_prajapati/Documents/SourceLibraries/Serial_LIB/ZebraPrinter_LIB/ZebraPrinter_Lib.h File Reference	9
4.2.1 Detailed Description	9
4.2.2 Function Documentation	10
4.2.2.1 ZebraPrinter_AddToPrintCode()	10
Index	11

Chapter 1

Class Index

1.1 Class List

Here are the classes, structs, unions and interfaces with brief descriptions:

ZebraPrinter_ContentParams	5
--	---

Chapter 2

File Index

2.1 File List

Here is a list of all documented files with brief descriptions:

C:/Users/jai_prajapati/Documents/SourceLibraries/Serial_LIB/ZebraPrinter_LIB/ ZebraPrinter_Lib.c	
A short description	7
C:/Users/jai_prajapati/Documents/SourceLibraries/Serial_LIB/ZebraPrinter_LIB/ ZebraPrinter_Lib.h . . .	9

Chapter 3

Class Documentation

3.1 ZebraPrinter_ContentParams Struct Reference

Public Attributes

- unsigned int **x**
- unsigned int **y**
- unsigned int **height**
- unsigned int **printWidth**
- int **labelTop**
- int **labelShift**
- int **tearOff**
- int **darkness**
- char **font** [20]
- unsigned int **width**
- unsigned int **col**
- unsigned int **row**
- unsigned int **quality**

The documentation for this struct was generated from the following file:

- C:/Users/jai_prajapati/Documents/SourceLibraries/Serial_LIB/ZebraPrinter_LIB/[ZebraPrinter_Lib.h](#)

Chapter 4

File Documentation

4.1 C:/Users/jai_prajapati/Documents/SourceLibraries/Serial_LIB/ZebraPrinter_LIB/ZebraPrinter_Lib.c File Reference

A short description.

```
#include <ansi_c.h>
#include <utility.h>
#include "SerialComm_LIB.h"
#include "ZebraPrinter_Lib.h"
```

Functions

- int [Initialize_ZebraPrinter_Lib](#) (char *PrinterSerialName, char errmsg[ERRLEN])
Initializes the printer through SerialLib and checks the connection by sending a status command.
- int [ZebraPrinter_AddToPrintCode](#) (char *PrintCode, ZebraPrinter_ContentType Type, [ZebraPrinter_ContentParams](#) Params, char *Content, char errmsg[ERRLEN])
Adds new content to PrintCode, only relevant parameters need to be set for params.
- int [ZebraPrinter_Code_Start](#) (char errmsg[ERRLEN])
ZT610 Printer, start with ^XA.
- int [ZebraPrinter_Code_String](#) (char *x, char *y, char *font, char *height, char *width, char *print_string, char errmsg[ERRLEN])
CodeContainer, x, y, font, height, width, print_string.
- int [ZebraPrinter_Code_DataMatrix](#) (char *x, char *y, char *font, char *height, char *col, char *row, char *print_string, char errmsg[ERRLEN])
//CodeContainer, x, y, font, height, col, row, print_string
- int [ZebraPrinter_Code_End](#) (char errmsg[ERRLEN])
//CodeContainer, x, y, font, height, col, row, print_string
- int [ZebraPrinter_Print](#) (char *PrinterSerialName, char *PrintCode, char errmsg[ERRLEN])
Send PrintCode to the printer via serial.
- void [ZebraPrinter_Close_Printer](#) (char *Printer, char errmsg[ERRLEN])
close printer

Variables

- char **ZebraPrinterCode** [2048] = {0}

4.1.1 Detailed Description

A short description.

Author

Chao Zhang

Copyright

Arxtron Technologies Inc.. All Rights Reserved.

Date

5/29/2020 4:09:26 PM

A longer description.

Date	Name	Rev.	Description
05-29-2020	Chao Zhang	1.↔ 0.0	Initial Release
09-01-2020	Chao Zhang	1.↔ 0.1	Added Teat off, Darkness

4.1.2 Function Documentation

4.1.2.1 ZebraPrinter_AddToPrintCode()

```
int ZebraPrinter_AddToPrintCode (
    char * PrintCode,
    ZebraPrinter_ContentType Type,
    ZebraPrinter_ContentParams Params,
    char * Content,
    char errmsg[ERRLEN] )
```

Adds new content to PrintCode, only relevant parameters need to be set for params.

Parameters

out	<i>PrintCode</i>	The code to append to
in	<i>Type</i>	The type of content to be added
in	<i>Params</i>	The parameters related to the type of content, only parameters relevant to the content type needs to be set
in	<i>Content</i>	The text content to be added

4.2 C:/Users/jai_prajapati/Documents/SourceLibraries/Serial_LIB/ZebraPrinter_LIB/ZebraPrinter_Lib.h File Reference

```
#include "cvideo.h"
#include "ArxtronToolslib.h"
```

Classes

- struct [ZebraPrinter_ContentParams](#)

Macros

- #define **ERR_INVALID_CONTENT_TYPE** -21001

Enumerations

- enum **ZebraPrinter_ContentType** {
 ZP_Header = 1, **ZP_Footer** = 2, **ZP_LabelTop** = 3, **ZP_PrintWidth** = 4,
 ZP_LabelShift = 5, **ZP_TearOff** = 6, **ZP_Darkness** = 7, **ZP_String** = 10,
 ZP_Barcode = 11, **ZP_Logo** = 30 }

Functions

- void **GetStandardErrMsg** (int error, char errmsg[ERRLEN])
- int CVICALLBACK **FunctionSelect** (int panel, int control, int event, void *callbackData, int eventData1, int eventData2)
- int CVICALLBACK **RunFunction** (int panel, int control, int event, void *callbackData, int eventData1, int eventData2)
- int [Initialize_ZebraPrinter_Lib](#) (char *PrinterSerialName, char errmsg[ERRLEN])
Initializes the printer through SerialLib and checks the connection by sending a status command.
- int [ZebraPrinter_AddToPrintCode](#) (char *PrintCode, ZebraPrinter_ContentType Type, [ZebraPrinter_ContentParams](#) Params, char *Content, char errmsg[ERRLEN])
Adds new content to PrintCode, only relevant parameters need to be set for params.
- int [ZebraPrinter_Print](#) (char *PrinterSerialName, char *PrintCode, char errmsg[ERRLEN])
Send PrintCode to the printer via serial.
- void [ZebraPrinter_Close_Printer](#) (char *Printer, char errmsg[ERRLEN])
close printer

4.2.1 Detailed Description

Author

Chao Zhang

Copyright

Arxtron Technologies Inc.. All Rights Reserved.

Date

5/29/2020 4:09:26 PM

4.2.2 Function Documentation

4.2.2.1 ZebraPrinter_AddToPrintCode()

```
int ZebraPrinter_AddToPrintCode (
    char * PrintCode,
    ZebraPrinter_ContentType Type,
    ZebraPrinter_ContentParams Params,
    char * Content,
    char errmsg[ERRLEN] )
```

Adds new content to *PrintCode*, only relevant parameters need to be set for *params*.

Parameters

out	<i>PrintCode</i>	The code to append to
in	<i>Type</i>	The type of content to be added
in	<i>Params</i>	The parameters related to the type of content, only parameters relevant to the content type needs to be set
in	<i>Content</i>	The text content to be added

Index

C:/Users/jai_prajapati/Documents/SourceLibraries/Serial_LIB/ZebraPrinter_LIB/ZebraPrinter_Lib.c,
[7](#)

C:/Users/jai_prajapati/Documents/SourceLibraries/Serial_LIB/ZebraPrinter_LIB/ZebraPrinter_Lib.h,
[9](#)

ZebraPrinter_AddToPrintCode

 ZebraPrinter_Lib.c, [8](#)

 ZebraPrinter_Lib.h, [10](#)

ZebraPrinter_ContentParams, [5](#)

ZebraPrinter_Lib.c

 ZebraPrinter_AddToPrintCode, [8](#)

ZebraPrinter_Lib.h

 ZebraPrinter_AddToPrintCode, [10](#)