

User Manual

for S32K3 AE Driver

Document Number: UM34AEASRR21-11 Rev0000R 3.0.0 Rev. 1.0

1 Revision History	2
2 Introduction	3
2.1 Supported Derivatives	3
2.2 Overview	4
2.3 About This Manual	5
2.4 Acronyms and Definitions	6
2.5 Reference List	6
3 Driver	7
3.1 Requirements	7
3.2 Driver Design Summary	7
3.3 Hardware Resources	8
3.4 Deviations from Requirements	8
3.5 Driver Limitations	8
3.6 Driver usage and configuration tips	8
3.7 Runtime errors	8
3.8 Symbolic Names Disclaimer	9
4 Tresos Configuration Plug-in	10
4.1 Module Ae	11
4.2 Container AeGeneral	12
4.3 Parameter AeVersionInfoApi	12
4.4 Parameter AeDevErrorDetect	12
4.5 Parameter AeRawbitEn	13
4.6 Container AeGeneralVendorSpecific	13
4.7 Parameter AeTimeoutMethod	14
4.8 Parameter AeTimeoutDuration	14
4.9 Container AeHvmVmConfig	15
4.10 Parameter AeHvmVoltageMonitorInputSelect	15
4.11 Parameter AeVmHighVoltageDetectInterruptEn	15
4.12 Parameter AeVmLowVoltageDetectInterruptEn	16
4.13 Parameter AeHvmHighVoltageDetectEn	16
4.14 Parameter AeHvmLowVoltageDetectEn	17
4.15 Parameter AeHvmLowDetectRefVoltage	17
4.16 Parameter AeHvmHighDetectRefVoltage	18
4.17 Container AeHvmHviConfig	18
4.18 Container AeHvmHviGeneralConfig	19
4.19 Parameter AeHvmHviAnalogchannel	19
4.20 Parameter AeHvmAnalogInput	20
4.21 Parameter AeHvmUnderControlIsrCallback	20

4.22 Container AeHvmHviInstanceConfig	21
4.23 Parameter AeHvmHviChannelIdx	21
4.24 Parameter AeHVIIInputDigitalEn	21
4.25 Parameter AeHVIIInterruptInputDigitalEn	22
4.26 Parameter AeHviDigitalInputPolarity	22
4.27 Parameter AeHviDividerSelect	23
4.28 Parameter AeHVIPullUpEn	23
4.29 Parameter AeHVIPullDownEn	24
4.30 Container AeSpi	24
4.31 Container AeSpiSequence	25
4.32 Parameter AeSpiAccessSynchronous	25
4.33 Reference AeSpiSequenceName	26
4.34 Container AeIrqConfig	26
4.35 Container AeIntConfig	26
4.36 Parameter AeIntName	27
4.37 Parameter AeIsrEnabled	27
4.38 Parameter AeIsrPriority	28
4.39 Parameter AeIntHandler	28
4.40 Container CommonPublishedInformation	29
4.41 Parameter ModuleId	29
4.42 Parameter VendorId	30
4.43 Parameter VendorApiInfix	30
4.44 Parameter ArReleaseMajorVersion	31
4.45 Parameter ArReleaseMinorVersion	31
4.46 Parameter ArReleaseRevisionVersion	32
4.47 Parameter SwMajorVersion	32
4.48 Parameter SwMinorVersion	33
4.49 Parameter SwPatchVersion	33
5 Module Index	35
5.1 Software Specification	35
6 Module Documentation	36
6.1 AEC Driver	36
6.1.1 Detailed Description	36
6.1.2 Data Structure Documentation	37
6.1.3 Types Reference	38
6.1.4 Enum Reference	38
6.1.5 Function Reference	38
6.2 HVM Driver	41
6.2.1 Detailed Description	41

6.2.2 Enum Reference	41
6.2.3 Function Reference	42
6.3 Ae Driver	45
6.3.1 Detailed Description	45
6.3.2 Macro Definition Documentation	46
6.3.3 Function Reference	50



Chapter 1

Revision History

Revision	Date	Author	Description
1.0	31.03.2023	NXP RTD Team	S32K3 Real-Time Drivers AUTOSAR 4.4 & R21-11 Version 3.0.0

Chapter 2

Introduction

- [Supported Derivatives](#)
- [Overview](#)
- [About This Manual](#)
- [Acronyms and Definitions](#)
- [Reference List](#)

This User Manual describes NXP Semiconductors' AE Driver for S32K3XX.

AE Driver configuration parameters description can be found in the Tresos Configuration Plugin section.

2.1 Supported Derivatives

The software described in this document is intended to be used with the following microcontroller devices of NXP Semiconductors:

- s32k310_mqfp100
- s32k310_lqfp48
- s32k311_mqfp100 / MWCT2015S_mqfp100
- s32k311_lqfp48
- s32k312_mqfp100 / MWCT2016S_mqfp100
- s32k312_mqfp172 / MWCT2016S_mqfp172
- s32k314_mqfp172
- s32k314_mapbga257
- s32k322_mqfp100 / MWCT2D16S_mqfp100
- s32k322_mqfp172 / MWCT2D16S_mqfp172

- s32k324_mqfp172 / MWCT2D17S_mqfp172
- s32k324_mapbga257
- s32k341_mqfp100
- s32k341_mqfp172
- s32k342_mqfp100
- s32k342_mqfp172
- s32k344_mqfp172
- s32k344_mapbga257
- s32k394_mapbga289
- s32k396_mapbga289
- s32k358_mqfp172
- s32k358_mapbga289
- s32k328_mqfp172
- s32k328_mapbga289
- s32k338_mqfp172
- s32k338_mapbga289
- s32k348_mqfp172
- s32k348_mapbga289
- s32m274_lqfp64
- s32m276_lqfp64

All of the above microcontroller devices are collectively named as S32K3.

Note: MWCT part numbers contain NXP confidential IP for Qi Wireless Power.

2.2 Overview

AUTOSAR (AUTomotive Open System ARchitecture) is an industry partnership working to establish standards for software interfaces and software modules for automobile electronic control systems.

AUTOSAR:

- paves the way for innovative electronic systems that further improve performance, safety and environmental friendliness.
- is a strong global partnership that creates one common standard: "Cooperate on standards, compete on implementation".
- is a key enabling technology to manage the growing electrics/electronics complexity. It aims to be prepared for the upcoming technologies and to improve cost-efficiency without making any compromise with respect to quality.
- facilitates the exchange and update of software and hardware over the service life of the vehicle.

2.3 About This Manual

This Technical Reference employs the following typographical conventions:

- **Boldface** style: Used for important terms, notes and warnings.
- *Italic* style: Used for code snippets in the text. Note that C language modifiers such "const" or "volatile" are sometimes omitted to improve readability of the presented code.

Notes and warnings are shown as below:

Note

This is a note.

Warning

This is a warning

2.4 Acronyms and Definitions

Term	Definition
API	Application Programming Interface
AUTOSAR	Automotive Open System Architecture
DEM	Diagnostic Event Manager
DET	Default Error Tracer
AE	Application Extension
AEC	Application Extension Controller
HVM	High Voltage Module
VM	Voltage Monitor
HVI	High Voltage Input
SPI	Serial Peripheral Interface
MCU	Micro controller Unit
N/A	Not Available
RAM	Random Access Memory

- The term "Ae Driver" is related to the software handling the Application Extension.
- The term "Application" is used for the software utilizing the AE Driver.

2.5 Reference List

#	Title	Version
1	S32M27x Reference Manual	Rev.2, Draft A, — 02/2023
2	S32M2xx Data Sheet	Rev. 2 RC — 12/2022

Chapter 3

Driver

- [Requirements](#)
- [Driver Design Summary](#)
- [Hardware Resources](#)
- [Deviations from Requirements](#)
- [Driver Limitations](#)
- [Driver usage and configuration tips](#)
- [Runtime errors](#)
- [Symbolic Names Disclaimer](#)

3.1 Requirements

None.

3.2 Driver Design Summary

The AE Driver controls the Application Extension Controller (AEC) module and High Voltage Monitor(HVM) of the S32K3XX device. It provides the following features:

- For AEC:
- A SPI interface for microcontroller communication to read/ write to AE's registers for polling and interrupt mode.
- Read Frame Counter status.
- Allow to control Raw bit.
- Decode global health status of frame.

- Read status of faults and events through interrupt_out raised.
- For HVM:
- A voltage divider to divide down different input voltage levels to the system voltage.
- Event generation, when the input logic level changes. This works also when the clock is off, so you can use this digital input interrupt for example to wake up the device from sleep mode.
- Event observation through interrupt generation, reading of an interrupt flag in register, or polling the event status from a register.
- Analog output, e.g. for reading the input voltage with an on-chip ADC.
- Selectable pull-up and pull-down connections on the input for open input detection.
- Fixed input voltage division by 11 in the connected HVI when a voltage monitor is enabled.
- Event generation, when the input voltage is out of customer-defined limits. You can configure the upper and lower limits of the allowed voltage range of the input signal.
- Observation of any voltage out of defined limits event through interrupt generation, reading of an interrupt flag in a register, or polling the event status from a register.

3.3 Hardware Resources

The SPI interface communication to microcontroller pin mapping can be done using the file **S32M27x_IOMU↔X.xlsx** attached to the Reference Manual.

3.4 Deviations from Requirements

None.

3.5 Driver Limitations

None.

3.6 Driver usage and configuration tips

None

3.7 Runtime errors

None.

3.8 Symbolic Names Disclaimer

All containers having `symbolicNameValue` set to `TRUE` in the AUTOSAR schema will generate defines like:

```
#define <Mip>Conf_<Container_ShortName>_<Container_ID>
```

For this reason it is forbidden to duplicate the names of such containers across the RTD configurations or to use names that may trigger other compile issues (e.g. match existing `#ifdefs` arguments).

Chapter 4

Tresos Configuration Plug-in

This chapter describes the Tresos configuration plug-in for the driver. All the parameters are described below.

- Module [Ae](#)
 - Container [AeGeneral](#)
 - * Parameter [AeVersionInfoApi](#)
 - * Parameter [AeDevErrorDetect](#)
 - * Parameter [AeRawbitEn](#)
 - * Container [AeGeneralVendorSpecific](#)
 - Parameter [AeTimeoutMethod](#)
 - Parameter [AeTimeoutDuration](#)
 - Container [AeHvmVmConfig](#)
 - * Parameter [AeHvmVoltageMonitorInputSelect](#)
 - * Parameter [AeVmHighVoltageDetectInterruptEn](#)
 - * Parameter [AeVmLowVoltageDetectInterruptEn](#)
 - * Parameter [AeHvmHighVoltageDetectEn](#)
 - * Parameter [AeHvmLowVoltageDetectEn](#)
 - * Parameter [AeHvmLowDetectRefVoltage](#)
 - * Parameter [AeHvmHighDetectRefVoltage](#)
 - Container [AeHvmHviConfig](#)
 - * Container [AeHvmHviGeneralConfig](#)
 - Parameter [AeHvmHviAnalogchannel](#)
 - Parameter [AeHvmAnalogInput](#)
 - Parameter [AeHvmUnderControlIsrCallback](#)
 - * Container [AeHvmHviInstanceConfig](#)
 - Parameter [AeHvmHviChannelIdx](#)
 - Parameter [AeHVIInputDigitalEn](#)
 - Parameter [AeHVIInterruptInputDigitalEn](#)
 - Parameter [AeHviDigitalInputPolarity](#)
 - Parameter [AeHviDividerSelect](#)
 - Parameter [AeHVIPullUpEn](#)
 - Parameter [AeHVIPullDownEn](#)

- Container [AeSpi](#)
 - * Container [AeSpiSequence](#)
 - Parameter [AeSpiAccessSynchronous](#)
 - Reference [AeSpiSequenceName](#)
- Container [AeIrqConfig](#)
 - * Container [AeIntConfig](#)
 - Parameter [AeIntName](#)
 - Parameter [AeIsrEnabled](#)
 - Parameter [AeIsrPriority](#)
 - Parameter [AeIntHandler](#)
- Container [CommonPublishedInformation](#)
 - * Parameter [ModuleId](#)
 - * Parameter [VendorId](#)
 - * Parameter [VendorApiInfix](#)
 - * Parameter [ArReleaseMajorVersion](#)
 - * Parameter [ArReleaseMinorVersion](#)
 - * Parameter [ArReleaseRevisionVersion](#)
 - * Parameter [SwMajorVersion](#)
 - * Parameter [SwMinorVersion](#)
 - * Parameter [SwPatchVersion](#)

4.1 Module Ae

Configuration of the Ae (Application Extension Driver) module.

Included containers:

- [AeGeneral](#)
- [AeHvmVmConfig](#)
- [AeHvmHviConfig](#)
- [AeSpi](#)
- [AeIrqConfig](#)
- [CommonPublishedInformation](#)

Property	Value
type	ECUC-MODULE-DEF
lowerMultiplicity	0
upperMultiplicity	1
postBuildVariantSupport	true
supportedConfigVariants	VARIANT-PRE-COMPILE, VARIANT-POST-BUILD

4.2 Container AeGeneral

General configuration of Ae Driver module.

Included subcontainers:

- [AeGeneralVendorSpecific](#)

Property	Value
type	ECUC-PARAM-CONF-CONTAINER-DEF
lowerMultiplicity	1
upperMultiplicity	1
postBuildVariantMultiplicity	N/A
multiplicityConfigClasses	N/A

4.3 Parameter AeVersionInfoApi

Enables / Disables Ae_GetVersionInfo API.

Property	Value
type	ECUC-BOOLEAN-PARAM-DEF
origin	AUTOSAR_ECUC
symbolicNameValue	false
lowerMultiplicity	1
upperMultiplicity	1
postBuildVariantMultiplicity	N/A
multiplicityConfigClasses	N/A
postBuildVariantValue	false
valueConfigClasses	VARIANT-POST-BUILD: PRE-COMPILE VARIANT-PRE-COMPILE: PRE-COMPILE
defaultValue	true

4.4 Parameter AeDevErrorDetect

Enables / Disables development error detection.

Property	Value
type	ECUC-BOOLEAN-PARAM-DEF
origin	AUTOSAR_ECUC

Property	Value
symbolicNameValue	false
lowerMultiplicity	1
upperMultiplicity	1
postBuildVariantMultiplicity	N/A
multiplicityConfigClasses	N/A
postBuildVariantValue	false
valueConfigClasses	VARIANT-POST-BUILD: PRE-COMPILE
	VARIANT-PRE-COMPILE: PRE-COMPILE
default Value	true

4.5 Parameter AeRawbitEn

Enables / Disables read after write

Property	Value
type	ECUC-BOOLEAN-PARAM-DEF
origin	NXP
symbolicNameValue	false
lowerMultiplicity	1
upperMultiplicity	1
postBuildVariantMultiplicity	N/A
multiplicityConfigClasses	N/A
postBuildVariantValue	true
valueConfigClasses	VARIANT-POST-BUILD: POST-BUILD
	VARIANT-PRE-COMPILE: PRE-COMPILE
default Value	false

4.6 Container AeGeneralVendorSpecific

General vendor-specific configuration of Ae Driver.

Included subcontainers:

- None

Property	Value
type	ECUC-PARAM-CONF-CONTAINER-DEF
lowerMultiplicity	1
upperMultiplicity	1
postBuildVariantMultiplicity	N/A
multiplicityConfigClasses	N/A

4.7 Parameter AeTimeoutMethod

Configures the timeout method.

Based on this selection a certain timeout method from OsIf will be used in the driver.

Note: If SystemTimer or CustomTimer are selected make sure the corresponding timer is enabled in OsIf General configuration.

Note: Implementation Specific Parameter.

Property	Value
type	ECUC-ENUMERATION-PARAM-DEF
origin	NXP
symbolicNameValue	false
lowerMultiplicity	1
upperMultiplicity	1
postBuildVariantMultiplicity	N/A
multiplicityConfigClasses	N/A
postBuildVariantValue	false
valueConfigClasses	VARIANT-PRE-COMPILE: PRE-COMPILE
	VARIANT-POST-BUILD: PRE-COMPILE
defaultValue	OSIF_COUNTER_DUMMY
literals	['OSIF_COUNTER_SYSTEM', 'OSIF_COUNTER_CUSTOM', 'OSIF_COUNTER_DUMMY']

4.8 Parameter AeTimeoutDuration

The unit of measurement is given in number of microseconds.

Property	Value
type	ECUC-INTEGER-PARAM-DEF
origin	NXP
symbolicNameValue	false
lowerMultiplicity	1
upperMultiplicity	1
postBuildVariantMultiplicity	N/A
multiplicityConfigClasses	N/A
postBuildVariantValue	false
valueConfigClasses	VARIANT-POST-BUILD: PRE-COMPILE
	VARIANT-PRE-COMPILE: PRE-COMPILE
defaultValue	1000
max	65535
min	1

4.9 Container AeHvmVmConfig

General Configuration Volatage Monitor.

Included subcontainers:

- None

Property	Value
type	ECUC-PARAM-CONF-CONTAINER-DEF
lowerMultiplicity	1
upperMultiplicity	1
postBuildVariantMultiplicity	N/A
multiplicityConfigClasses	N/A

4.10 Parameter AeHvmVoltageMonitorInputSelect

Select the voltage that is observed by the voltage monitor.

Note: Implementation Specific Parameter.

Property	Value
type	ECUC-ENUMERATION-PARAM-DEF
origin	NXP
symbolicNameValue	false
lowerMultiplicity	1
upperMultiplicity	1
postBuildVariantMultiplicity	N/A
multiplicityConfigClasses	N/A
postBuildVariantValue	true
valueConfigClasses	VARIANT-PRE-COMPILE: PRE-COMPILE
	VARIANT-POST-BUILD: POST-BUILD
defaultValue	VM_HIGH_VOLTAGE_INPUT
literals	['VM_HIGH_VOLTAGE_INPUT', 'VM_SENSE_VOLTAGE']

4.11 Parameter AeVmHighVoltageDetectInterruptEn

This parameter is used to enable/disable the digital input interrupt of High Voltage Detect.

Property	Value
type	ECUC-BOOLEAN-PARAM-DEF
origin	NXP
symbolicNameValue	false
lowerMultiplicity	1
upperMultiplicity	1
postBuildVariantMultiplicity	N/A
multiplicityConfigClasses	N/A
postBuildVariantValue	true
valueConfigClasses	VARIANT-POST-BUILD: POST-BUILD
	VARIANT-PRE-COMPILE: PRE-COMPILE
default Value	false

4.12 Parameter AeVmLowVoltageDetectInterruptEn

This parameter is used to enable/disable the digital input interrupt of Low Voltage Detect.

Property	Value
type	ECUC-BOOLEAN-PARAM-DEF
origin	NXP
symbolicNameValue	false
lowerMultiplicity	1
upperMultiplicity	1
postBuildVariantMultiplicity	N/A
multiplicityConfigClasses	N/A
postBuildVariantValue	true
valueConfigClasses	VARIANT-POST-BUILD: POST-BUILD
	VARIANT-PRE-COMPILE: PRE-COMPILE
default Value	false

4.13 Parameter AeHvmHighVoltageDetectEn

Enables / Disables the voltage monitor for high voltage detection.

Property	Value
type	ECUC-BOOLEAN-PARAM-DEF
origin	NXP
symbolicNameValue	false
lowerMultiplicity	1
upperMultiplicity	1

Property	Value
postBuildVariantMultiplicity	N/A
multiplicityConfigClasses	N/A
postBuildVariantValue	true
valueConfigClasses	VARIANT-POST-BUILD: POST-BUILD
	VARIANT-PRE-COMPILE: PRE-COMPILE
defaultValue	false

4.14 Parameter AeHvmLowVoltageDetectEn

Enables / Disables the voltage monitor for Low voltage detection.

Property	Value
type	ECUC-BOOLEAN-PARAM-DEF
origin	NXP
symbolicNameValue	false
lowerMultiplicity	1
upperMultiplicity	1
postBuildVariantMultiplicity	N/A
multiplicityConfigClasses	N/A
postBuildVariantValue	true
valueConfigClasses	VARIANT-POST-BUILD: POST-BUILD
	VARIANT-PRE-COMPILE: PRE-COMPILE
defaultValue	false

4.15 Parameter AeHvmLowDetectRefVoltage

Configures the reference voltage level for low voltage detection.

This reference voltage level is in datasheet.

Note: Implementation Specific Parameter.

Property	Value
type	ECUC-ENUMERATION-PARAM-DEF
origin	NXP
symbolicNameValue	false
lowerMultiplicity	1
upperMultiplicity	1
postBuildVariantMultiplicity	N/A

Property	Value
multiplicityConfigClasses	N/A
postBuildVariantValue	true
valueConfigClasses	VARIANT-PRE-COMPILE: PRE-COMPILE
	VARIANT-POST-BUILD: POST-BUILD
defaultValue	VM_LBI1
literals	['VM_LBI1', 'VM_LBI2', 'VM_LBI3', 'VM_LBI4']

4.16 Parameter AeHvmHighDetectRefVoltage

Configures the reference voltage level for high voltage detection.

This reference voltage level is in datasheet.

Note: Implementation Specific Parameter.

Property	Value
type	ECUC-ENUMERATION-PARAM-DEF
origin	NXP
symbolicNameValue	false
lowerMultiplicity	1
upperMultiplicity	1
postBuildVariantMultiplicity	N/A
multiplicityConfigClasses	N/A
postBuildVariantValue	true
valueConfigClasses	VARIANT-PRE-COMPILE: PRE-COMPILE
	VARIANT-POST-BUILD: POST-BUILD
defaultValue	VM_HBI1
literals	['VM_HBI1', 'VM_HBI2']

4.17 Container AeHvmHviConfig

Configuration of High Voltage Input for each instances.

Included subcontainers:

- [AeHvmHviGeneralConfig](#)
- [AeHvmHviInstanceConfig](#)

Property	Value
type	ECUC-PARAM-CONF-CONTAINER-DEF
lowerMultiplicity	1
upperMultiplicity	1
postBuildVariantMultiplicity	N/A
multiplicityConfigClasses	N/A

4.18 Container AeHvmHviGeneralConfig

Included subcontainers:

- None

Property	Value
type	ECUC-PARAM-CONF-CONTAINER-DEF
lowerMultiplicity	1
upperMultiplicity	1
postBuildVariantMultiplicity	N/A
multiplicityConfigClasses	N/A

4.19 Parameter AeHvmHviAnalogchannel

Configures the Analog channel.

Enable the analog input for one HVI.

Note: Implementation Specific Parameter.

Property	Value
type	ECUC-ENUMERATION-PARAM-DEF
origin	NXP
symbolicNameValue	false
lowerMultiplicity	1
upperMultiplicity	1
postBuildVariantMultiplicity	N/A
multiplicityConfigClasses	N/A
postBuildVariantValue	true
valueConfigClasses	VARIANT-PRE-COMPILE: PRE-COMPILE
	VARIANT-POST-BUILD: POST-BUILD
defaultValue	HVI0_CHANNEL
literals	['HVI0_CHANNEL', 'HVI1_CHANNEL']

4.20 Parameter AeHvmAnalogInput

Configures the Analog Input.

Select the analog input that is given out on the analog output of the instance that is selected.

Note: Implementation Specific Parameter.

Property	Value
type	ECUC-ENUMERATION-PARAM-DEF
origin	NXP
symbolicNameValue	false
lowerMultiplicity	1
upperMultiplicity	1
postBuildVariantMultiplicity	N/A
multiplicityConfigClasses	N/A
postBuildVariantValue	true
valueConfigClasses	VARIANT-PRE-COMPILE: PRE-COMPILE
	VARIANT-POST-BUILD: POST-BUILD
defaultValue	HVI_ANALOG_INPUT_BUFFERED
literals	['HVI_ANALOG_OUT_OHMIC', 'HVI_ANALOG_INPUT_BUFFERED', 'HVI_ANALOG_DIVIDE_DOWN_HIGH_INPUT_BUFFERED', 'HVI_ANALOG_INPUT_UNBUFFERED']

4.21 Parameter AeHvmUnderControllerCallback

Enables callback function was handled by user for Hvm_Ip_pfReportCallback, if is disable, driver doesn't do anything, callback function is empty.

Property	Value
type	ECUC-BOOLEAN-PARAM-DEF
origin	NXP
symbolicNameValue	false
lowerMultiplicity	1
upperMultiplicity	1
postBuildVariantMultiplicity	N/A
multiplicityConfigClasses	N/A
postBuildVariantValue	false
valueConfigClasses	VARIANT-POST-BUILD: PRE-COMPILE
	VARIANT-PRE-COMPILE: PRE-COMPILE
defaultValue	false

4.22 Container AeHvmHviInstanceConfig

Container information to configure for each HVI instance.

Included subcontainers:

- None

Property	Value
type	ECUC-PARAM-CONF-CONTAINER-DEF
lowerMultiplicity	0
upperMultiplicity	255
postBuildVariantMultiplicity	true
multiplicityConfigClasses	VARIANT-POST-BUILD: POST-BUILD
	VARIANT-PRE-COMPILE: PRE-COMPILE

4.23 Parameter AeHvmHviChannelIdx

High Voltage Input channel Index

Property	Value
type	ECUC-INTEGER-PARAM-DEF
origin	NXP
symbolicNameValue	false
lowerMultiplicity	1
upperMultiplicity	1
postBuildVariantMultiplicity	N/A
multiplicityConfigClasses	N/A
postBuildVariantValue	true
valueConfigClasses	VARIANT-POST-BUILD: POST-BUILD
	VARIANT-PRE-COMPILE: PRE-COMPILE
defaultValue	0
max	N/A
min	0

4.24 Parameter AeHVIInputDigitalEn

This parameter is used to enable/disable the digital input.

Property	Value
type	ECUC-BOOLEAN-PARAM-DEF
origin	NXP
symbolicNameValue	false
lowerMultiplicity	1
upperMultiplicity	1
postBuildVariantMultiplicity	N/A
multiplicityConfigClasses	N/A
postBuildVariantValue	true
valueConfigClasses	VARIANT-POST-BUILD: POST-BUILD
	VARIANT-PRE-COMPILE: PRE-COMPILE
default Value	false

4.25 Parameter AeHVIIInterruptInputDigitalEn

This parameter is used to enable/disable the digital input interrupt of HVI channel.

Property	Value
type	ECUC-BOOLEAN-PARAM-DEF
origin	NXP
symbolicNameValue	false
lowerMultiplicity	1
upperMultiplicity	1
postBuildVariantMultiplicity	N/A
multiplicityConfigClasses	N/A
postBuildVariantValue	true
valueConfigClasses	VARIANT-POST-BUILD: POST-BUILD
	VARIANT-PRE-COMPILE: PRE-COMPILE
default Value	false

4.26 Parameter AeHviDigitalInputPolarity

Configures the Digital Input Polarity.

Configure whether the high or the low state on the digital input triggers an event.

Note: Implementation Specific Parameter.

Property	Value
type	ECUC-ENUMERATION-PARAM-DEF
origin	NXP

Property	Value
symbolicNameValue	false
lowerMultiplicity	1
upperMultiplicity	1
postBuildVariantMultiplicity	N/A
multiplicityConfigClasses	N/A
postBuildVariantValue	true
valueConfigClasses	VARIANT-PRE-COMPILE: PRE-COMPILE
	VARIANT-POST-BUILD: POST-BUILD
defaultValue	HVI_DIGITAL_INPUT_POLARITY_PULLDOWN
literals	['HVI_DIGITAL_INPUT_POLARITY_PULLDOWN', 'HVI_DIGITAL_INPUT_POLARITY_PULLUP']

4.27 Parameter AeHviDividerSelect

Configures the ratio of the voltage division.

The pull down must be enabled to divide by the ratios selectable here. To set a divider ratio of 1, the pull down must be disabled.

Note: Implementation Specific Parameter.

Property	Value
type	ECUC-ENUMERATION-PARAM-DEF
origin	NXP
symbolicNameValue	false
lowerMultiplicity	1
upperMultiplicity	1
postBuildVariantMultiplicity	N/A
multiplicityConfigClasses	N/A
postBuildVariantValue	true
valueConfigClasses	VARIANT-PRE-COMPILE: PRE-COMPILE
	VARIANT-POST-BUILD: POST-BUILD
defaultValue	HVI_VOLTAGE_DIVISION_2
literals	['HVI_VOLTAGE_DIVISION_2', 'HVI_VOLTAGE_DIVISION_6', 'HVI_VOLTAGE_DIVISION_11', 'HVI_VOLTAGE_DIVISION_16']

4.28 Parameter AeHVIPullUpEn

This parameter is used to enable/disable the pull up on the input of each instance HVI.

Property	Value
type	ECUC-BOOLEAN-PARAM-DEF
origin	NXP
symbolicNameValue	false
lowerMultiplicity	1
upperMultiplicity	1
postBuildVariantMultiplicity	N/A
multiplicityConfigClasses	N/A
postBuildVariantValue	true
valueConfigClasses	VARIANT-POST-BUILD: POST-BUILD
	VARIANT-PRE-COMPILE: PRE-COMPILE
default Value	false

4.29 Parameter AeHVIPullDownEn

This parameter is used to enable/disable the pull down on the input of each instance HVI.

Property	Value
type	ECUC-BOOLEAN-PARAM-DEF
origin	NXP
symbolicNameValue	false
lowerMultiplicity	1
upperMultiplicity	1
postBuildVariantMultiplicity	N/A
multiplicityConfigClasses	N/A
postBuildVariantValue	true
valueConfigClasses	VARIANT-POST-BUILD: POST-BUILD
	VARIANT-PRE-COMPILE: PRE-COMPILE
default Value	false

4.30 Container AeSpi

Configuration of one Application Extension SPI access (if SPI is used).

Included subcontainers:

- [AeSpiSequence](#)

Property	Value
type	ECUC-PARAM-CONF-CONTAINER-DEF

Property	Value
lowerMultiplicity	1
upperMultiplicity	1
postBuildVariantMultiplicity	N/A
multiplicityConfigClasses	N/A

4.31 Container AeSpiSequence

Container gives Ae driver information about one SPI sequence.

Included subcontainers:

- None

Property	Value
type	ECUC-PARAM-CONF-CONTAINER-DEF
lowerMultiplicity	1
upperMultiplicity	255
postBuildVariantMultiplicity	true
multiplicityConfigClasses	VARIANT-POST-BUILD: PRE-COMPILE
	VARIANT-PRE-COMPILE: PRE-COMPILE

4.32 Parameter AeSpiAccessSynchronous

This parameter is used to define whether the access to the Spi sequence is synchronous or asynchronous.

Property	Value
type	ECUC-BOOLEAN-PARAM-DEF
origin	NXP
symbolicNameValue	false
lowerMultiplicity	1
upperMultiplicity	1
postBuildVariantMultiplicity	N/A
multiplicityConfigClasses	N/A
postBuildVariantValue	false
valueConfigClasses	VARIANT-POST-BUILD: PRE-COMPILE
	VARIANT-PRE-COMPILE: PRE-COMPILE
default Value	false

4.33 Reference AeSpiSequenceName

Reference to a Spi sequence configuration container.

Property	Value
type	ECUC-REFERENCE-DEF
origin	NXP
lowerMultiplicity	1
upperMultiplicity	1
postBuildVariantMultiplicity	N/A
multiplicityConfigClasses	N/A
postBuildVariantValue	false
valueConfigClasses	VARIANT-POST-BUILD: PRE-COMPILE
	VARIANT-PRE-COMPILE: PRE-COMPILE
requiresSymbolicNameValue	False
destination	/AUTOSAR/EcuDefs/Spi/SpiDriver/SpiSequence

4.34 Container AeIrqConfig

Generic configuration for the interrupts (events, faults).

Included subcontainers:

- [AeIntConfig](#)

Property	Value
type	ECUC-PARAM-CONF-CONTAINER-DEF
lowerMultiplicity	1
upperMultiplicity	1
postBuildVariantMultiplicity	N/A
multiplicityConfigClasses	N/A

4.35 Container AeIntConfig

Vendor specific:

Configuration for interrupt requests.

Included subcontainers:

- None

Property	Value
type	ECUC-PARAM-CONF-CONTAINER-DEF
lowerMultiplicity	25
upperMultiplicity	25
postBuildVariantMultiplicity	N/A
multiplicityConfigClasses	N/A

4.36 Parameter AeIntName

Vendor specific:

Interrupt Name caused by faults or events.

Property	Value
type	ECUC-ENUMERATION-PARAM-DEF
origin	NXP
symbolicNameValue	false
lowerMultiplicity	1
upperMultiplicity	1
postBuildVariantMultiplicity	N/A
multiplicityConfigClasses	N/A
postBuildVariantValue	false
valueConfigClasses	VARIANT-PRE-COMPILE: PRE-COMPILE VARIANT-POST-BUILD: PRE-COMPILE
defaultValue	LIN_INT
literals	['LIN_INT', 'OCD_VDDE', 'TEMP_WDG_PMC', 'TEMP_WDG_PHY', 'CAN_INT', 'LVD_VDDC', 'WAKEUP', 'HVI_ACTIVE', 'HVI_AE_SUPPLY', 'STATERESET', 'FRAMEWIDTH', 'GDU_FAULT_PROT', 'GDU_INT', 'DPA_PG_A_OC_NEG', 'DPA_PG_A_OC_POS', 'PMC_VLS', 'RAW_FAILED', 'CHKSUM_ERR', 'OBSCHK_ERR', 'XFER_ERR', 'EVENT_EXPIRED', 'MCU_SUPPLY', 'HVD_AE_INTERN', 'ILL_TEST', 'ALIVE_WDG']

4.37 Parameter AeIsrEnabled

Vendor specific: Enable to raise interrupt_out for events/faults which owned by AEC.

Property	Value
type	ECUC-BOOLEAN-PARAM-DEF
origin	NXP
symbolicNameValue	false
lowerMultiplicity	1

Property	Value
upperMultiplicity	1
postBuildVariantMultiplicity	N/A
multiplicityConfigClasses	N/A
postBuildVariantValue	false
valueConfigClasses	VARIANT-PRE-COMPILE: PRE-COMPILE
	VARIANT-POST-BUILD: PRE-COMPILE
defaultValue	false

4.38 Parameter AeIsrPriority

Set priority to handle for event or fault which caused interrupt.

Priority's value smaller that will be handled first.

Property	Value
type	ECUC-INTEGER-PARAM-DEF
origin	NXP
symbolicNameValue	true
lowerMultiplicity	1
upperMultiplicity	1
postBuildVariantMultiplicity	N/A
multiplicityConfigClasses	N/A
postBuildVariantValue	false
valueConfigClasses	VARIANT-POST-BUILD: PRE-COMPILE
	VARIANT-PRE-COMPILE: PRE-COMPILE
defaultValue	0
max	N/A
min	0

4.39 Parameter AeIntHandler

Function to be installed as the interrupt handler.

Property	Value
type	ECUC-FUNCTION-NAME-DEF
origin	NXP
symbolicNameValue	false
lowerMultiplicity	1
upperMultiplicity	1

Property	Value
postBuildVariantMultiplicity	N/A
multiplicityConfigClasses	N/A
postBuildVariantValue	false
valueConfigClasses	VARIANT-PRE-COMPILE: PRE-COMPILE
	VARIANT-POST-BUILD: PRE-COMPILE
defaultValue	undefined_handler

4.40 Container CommonPublishedInformation

Common container, aggregated by all modules. It contains published information about vendor and versions.

Included subcontainers:

- None

Property	Value
type	ECUC-PARAM-CONF-CONTAINER-DEF
lowerMultiplicity	1
upperMultiplicity	1
postBuildVariantMultiplicity	N/A
multiplicityConfigClasses	N/A

4.41 Parameter ModuleId

Module ID of this module from the BSW Module List.

Property	Value
type	ECUC-INTEGER-PARAM-DEF
origin	NXP
symbolicNameValue	false
lowerMultiplicity	1
upperMultiplicity	1
postBuildVariantMultiplicity	N/A
multiplicityConfigClasses	N/A
postBuildVariantValue	false
valueConfigClasses	VARIANT-POST-BUILD: PUBLISHED-INFORMATION
	VARIANT-PRE-COMPILE: PUBLISHED-INFORMATION
defaultValue	250
max	250
min	250

4.42 Parameter VendorId

Vendor ID of the dedicated implementation of this module according to the AUTOSAR vendor list.

Property	Value
type	ECUC-INTEGER-PARAM-DEF
origin	NXP
symbolicNameValue	false
lowerMultiplicity	1
upperMultiplicity	1
postBuildVariantMultiplicity	N/A
multiplicityConfigClasses	N/A
postBuildVariantValue	false
valueConfigClasses	VARIANT-POST-BUILD: PUBLISHED-INFORMATION
	VARIANT-PRE-COMPILE: PUBLISHED-INFORMATION
defaultValue	43
max	43
min	43

4.43 Parameter VendorApiInfix

In driver modules which can be instantiated several times on a single ECU,

BSW00347 requires that the name of APIs is extended by the VendorId and a vendor specific name.

This parameter is used to specify the vendor specific name.

In total, the implementation specific name is generated as follows:

[ModuleName]_[VendorId]_[VendorApiInfix][API name from SWS].

E.g. Assuming that the VendorId of the implementor is 123 and the implementer chose a

VendorApiInfix of 'v11r456' an API named Can_Write defined in the SWS will translate to Can_123_v11r456Write.

This parameter is mandatory for all modules with upper multiplicity > 1.

It shall not be used for modules with upper multiplicity = 1.

Property	Value
type	ECUC-STRING-PARAM-DEF
origin	NXP
symbolicNameValue	false
lowerMultiplicity	0
upperMultiplicity	1

Property	Value
postBuildVariantMultiplicity	false
multiplicityConfigClasses	VARIANT-POST-BUILD: PUBLISHED-INFORMATION
	VARIANT-PRE-COMPILE: PUBLISHED-INFORMATION
postBuildVariantValue	false
valueConfigClasses	VARIANT-POST-BUILD: PUBLISHED-INFORMATION
	VARIANT-PRE-COMPILE: PUBLISHED-INFORMATION
defaultValue	

4.44 Parameter ArReleaseMajorVersion

Major version number of AUTOSAR specification on which the appropriate implementation is based on.

Property	Value
type	ECUC-INTEGER-PARAM-DEF
origin	NXP
symbolicNameValue	false
lowerMultiplicity	1
upperMultiplicity	1
postBuildVariantMultiplicity	N/A
multiplicityConfigClasses	N/A
postBuildVariantValue	false
valueConfigClasses	VARIANT-POST-BUILD: PUBLISHED-INFORMATION
	VARIANT-PRE-COMPILE: PUBLISHED-INFORMATION
defaultValue	4
max	4
min	4

4.45 Parameter ArReleaseMinorVersion

Minor version number of AUTOSAR specification on which the appropriate implementation is based on.

Property	Value
type	ECUC-INTEGER-PARAM-DEF
origin	NXP
symbolicNameValue	false
lowerMultiplicity	1
upperMultiplicity	1
postBuildVariantMultiplicity	N/A
multiplicityConfigClasses	N/A

Property	Value
postBuildVariantValue	false
valueConfigClasses	VARIANT-POST-BUILD: PUBLISHED-INFORMATION
	VARIANT-PRE-COMPILE: PUBLISHED-INFORMATION
defaultValue	7
max	7
min	7

4.46 Parameter ArReleaseRevisionVersion

Revision version number of AUTOSAR specification on which the appropriate implementation is based on.

Property	Value
type	ECUC-INTEGER-PARAM-DEF
origin	NXP
symbolicNameValue	false
lowerMultiplicity	1
upperMultiplicity	1
postBuildVariantMultiplicity	N/A
multiplicityConfigClasses	N/A
postBuildVariantValue	false
valueConfigClasses	VARIANT-POST-BUILD: PUBLISHED-INFORMATION
	VARIANT-PRE-COMPILE: PUBLISHED-INFORMATION
defaultValue	0
max	0
min	0

4.47 Parameter SwMajorVersion

Major version number of the vendor specific implementation of the module. The numbering is vendor specific.

Property	Value
type	ECUC-INTEGER-PARAM-DEF
origin	NXP
symbolicNameValue	false
lowerMultiplicity	1
upperMultiplicity	1
postBuildVariantMultiplicity	N/A
multiplicityConfigClasses	N/A
postBuildVariantValue	false
valueConfigClasses	VARIANT-POST-BUILD: PUBLISHED-INFORMATION

Property	Value
	VARIANT-PRE-COMPILE: PUBLISHED-INFORMATION
defaultValue	3
max	3
min	3

4.48 Parameter SwMinorVersion

Minor version number of the vendor specific implementation of the module. The numbering is vendor specific.

Property	Value
type	ECUC-INTEGER-PARAM-DEF
origin	NXP
symbolicNameValue	false
lowerMultiplicity	1
upperMultiplicity	1
postBuildVariantMultiplicity	N/A
multiplicityConfigClasses	N/A
postBuildVariantValue	false
valueConfigClasses	VARIANT-POST-BUILD: PUBLISHED-INFORMATION
	VARIANT-PRE-COMPILE: PUBLISHED-INFORMATION
defaultValue	0
max	0
min	0

4.49 Parameter SwPatchVersion

Patch version number of the vendor specific implementation of the module. The numbering is vendor specific.

Property	Value
type	ECUC-INTEGER-PARAM-DEF
origin	NXP
symbolicNameValue	false
lowerMultiplicity	1
upperMultiplicity	1
postBuildVariantMultiplicity	N/A
multiplicityConfigClasses	N/A
postBuildVariantValue	false
valueConfigClasses	VARIANT-POST-BUILD: PUBLISHED-INFORMATION
	VARIANT-PRE-COMPILE: PUBLISHED-INFORMATION
defaultValue	0

Tresos Configuration Plug-in

Property	Value
max	0
min	0

This chapter describes the Tresos configuration plug-in for the Ae Driver. The most of the parameters are described below.



Chapter 5

Module Index

5.1 Software Specification

Here is a list of all modules:

AEC Driver	36
HVM Driver	41
Ae Driver	45

Chapter 6

Module Documentation

6.1 AEC Driver

6.1.1 Detailed Description

6.1.1.1 Functions Expectation called for read/write value from/to AE's registers in polling/interrupt mode:

- `Aec_Ip_Init`
- `Aec_Ip_SpiWrite`
- `Aec_Ip_SpiRead`

Data Structures

- struct [Aec_Ip_SpiConfigType](#)
SPI configuration for access Implements : `Aec_Ip_SpiConfigType_Class`. [More...](#)
- struct [Aec_Ip_IntRouteConfigType](#)
Structure storing the routing and handler configuration for an interrupt request. [More...](#)

Types Reference

- typedef void(* [Aec_Ip_IntHandlerType](#)) (void)
Interrupt handler type.

Enum Reference

- enum [Aec_Ip_StatusType](#)

Function Reference

- [Aec_Ip_StatusType Aec_Ip_Init](#) (const Aec_Ip_ConfigType *AecConfig)
Initializes the Aec Driver.
- [Aec_Ip_StatusType Aec_Ip_SpiWrite](#) (uint32 RegAddr, uint8 DataWidth, uint32 Data)
Write Value to indexed register by Register address through SPI.
- [Aec_Ip_StatusType Aec_Ip_SpiRead](#) (uint32 RegAddr, uint8 DataWidth, uint32 *Data)
Read Value return from indexed register by Register address through SPI.
- boolean [Aec_Ip_Spi_Frame_Counter](#) (boolean IsVerify, uint8 ExpectedFrameCount, uint8 *ActualFrameCount)
Verify for correctness the received frame counter or just read number of frames.
- uint16 [Aec_Ip_DecodeGlobalHeathStatus](#) (void)
Return status of global heath.

6.1.2 Data Structure Documentation

6.1.2.1 struct Aec_Ip_SpiConfigType

SPI configuration for access Implements : Aec_Ip_SpiConfigType_Class.

Definition at line 88 of file Aec_Ip_Types.h.

6.1.2.2 struct Aec_Ip_IntRouteConfigType

Structure storing the routing and handler configuration for an interrupt request.

Definition at line 114 of file Aec_Ip_Types.h.

Data Fields

- uint16 [IsrMask](#)
Name of event/fault.
- uint8 [IsrPriority](#)
Priority for event/fault.
- [Aec_Ip_IntHandlerType pfHandler](#)
Interrupt handler.

6.1.2.2.1 Field Documentation

6.1.2.2.1.1 [IsrMask](#) uint16 [IsrMask](#)

Name of event/fault.

Definition at line 117 of file Aec_Ip_Types.h.

6.1.2.2.1.2 IsrPriority `uint8 IsrPriority`

Priority for event/fault.

Definition at line 119 of file `Aec_Ip_Types.h`.

6.1.2.2.1.3 pfHandler `Aec_Ip_IntHandlerType pfHandler`

Interrupt handler.

Definition at line 121 of file `Aec_Ip_Types.h`.

6.1.3 Types Reference

6.1.3.1 Aec_Ip_IntHandlerType

```
typedef void(* Aec_Ip_IntHandlerType) (void)
```

Interrupt handler type.

Definition at line 108 of file `Aec_Ip_Types.h`.

6.1.4 Enum Reference

6.1.4.1 Aec_Ip_StatusType

```
enum Aec_Ip_StatusType
```

Enumerator

<code>AEC_STATUS_SUCCESS</code>	Generic operation success status
<code>AEC_STATUS_ERROR</code>	Generic operation failure status
<code>AEC_STATUS_TIMEOUT</code>	Generic operation timeout status

Definition at line 95 of file `Aec_Ip_Types.h`.

6.1.5 Function Reference

6.1.5.1 Aec_Ip_Init()

```
Aec_Ip_StatusType Aec_Ip_Init (  
    const Aec_Ip_ConfigType * AecConfig )
```

Initializes the Aec Driver.

The configuration pointer is internally stored and the driver is initialized.

Return AEC_STATUS_SUCCESS if initialized successful. AEC_STATUS_TIMEOUT if initialized failed.

6.1.5.2 Aec_Ip_SpiWrite()

```
Aec_Ip_StatusType Aec_Ip_SpiWrite (
    uint32 RegAddr,
    uint8 DataWidth,
    uint32 Data )
```

Write Value to indexed register by Register address through SPI.

Parameters

in	<i>RegAddr</i>	Register address want to write to.
in	<i>DataWidth</i>	Size of register in AEC that want to read/write.
in	<i>Data</i>	Value want to write to indexed register.

6.1.5.3 Aec_Ip_SpiRead()

```
Aec_Ip_StatusType Aec_Ip_SpiRead (
    uint32 RegAddr,
    uint8 DataWidth,
    uint32 * Data )
```

Read Value return from indexed register by Register address through SPI.

Parameters

in	<i>RegAddr</i>	Register address want to read from.
in	<i>DataWidth</i>	Size of register in AEC that want to read/write.
out	<i>Data</i>	Value want to read from indexed register.

6.1.5.4 Aec_Ip_Spi_Frame_Counter()

```
boolean Aec_Ip_Spi_Frame_Counter (
    boolean IsVerify,
```

Module Documentation

```
uint8 ExpectedFrameCount,  
uint8 * ActualFrameCount )
```

Verify for correctness the received frame counter or just read number of frames.

Parameters

in	<i>IsVerify</i>	want to verify for correctness for frame counter.
in	<i>ExpectedFrameCount</i>	Number of frame expected get.
out	<i>ActualFrameCount</i>	Number of frame get in real.

return TRUE if verify correct.

6.1.5.5 Aec_Ip_DecodeGlobalHeathStatus()

```
uint16 Aec_Ip_DecodeGlobalHeathStatus (  
    void )
```

Return status of global heath.

6.2 HVM Driver

6.2.1 Detailed Description

6.2.1.1 Functions Expectation called first for configuration initilized:

- `Hvm_Ip_Init`

Enum Reference

- enum `Hvm_Ip_StatusType`
- enum `Hvm_Ip_OutputStatusType`

Function Reference

- `Hvm_Ip_StatusType Hvm_Ip_Init` (const `Hvm_Ip_ConfigType` *pHvmConfig)
Initializes the Hvm Driver.
- `Hvm_Ip_StatusType Hvm_Ip_AdcMeasureConfig` (const `Ae_HviHighVoltageInputConfig` *pHviHighVoltageInputConfig, `Ae_AnalogInputType` AnalogInputSelect)
Initializes the configuration for analog input for measurement.
- `Hvm_Ip_StatusType Hvm_Ip_DigitalInputEventConfig` (const `Ae_HviChannelConfig` *pHviConfig)
Initializes the configuration for digital input.
- `Hvm_Ip_StatusType Hvm_Ip_VoltageMonitorConfig` (const `Ae_VmConfig` *pAeVmConfig, const `Ae_HviHighVoltageInputConfig` *pHighVoltageInput)
Initializes the configuration for Voltage Monitor.
- void `Hvm_Ip_ReadFaultsEventsStatus` (void)
Check status flag used in polling mode.
- void `Hvm_Ip_FaultsEventsProccess` (void)
Check and clear interrupt flag used in interrupt mode.

6.2.2 Enum Reference

6.2.2.1 Hvm_Ip_StatusType

enum `Hvm_Ip_StatusType`

Enumerator

<code>HVM_STATUS_SUCCESS</code>	Generic operation success status
<code>HVM_STATUS_ERROR</code>	Generic operation failure status
<code>HVM_STATUS_TIMEOUT</code>	Generic operation timeout status

Definition at line 71 of file Hvm_Ip_Types.h.

6.2.2.2 Hvm_Ip_OutputStatusType

```
enum Hvm_Ip_OutputStatusType
```

Enumerator

HVM_STATUS_NOTHING_DETECT	Generic operation nothing detect status
HVM_STATUS_HIGH_DETECT	Generic operation high voltage detect status
HVM_STATUS_LOW_DETECT	Generic operation low voltage detect status
HVM_STATUS_DIGITAL_INPUT_ACTIVE	Generic operation digital input active status
HVM_STATUS_OUTPUT_ERROR	Generic operation failure status

Definition at line 80 of file Hvm_Ip_Types.h.

6.2.3 Function Reference

6.2.3.1 Hvm_Ip_Init()

```
Hvm_Ip_StatusType Hvm_Ip_Init (
    const Hvm_Ip_ConfigType * pHvmConfig )
```

Initializes the Hvm Driver.

The configuration pointer is internally stored and the driver is initialized.

Parameters

in	<i>HvmConfig</i>	Pointer to the module configuration structure
----	------------------	---

Return values

<i>HVM_STATUS_SUCCESS</i>	The initialization was successful.
---------------------------	------------------------------------

6.2.3.2 Hvm_Ip_AdcMeasureConfig()

```
Hvm_Ip_StatusType Hvm_Ip_AdcMeasureConfig (
    const Ae_HviHighVoltageInputConfig * pHviHighVoltConfig,
    Ae_AnalogInputType AnalogInputSelect )
```

Initializes the configuration for analog input for measurement.

Base on configuration to select analog input, HVI channel, divider if high voltage input selected.

Parameters

in	<i>pHviHighVoltConfig</i>	Pointer to configuration for High Voltage Input. AnalogInputSelect Type of analog input.
----	---------------------------	--

Return values

<i>HVM_STATUS_SUCCESS</i>	The initialization was successful.
---------------------------	------------------------------------

6.2.3.3 Hvm_Ip_DigitalInputEventConfig()

```
Hvm_Ip_StatusType Hvm_Ip_DigitalInputEventConfig (
    const Ae_HviChannelConfig * pHviConfig )
```

Initializes the configuration for digital input.

Initializes the configuration for digital input include: voltage input source, divider, mode polling or interrupt used.

Parameters

in	<i>pHviConfig</i>	HVI channels configuration.
----	-------------------	-----------------------------

Return values

<i>HVM_STATUS_SUCCESS</i>	The initialization was successful.
---------------------------	------------------------------------

6.2.3.4 Hvm_Ip_VoltageMonitorConfig()

```
Hvm_Ip_StatusType Hvm_Ip_VoltageMonitorConfig (
    const Ae_VmConfig * pAeVmConfig,
    const Ae_HviHighVoltageInputConfig * pHighVoltageInput )
```

Initializes the configuration for Voltage Monitor.

Initializes the configuration for High/Low voltage detect.

Parameters

in	<i>pAeVmConfig</i>	Pointer to configuration of VM.
in	<i>pHighVoltageInput</i>	Pointer to configuration of High Voltage Input.

Return values

<i>HVM_STATUS_SUCCESS</i>	The initialization was successful.
---------------------------	------------------------------------

6.2.3.5 Hvm_Ip_ReadFaultsEventsStatus()

```
void Hvm_Ip_ReadFaultsEventsStatus (
    void )
```

Check status flag used in polling mode.

This function used to read status flag for digital input, high voltage, low voltage detect.

6.2.3.6 Hvm_Ip_FaultsEventsProccess()

```
void Hvm_Ip_FaultsEventsProccess (
    void )
```

Check and clear interrupt flag used in interrupt mode.

Check interrupt flag, clear flag if event (digital input, high voltage, low voltage detected) occurred.

6.3 Ae Driver

6.3.1 Detailed Description

Macros

- `#define AE_SID_INIT`
Service ID of Ae_Init.
- `#define AE_SID_WRITEREGISTER`
Service ID of Ae_WriteRegister.
- `#define AE_SID_READREGISTER`
Service ID of Ae_ReadRegister.
- `#define AE_SID_GETVERSIONINFO`
Service ID of Ae_GetVersionInfo.
- `#define AE_SID_ADCMEASURECONFIG`
Service ID of Ae_AdcMeasureConfig.
- `#define AE_SID_DIGITALINPUTCONFIG`
Service ID of Ae_DigitalInputEventConfig.
- `#define AE_SID_VOLTAGEMONITORCONFIG`
Service ID of Ae_VoltageMonitorConfig.
- `#define AE_SID_DECODEGLOBALHEATHSTATUS`
Service ID of Ae_DecompileGlobalHeathStatus.
- `#define AE_SID_FRAMECOUNTER`
Service ID of Ae_Frame_Counter.
- `#define AE_SID_FAULTSEVENTSPROCESS`
Service ID of Ae_FaultsEventsProccess.
- `#define AE_SID_READFAULTSEVENTSSTATUS`
Service ID of Ae_ReadFaultsEventsStatus.
- `#define AE_E_INV_CTRL_IDX`
Development Error ID for "Invalid Controller Index".
- `#define AE_E_UNINIT`
Development Error ID for "Uninitialized Controller".
- `#define AE_E_PARAM_POINTER`
Development Error ID for "Invalid (Null) Pointer Parameter".
- `#define AE_E_INV_PARAM`
Development Error ID for "Invalid Parameter".
- `#define AE_E_INV_MODE`
Development Error ID for "Invalid Controller Mode".
- `#define AE_E_INIT_FAILED`
Development Error ID for "Invalid Configuration pointer argument".

Function Reference

- void [Ae_Init](#) (const Ae_ConfigType *CfgPtr)
Initializes the Ae Driver.
- Std_ReturnType [Ae_ReadRegister](#) (uint32 RegAddr, uint8 DataWidth, uint32 *RegValPtr)
Read register value.
- Std_ReturnType [Ae_WriteRegister](#) (uint32 RegAddr, uint8 DataWidth, uint32 RegVal)
Write register value.
- uint16 [Ae_DecodeGlobalHeathStatus](#) (void)
Return status of global heath.
- boolean [Ae_Frame_Counter](#) (boolean IsVerify, uint8 ExpectedFrameCount, uint8 *ActualFrameCount)
Verify for correctness the received frame counter or just number of frames.
- Std_ReturnType [Ae_AdcMeasureConfig](#) (const Ae_HviHighVoltageInputConfig *pHviHighVoltConfig, Ae_AnalogInputType AnalogInputSelect)
Initializes the configuration for analog input for measurement.
- Std_ReturnType [Ae_DigitalInputEventConfig](#) (const Ae_HviChannelConfig *pAeHviChannelConfig)
Initializes the configuration for digital input.
- Std_ReturnType [Ae_VoltageMonitorConfig](#) (const Ae_VmConfig *pAeVmConfig, const Ae_HviHighVoltageInputConfig *pHighVoltageInput)
Initializes the configuration for High/Low Voltage detect.
- void [Ae_FaultsEventsProcess](#) (void)
Check and clear interrupt flag used in interrupt mode.
- void [Ae_ReadFaultsEventsStatus](#) (void)
Check status flag used in polling mode for digital input, high/low voltage detect.
- void [Ae_GetVersionInfo](#) (Std_VersionInfoType *VersionInfoPtr)
Returns the version information of this module.

6.3.2 Macro Definition Documentation

6.3.2.1 AE_SID_INIT

```
#define AE_SID_INIT
```

Service ID of Ae_Init.

Definition at line 80 of file Ae.h.

6.3.2.2 AE_SID_WRITEREGISTER

```
#define AE_SID_WRITEREGISTER
```

Service ID of Ae_WriteRegister.

Definition at line 82 of file Ae.h.

6.3.2.3 AE_SID_READREGISTER

```
#define AE_SID_READREGISTER
```

Service ID of Ae_ReadRegister.

Definition at line 84 of file Ae.h.

6.3.2.4 AE_SID_GETVERSIONINFO

```
#define AE_SID_GETVERSIONINFO
```

Service ID of Ae_GetVersionInfo.

Definition at line 86 of file Ae.h.

6.3.2.5 AE_SID_ADCMEASURECONFIG

```
#define AE_SID_ADCMEASURECONFIG
```

Service ID of Ae_AdcMeasureConfig.

Definition at line 88 of file Ae.h.

6.3.2.6 AE_SID_DIGITALINPUTCONFIG

```
#define AE_SID_DIGITALINPUTCONFIG
```

Service ID of Ae_DigitalInputEventConfig.

Definition at line 90 of file Ae.h.

6.3.2.7 AE_SID_VOLTAGEMONITORCONFIG

```
#define AE_SID_VOLTAGEMONITORCONFIG
```

Service ID of Ae_VoltageMonitorConfig.

Definition at line 92 of file Ae.h.

6.3.2.8 AE_SID_DECODEGLOBALHEATHSTATUS

```
#define AE_SID_DECODEGLOBALHEATHSTATUS
```

Service ID of Ae_DecodeGlobalHeathStatus.

Definition at line 94 of file Ae.h.

6.3.2.9 AE_SID_FRAMECOUNTER

```
#define AE_SID_FRAMECOUNTER
```

Service ID of Ae_Frame_Counter.

Definition at line 96 of file Ae.h.

6.3.2.10 AE_SID_FAULTSEVENTSPROCESS

```
#define AE_SID_FAULTSEVENTSPROCESS
```

Service ID of Ae_FaultsEventsProcess.

Definition at line 98 of file Ae.h.

6.3.2.11 AE_SID_READFAULTSEVENTSSTATUS

```
#define AE_SID_READFAULTSEVENTSSTATUS
```

Service ID of Ae_ReadFaultsEventsStatus.

Definition at line 100 of file Ae.h.

6.3.2.12 AE_E_INV_CTRL_IDX

```
#define AE_E_INV_CTRL_IDX
```

Development Error ID for "Invalid Controller Index".

Definition at line 106 of file Ae.h.

6.3.2.13 AE_E_UNINIT

```
#define AE_E_UNINIT
```

Development Error ID for "Uninitialized Controller".

Definition at line 108 of file Ae.h.

6.3.2.14 AE_E_PARAM_POINTER

```
#define AE_E_PARAM_POINTER
```

Development Error ID for "Invalid (Null) Pointer Parameter".

Definition at line 110 of file Ae.h.

6.3.2.15 AE_E_INV_PARAM

```
#define AE_E_INV_PARAM
```

Development Error ID for "Invalid Parameter".

Definition at line 112 of file Ae.h.

6.3.2.16 AE_E_INV_MODE

```
#define AE_E_INV_MODE
```

Development Error ID for "Invalid Controller Mode".

Definition at line 114 of file Ae.h.

6.3.2.17 AE_E_INIT_FAILED

```
#define AE_E_INIT_FAILED
```

Development Error ID for "Invalid Configuration pointer argument".

Definition at line 116 of file Ae.h.

6.3.3 Function Reference

6.3.3.1 Ae_Init()

```
void Ae_Init (
    const Ae_ConfigType * CfgPtr )
```

Initializes the Ae Driver.

The configuration pointer is internally stored and the driver is initialized.

6.3.3.2 Ae_ReadRegister()

```
Std_ReturnType Ae_ReadRegister (
    uint32 RegAddr,
    uint8 DataWidth,
    uint32 * RegValPtr )
```

Read register value.

Read register value.

Parameters

in	<i>RegAddr</i>	Index of the AE register to be read.
in	<i>DataWidth</i>	Size of register in AEC that want to read/write.
out	<i>RegValPtr</i>	Filled with the register content of the indexed register

Return E_OK if read value from register successful. E_NOT_OK E_OK if read value from register failure.

6.3.3.3 Ae_WriteRegister()

```
Std_ReturnType Ae_WriteRegister (
    uint32 RegAddr,
    uint8 DataWidth,
    uint32 RegVal )
```

Write register value.

Write register value.

Parameters

in	<i>RegAddr</i>	Index of the AE register to be write.
in	<i>DataWidth</i>	Size of register in AEC that want to read/write.
in	<i>RegVal</i>	Filled with the register content of the indexed register

Return E_OK if write value from register successful. E_NOT_OK E_OK if write value from register failure.

6.3.3.4 Ae_DecodeGlobalHeathStatus()

```
uint16 Ae_DecodeGlobalHeathStatus (
    void )
```

Return status of global heath.

6.3.3.5 Ae_Frame_Counter()

```
boolean Ae_Frame_Counter (
    boolean IsVerify,
    uint8 ExpectedFrameCount,
    uint8 * ActualFrameCount )
```

Verify for correctness the received frame counter or just number of frames.

Parameters

in	<i>IsVerify</i>	want to verify for correctness for frame counter.
in	<i>ExpectedFrameCount</i>	Number of frame expected get.
out	<i>ActualFrameCount</i>	Number of frame get in real.

Return counter status of respond frame from AE_Robin.

6.3.3.6 Ae_AdcMeasureConfig()

```
Std_ReturnType Ae_AdcMeasureConfig (
    const Ae_HviHighVoltageInputConfig * pHviHighVoltConfig,
    Ae_AnalogInputType AnalogInputSelect )
```

Initializes the configuration for analog input for measurement.

Parameters

in	<i>pHviHighVoltConfig</i>	Pointer for configuration of High Voltage Input.
in	<i>AnalogInputSelect</i>	Type of Analog Input.

Return E_OK The initialization was successful.

6.3.3.7 Ae_DigitalInputEventConfig()

```
Std_ReturnType Ae_DigitalInputEventConfig (
    const Ae_HviChannelConfig * pAeHviChannelConfig )
```

Initializes the configuration for digital input.

Parameters

in	<i>pAeHviChannelConfig</i>	Pointer to configuration of HVI channel.
----	----------------------------	--

Return E_OK The initialization was successful.

6.3.3.8 Ae_VoltageMonitorConfig()

```
Std_ReturnType Ae_VoltageMonitorConfig (
    const Ae_VmConfig * pAeVmConfig,
    const Ae_HviHighVoltageInputConfig * pHighVoltageInput )
```

Initializes the configuration for High/Low Voltage detect.

Parameters

in	<i>pAeVmConfig</i>	Pointer to configuration of VM.
in	<i>pHighVoltageInput</i>	Pointer to configuration of High Voltage Input.

Return E_OK The initialization was successful.

6.3.3.9 Ae_FaultsEventsProcess()

```
void Ae_FaultsEventsProcess (
    void )
```

Check and clear interrupt flag used in interrupt mode.

Return Interrupt flag want to read raised or not.

6.3.3.10 Ae_ReadFaultsEventsStatus()

```
void Ae_ReadFaultsEventsStatus (
    void )
```

Check status flag used in polling mode for digital input, high/low voltage detect.

6.3.3.11 Ae_GetVersionInfo()

```
void Ae_GetVersionInfo (
    Std_VersionInfoType * VersionInfoPtr )
```

Returns the version information of this module.

Parameters

out	<i>VersionInfoPtr</i>	Pointer where to store the version information of this particular module instance. implements Ae_GetVersionInfo_Activity
-----	-----------------------	---

How to Reach Us:

Home Page:

nxp.com

Web Support:

nxp.com/support

Information in this document is provided solely to enable system and software implementers to use NXP products. There are no express or implied copyright licenses granted hereunder to design or fabricate any integrated circuits based on the information in this document. NXP reserves the right to make changes without further notice to any products herein.

NXP makes no warranty, representation, or guarantee regarding the suitability of its products for any particular purpose, nor does NXP assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters that may be provided in NXP data sheets and/or specifications can and do vary in different applications, and actual performance may vary over time. All operating parameters, including "typicals," must be validated for each customer application by customer's technical experts. NXP does not convey any license under its patent rights nor the rights of others. NXP sells products pursuant to standard terms and conditions of sale, which can be found at the following address: nxp.com/SalesTermsandConditions.

NXP, the NXP logo, NXP SECURE CONNECTIONS FOR A SMARTER WORLD, COOLFLUX, EMBRACE, GREENCHIP, HITAG, I2C BUS, ICODE, JCOP, LIFE VIBES, MIFARE, MIFARE CLASSIC, MIFARE DESFire, MIFARE PLUS, MIFARE FLEX, MANTIS, MIFARE ULTRALIGHT, MIFARE4MOBILE, MIGLO, NTAG, ROADLINK, SMARTLX, SMARTMX, STARPLUG, TOPFET, TRENCHMOS, UCODE, Freescale, the Freescale logo, Altivec, C-5, CodeTEST, CodeWarrior, ColdFire, ColdFire+, C-Ware, the Energy Efficient Solutions logo, Kinetis, Layerscape, MagniV, mobileGT, PEG, PowerQUICC, Processor Expert, QorIQ, QorIQ Qonverge, Ready Play, SafeAssure, the SafeAssure logo, StarCore, Symphony, VortiQa, Vybrid, Airfast, BeeKit, BeeStack, CoreNet, Flexis, MXC, Platform in a Package, QUICC Engine, SMARTMOS, Tower, TurboLink, and UMEMS are trademarks of NXP B.V. All other product or service names are the property of their respective owners. ARM, AMBA, ARM Powered, Artisan, Cortex, Jazelle, Keil, SecurCore, Thumb, TrustZone, and Vision are registered trademarks of ARM Limited (or its subsidiaries) in the EU and/or elsewhere. ARM7, ARM9, ARM11, big.LITTLE, CoreLink, CoreSight, DesignStart, Mali, mbed, NEON, POP, Sensinode, Socrates, ULINK and Versatile are trademarks of ARM Limited (or its subsidiaries) in the EU and/or elsewhere. All rights reserved. Oracle and Java are registered trademarks of Oracle and/or its affiliates. The Power Architecture and Power.org word marks and the Power and Power.org logos and related marks are trademarks and service marks licensed by Power.org.

© 2023 NXP B.V.

